

**PROCESS DESCRIPTION  
FOR  
MICRONIZED COAL RE-BURNING PROJECT  
FOR  
NYSEG/KODAK  
NEW YORK, U.S.A.**

**BY  
FULLER MINERAL PROCESSING, INC.  
BETHLEHEM, PENNSYLVANIA**

**Document No. 8.700865  
Revision No. 3  
August 14, 1996**

 <b>FULLER MINERAL PROCESSING, INC.</b>	<b>CERTIFIED FOR CONSTRUCTION</b> <i>Lawrence J. Dupon</i>	SIGNATURE _____ DATE: <b>AUG 15 1996</b>
---	---	---

REVISION NUMBER	DESCRIPTION	PREPARED BY	APPROVED BY	DATE
0	INITIAL ISSUE	J.R.	B.J.Z./L.S.	05/10/96
1	GENERAL REVISIONS	J.R.	B.J.Z./L.S.	05/31/96
2	Added Bearing Housing Water Jacket System	L.S.	B.J.Z./D.F.	07/29/96
3	Added Safety procedures for shutdown	L.S.	B.J.Z.	08/14/96

**TABLE OF CONTENTS**

A.	General Information .....	1
B.	System Description .....	1
C.	Normal Startup .....	3
D.	Normal Operation .....	5
E.	Normal Shutdown .....	6
F.	Abnormal Shutdown .....	7
G.	Emergency Shutdown .....	10

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

**A. GENERAL INFORMATION**

The Coal Grinding System will be used to process bituminous coal for the MCRP (Micronized Coal Re-burn Project).

**B. SYSTEM DESCRIPTION**

The Coal Milling System consists of two coal grinding mill circuits each containing the following equipment:

200HP Fuller-Microfuel 3018 Micromills [PM-CH-15B001E, PM-CH-15B001W] complete with lubrication and labyrinth seal systems [LU-CH-15B001E, LU-CH-15B001W] and each with a bearing housing cooling water jacket.

Plant air solenoid valve [SV-1A-15B040E, SV-1A-15B040W] for the Lubrication and labyrinth seal systems

Bearing Housing Water Jacket solenoid valve [SV-CW-15B003E, SV-CW-15B003W], manual isolation valve [HV-CW-15B001E, HV-CW-15B001W], flow switch [FS-CW-15B001E, FS-CW-15B001W], and throttle valve [HV-CW-15B002E, HV-CW-15B002W] arrangement (all by others).

Micromill classifiers [CL-CH-15B001E, CL-CH-15B001W]

Classifier rotary feeders [RV-CH-15B002E, RV-CH-15B002W]

Mill Flue-Gas inlet control dampers [CZ-TG-15B002E, CZ-TG-15B002W]

Mill inlet air flow meters [FT-TG-15B026E, FT-TG-15B026W]

Mill inlet rotary feeders [RV-CH-15B001E, RV-CH-15B001W]

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

In general all equipment may be operated in individual manual mode to permit maintenance testing of the equipment. If any equipment is operated in this manner, automatic operation of the group to which the piece of equipment belongs will not be permitted. Similarly, once an equipment group is selected for automatic group mode of operation, an individual piece of equipment cannot be operated in individual manual mode of operation.

When a piece of equipment is operated in its individual manual operating mode, only protection and personnel safety interlocks are operable.

The following sections in this document describe the operation of each of the micro mills in the following situations:

Normal Startup

Normal Operation

Normal Shutdowns

Abnormal Shutdowns

Emergency Shutdowns

For clarification of the process description, refer to the following Fuller drawings which show the process flow information for the system:

1.724705, Rev. 0

1.724706, Rev. 0

1.724707, Rev. 1

1.724708, Rev. 1

1.725164, Rev. 0

**C. Normal Startup of The Coal Milling System**

*Since both the Micromill circuits operate in the same manner, the operation described herein is for the Mill No. 1 circuit only. The operation of the second mill is identical.*

NOTE: For normal startup of the mill to proceed, it is necessary that the plant's compressed air supply (for the Mill seal air and lube mist system) and instrument air supply (for the control valve air) be fully available at the required pressure and volume. The plant cooling water supply (for the Mill Bearing Housing Water Jacket) should also be fully available at the required temperature and flow. In addition, the boiler must be in its normal operating state and ready to accept Micronized coal through the new burners. Finally, the Mill Tramp iron gate must be closed as sensed by limit switch [ZSC-CH-15B012E].

3

The Micromill startup proceeds in the sequence described in the following paragraphs:

When the boiler is ready to accept Micronized coal through the new burners and the Transport Gas Fan is running, an alarm bell (by others) will ring for seven (7) seconds to notify anyone near the system of the pending start of the Coal Milling System.

First the Mill Air Supply Solenoid Valve [SV-1A-15B040E] is energized, establishing the Mill Labyrinth Air Seal System, starting the Mill Mist Lubrication System, and simultaneously starting the Mill Lube Mist Demister Unit [TK-CH-15B001]. At the same time that the Mill Air Supply Solenoid Valve [SV-1A-15B040E] is energized, the Mill Bearing Housing Water Jacket solenoid [SV-CW-15B003E, by others] is energized, initiating the closed loop water cooling system for the bearing housing.

After the Labyrinth Seal and Lube System compressed air pressure is above the minimum required pressure (44 psi) as sensed by pressure switch [PS-1A-15B003E], the Tramp Iron Gate is closed as sensed by its position switch [ZSC-CH-15B012E], and the Mill Bearing Housing Water Jacket water circulation is above 3 gpm as sensed

PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT

by the flow switch [FS-CW-15B001E, by others] being not low, the Mill Inlet Damper [CZ-TG-15B002E] is moved to the fully open position.

After the Mill Inlet Damper [CZ-TG-15B002E] is in its fully open position as sensed by position switch [ZSO-TG-15B002E], the Mill Mist Lube System oil level [LS-CH-15B001E] is not low, the Mill Mist Lube System air pressure [PS-1A-15B003E] is not low, the Mill upper/lower bearing temperatures [TE-CH-15B048E/TE-CH-15B049E] are not HI-HI, and the Mill vibration [VT-CH-15B001E] is not HI-HI (there is a thirty (30) second bypass of vibration monitor during the mill start-up), and three (3) minutes have elapsed since the Mill air supply Solenoid Valve [SV-1A-15B040E] was energized, the Mill [PM-CH-15B001E] motor is started.

Seventy-five (75) seconds (to allow the mill to ramp up to speed) after starting the Mill [PM-CH-15B001E] motor, as sensed by motion switch [SS-CH-15B004E] not indicating zero speed, the Mill Classifier Rotary Feeder [RV-CH-15B002E] is started.

After the Mill Classifier Rotary Feeder [RV-CH-15B002E] is started, as sensed by motion switch [SS-CH-15B002E] not indicating zero speed, the automatic airflow control portion of the circuit is placed in its normal operating configuration.

Once the Classifier Outlet Temperature [TE-CH-15B050E] (by others) reaches 150°F, at least one hundred twenty five (125) seconds have elapsed since the starting of the Classifier Rotary Feeder [RV-CH-15B002E] as sensed by the motion switch [SS-CH-15B002E] not indicating zero speed, and the oxygen content of the transport gas as sensed by the customer's oxygen analyzer is below eight percent, the Mill Inlet Rotary Feeder [RV-CH-15B001E] is started.

After the Mill Inlet Rotary Feeder [RV-CH-15B001E] is started, as sensed by motion switch [SS-CH-15B003E] not indicating zero speed, the Coal Feed Screw Conveyor (by others) can be started to introduce material flow to the Coal Milling System.

*Note: the coal feed screw conveyor (by others) should start at a maximum set point of roughly 50% mill maximum capacity.*

**D. Normal Operation of the Coal Milling System**

Once the System has been started in the manner described in section C, normal operation consists of controlling the following:

The air flow rate into the Mill

The material feed rate into the Mill circuit (by others)

The air flow rate into the mill is controlled by the operation of the Mill Air Inlet Damper [CZ-TG-15B002E]. The control loop consists of a flow indicating controller that permits the operator to set a mill inlet air flow rate set point.

In normal operation, the flow rate at full load is set at 3460 ACFM; however, this value will be verified and adjusted during startup testing of the mill, and a table of mill inlet air flow rates will be prepared for use by the operators.

The feed rate of material into the mill circuit is manually adjusted by the operator.

*Note: during startup the maximum mill capacity will be determined, and a table of mill operating points will be established by Fuller.*

**E. Normal Shutdown of The Coal Milling System**

A normal shutdown of the Coal Milling System is a sequenced shutdown of the System, and is either initiated by the system operator, or automatically initiated by one of the following conditions:

Mill Mist Lube System oil level low, as sensed by level switch [LS-CH-15B001E], persisting for a period of 10 minutes or longer

High Mill vibration [VT-CH-15B001E] (in excess of 0.4 in./sec.) which persists for 10 minutes or longer

When normal shutdown is initiated, the shutdown proceeds as described below:

The Coal Feed Screw Conveyor (by others) is stopped to cut-off material flow to the Coal Milling System

Ten seconds after The Coal Feed Screw Conveyor (by others) is stopped, the mill inlet rotary feeder [RV-CH-15B001E], as sensed by motion switch [SS-CH-15B001E] indicating zero speed, is stopped

Once the mill inlet rotary feeder [RV-CH-15B001E] is stopped, as sensed by motion switch [SS-CH-15B001E] indicating zero speed, and after a 10 minute time delay to purge the system, the Classifier Rotary Feeder [RV-CH-15B002E] is stopped

Ten seconds after the Classifier Rotary Feeder [RV-CH-15B002E] is stopped, as sensed by motion switch [SS-CH-15B002E] indicating zero speed, the Mill [PM-CH-15B001E] is stopped

Ten seconds after the mill [PM-CH-15B001E] stop is initiated, the Mill Inlet Damper [CZ-TG-15B002E] is closed

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

After the Mill Inlet Damper [CZ-TG-15B002E] is closed, as sensed by its position switch [ZSC-TG-15B002E], and the mill [PM-CH-15B001E] is stopped, as sensed by motion switch [SS-CH-15B004E] indicating zero speed, the Mill Compressed Air System Valve (to the Mill Mist Lube System) is closed by de-energizing Solenoid Valve [SV-1A-15B040E], the Mill Bearing Housing Water Jacket solenoid [SV-CW-15B003E, by others] is de-energized, and the Mill Lube Mist Demister [TK-CH-15B001] is stopped. **Note: If Mill No. 2 circuit is running, the Mill Lube Mist Demister is left running.**

The de-energizing of Solenoid Valves [SV-1A-15B040E] and [SV-CW-15B003E] completes the normal shutdown of the Coal Milling System.

Note: The Transport Gas Fan, supplying air to the mill systems, may only be stopped during a shutdown of the boiler. When a coal milling system is shutdown and the boiler is operating, the transport gas will by-pass the mill system to provide cooling air to the burners.

**F. Abnormal Shutdowns Of The Coal Milling System**

Abnormal shutdowns are those unplanned shutdowns of the system caused by either isolated process or equipment abnormalities, activation of individual equipment safety devices, or automatic activation of personnel safety systems.

Abnormal shutdowns caused by isolated process or equipment abnormalities or activation of individual safety devices will cause the immediate stopping of the affected piece of equipment and will stop all upstream equipment in a cascade fashion. Equipment downstream of the faulted piece of equipment or point at which the abnormality occurs will continue in normal operation.

- 3 In an abnormal shutdown, the mill circuit **MUST** cool down for a period of one hour prior to the opening of any equipment or ductwork ports, flanges, or (tramp iron) cleanout gates by maintenance personnel. This will prevent injury from high temperatures and reduce the danger of introducing excess oxygen into the system, which could feasibly lead to fires or explosions.

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

If, during normal operation of the Coal Milling System, any of the following systems or equipment is activated, all equipment in the System will be stopped without any intentional time delays to allow for equipment clean out and deceleration:

If at any time the boiler becomes unable to continue to receive Micronized coal through the new burners

Transport Gas Fan not running (by others)

Mill air supply system Low (< 44 psi), as sensed by pressure switch [PS-1A-15B003E]

Tramp iron gate not closed, as sensed by limit switch [ZSC-CH-15B012E].

Mill vibration [VT-CH-15B001E] high-high (0.75 in./sec)

Mill upper bearing temperature HI-HI, as sensed by temperature element [TE-CH-15B048E]

Mill lower bearing temperature HI-HI, as sensed by temperature element [TE-CH-15B049E]

During normal operation of the Coal Milling System, if the Mill [PM-CH-15B001E] Motor stalls, as sensed by motion switch [SS-CH-15B004E] indicating zero speed, the following equipment is stopped in the sequence indicated without any intentional time delays to allow for equipment clean out and deceleration:

Coal Feed Screw Conveyor (by others).

Mill Inlet Rotary Feeder [RV-CH-15B001E]

Classifier Rotary Airlock [RV-CH-15B002E]

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

During normal operation of the Coal Milling System, if the Classifier Rotary Feeder [RV-CH-15B002E] stalls, as sensed by motion switch [SS-CH-15B002E] indicating zero speed, the following equipment is stopped in the sequence indicated without any intentional time delays to allow for equipment clean out and deceleration:

Coal Feed Screw Conveyor (by others)

Mill Inlet Rotary Feeder [RV-CH-15B001E]

During normal operation of the Coal Milling System, if the Mill Inlet Rotary Feeder [RV-CH-15B001E] stalls, as sensed by motion switch [SS-CH-15B001E] indicating zero speed, the following equipment is stopped in the sequence indicated without any intentional time delays to allow for equipment clean out and deceleration:

Coal Feed Screw Conveyor (by others)

During normal operation of the Coal Milling System, if the Mill Inlet Air flow falls below 2425 ACFM or the oxygen content of the transport gas exceeds eight percent (as sensed by the customer's oxygen analyzer), the following equipment is stopped in the sequence indicated without any intentional time delays to allow for equipment clean out and deceleration:

Coal Feed Screw Conveyor (by others)

Mill Inlet Rotary Feeder [RV-CH-15B001E]

*Note: After an abnormal shutdown as detailed in the above case, the mill circuit can be restarted once the airflow returns to its normal operating point and the oxygen content in the Mill falls below 7.5 percent. The coal feed screw conveyor should start at its minimum set point, and the circuit brought back to maximum capacity.*

During normal operation of the Coal Milling System, if the Mill Bearing Housing Water Jacket water circulation is less than 3 gpm as sensed by the flow switch [FS-CW-15B001E, by others]:

**"ALARM ONLY"**

During normal operation of the Coal Milling System, if the classifier outlet temperature (by others) falls below 140°F:

**"ALARM ONLY"**

Note: if the alarm persists, it is recommended that the operator use his discretion whether to "cut-back" or "cut-off" the coal feed.

**G. Emergency Shutdowns Of The Coal Milling System.**

Emergency shutdowns will cause the immediate and simultaneous shutdown of the entire Coal Milling System.

Any emergency shutdowns of the entire Coal Milling System shall be at the discretion of the customer.

- 3 In an emergency shutdown, the mill circuit MUST cool down for a period of one hour prior to the opening of any equipment or ductwork ports, flanges, or (tramp iron) cleanout gates by maintenance personnel. This will prevent injury from high temperatures and reduce the danger of introducing excess oxygen into the system, which could feasibly lead to fires or explosions.

Installation, Operation & Maintenance  
Manual

MF-3018 MicroMill

 FULLER MINERAL PROCESSING, INC.
CERTIFIED FOR CONSTRUCTION
SIGNATURE <u><i>Blair Jantzen</i></u>
DATE: <u>JUL 31 1990</u>

## TABLE OF CONTENTS

1. PRINCIPLES OF OPERATION AND SPECIFICATIONS	Page 1
1.1 GENERAL DESCRIPTION	Page 1
1.1.1 Construction	Page 1
1.1.2 Fuel/Product Micronization	Page 1
1.2 PRINCIPLES OF OPERATION	Page 2
1.3 SPECIFICATIONS FORM SHEET	Page 5
2. INSTALLATION AND COMMISSIONING	Page 6
2.1 SHIPMENT INSPECTION AND VERIFICATION	Page 6
2.2 INSTALLATION OF EQUIPMENT (PHASE 1)	Page 6
2.2.1 Frame Erection and Installation (See Dwg. 1.713916)	Page 6
2.2.2 Installation of Mill Housing Frame, Vibration Isolators and Mill Discharge Transition (See Dwg 1.713916)	Page 6
2.2.3 Installation of Feed System (See Dwg. 1.713916)	Page 8
2.2.4 Installation of Lube Mist Assembly (See Drawing 3.704580)	Page 8
2.2.5 Lube Mist Piping Installation and Lube Mist Set-up	Page 8
2.2.6 Labyrinth Seal Installation and Labyrinth Seal Set-Up	Page 9
2.2.7 Installation and Set-Up of Vibration Transmitter, RTD's, Pressure Switch, and Lube Mist/Labyrinth Seal Solenoids (See Dwg. 3.704580)	Page 10
2.2.7.1 Vibration Transmitter	Page 10
2.2.7.2 PT100 RTD's	Page 10
2.2.7.3 Pressure Switch	Page 10
2.2.7.4 Limit Switches Tramp Iron Gate	Page 11
2.2.7.5 Labyrinth Seal/Lube Mist	Page 11
2.2.7.6 Speed Switches	Page 11

2.2.8	Low-Level Alarm for Lube Mist	Page 11
2.2.9	Regulator Settings and Purge	Page 11
2.2.9.1	Labyrinth Seal Pressure Setting	Page 11
2.2.9.2	Lube Mist Assembly	Page 12
2.2.9.3	Cooling Water Jacket	Page 12
2.2.10	Installation of Motor, Driver/Driven Pulleys, Drive Belts and Belt Guard	Page 13
2.3	SYSTEM CHECK-OUT PRIOR TO INSTALLATION OF BACKPLATE ASSEMBLY	Page 14
2.4	INSTALLATION OF EQUIPMENT (PHASE 2)	Page 15
2.4.1	Backplate Assembly, Rotational Impact Zone (RIZ), Cone and Expansion Bellows	Page 15
2.4.2	Installation of RIZ (Rotational Impact Zone), Cone and Expansion Joint w/Liner	Page 17
2.5	COMPLETE SYSTEM CHECK-OUT	Page 18
3.	OPERATION	Page 19
3.1	INSPECTION OF EQUIPMENT	Page 19
3.1.1	General	Page 19
3.1.2	Feed System	Page 19
3.1.3	MicroMill	Page 19
3.1.4	Bearing Inspection	Page 21
3.1.5	Auxiliaries and Ducting	Page 21
3.1.6	Turbo Blower	Page 22
3.2	START-UP AND INITIAL OPERATION	Page 22
3.2.1	MicroMill	Page 22
3.2.2	Motor	Page 23
3.2.3	Valves and Auxiliaries	Page 23
3.3	PREREQUISITES FOR GOOD OPERATIONS	Page 23
3.3.1	Feed Screw Conveyor	Page 23
3.3.2	MicroMill	Page 24
3.4	OPERATION OF THE MICROMILL WHEN GRINDING COAL/RAW MATERIAL	Page 24
4.	MAINTENANCE AND REPAIRS	Page 26
4.1	GENERAL	Page 26

4.2 REPLACEABLE-BLADE SECTIONS	Page 26
4.3 ROTATIONAL IMPACT ZONE (RIZ) AND MILL CONE LINERS	Page 28
4.4 INSTALLATION OF NEW BEARINGS	Page 28
4.5 REASSEMBLY OF THE BEARING HOUSING	Page 29
4.6 OIL FOR LUBRICATING BEARINGS AND THE LUBEMIST SYSTEM	Page 30
4.7 MAINTENANCE OF FEED SYSTEM AND AUXILIARIES	Page 30
4.8 MICROMILL, CLASSIFIER AND AIRLOCK	Page 31
4.9 ROUTINE MAINTENANCE FOR SCREW FEEDER, MOTOR AND OTHER ANCILLARY EQUIPMENT	Page 31
TABLE I:	Page 7
FIGURE 1:	Page 32
REFERENCE DOCUMENTS:	
A) Micromill Assembly Parts List 5.702628	
B) Micromill Instrumentation, Lubemist, and Air Piping Assembly Parts List 5.701743	
C) Classifier Drawing 429-93-4-2003.	
D) Vendor Manuals	

---

## 1. PRINCIPLES OF OPERATION AND SPECIFICATIONS

---

### 1.1 GENERAL DESCRIPTION

The MicroFuel 30" MicroMill micronizes fuels and products over a wide range of grindabilities and moisture contents. The MicroMill design produces sustained product fineness over long periods of time with minimum power consumptions, good availability, ease of maintenance with minimum expense, and quiet and vibrationless operation. The housing of the MicroMill is constructed entirely of steel. The replaceable blades and sections of the machine subject to extreme abrasion are made of high chrome wear-resistant white iron, ceramics, or wear-resistant alloys. These wearing parts are so designed that replacement, when required, can be conveniently made with a minimum of labor and outage time. The MicroMill has been designed to operate for long periods of time with only minimum attention such as routine inspection of bearings and lubrication systems. The MicroMill does not require any adjustment while in operation.

#### 1.1.1 Construction

The MicroMill housing and major components are fabricated with welded steel and connected by bolted flange connections. The major components are shown on assembly drawings 1.716957 and 1.713916 and listed in Parts List No. 5.702628. The cone and Rotational Impact Zone are connected to the mill housing and equipped with a pivot pin system to allow the cone and Rotational Impact Zone sections to swing out of the way to allow access to the impeller and replaceable blades. Replacement of the blade sections and the complete impeller assembly can be accomplished without removal of the cone and Rotational Impact Zone sections. The steel MicroMill housing, classifier and major wear parts are protected with ceramic wear-resistant material.

#### 1.1.2 Fuel/Product Micronization

The fuel/product is fed into the MicroMill by a feed screw conveyor and is controlled by an input signal from the customer's control center. There is no fuel/product level in the MicroMill, hence there is no fuel/product level control. The feed screw conveyor,

mounted near the MicroMill feed inlet piping, drops the fuel/product into the primary air stream with recycled fuel/product. The fuel/product and primary air enter the MicroMill cone where surface moisture is evaporated. As they enter the cone section, they begin to swirl in a cyclonic motion caused by the rotation of the impeller. The fuel/product is held to the edge of the cone by centrifugal force. As the air and fuel/product proceed up in the cone, the area increases and the upward velocity decreases until the particles form bands of comparable mass. The smaller, higher-velocity particles passing through these bands collide with larger particles, breaking them up. Thus, particle-to-particle attrition.

This action continues until the particle is small enough to be drawn from the cone/Rotational Impact Zone through the impeller and discharged to the classifier. Here the oversized particles are rejected and returned to the MicroMill feed system upstream of the raw fuel/product feed through an airlock. The fine fuel/product is discharged directly to the burner system or collection device. The hot primary air, recycle fuel/product, and raw fuel/product are violently mixed and attrited in the cone section promoting additional drying of the fuel/product. The primary air temperature is increased as the fuel/product moisture increases to remove additional moisture from the fuel/product.

## 1.2 PRINCIPLES OF OPERATION

The MicroMill System is a patented centrifugal-pneumatic pulverizer which reduces the particle size by particle-to-particle attrition. The heart of the MicroMill System is shown on drawing 1.716957. The major components are:

- Inlet cone (Part No. 01.01.01.19)
- Rotational Impact Zone (Part No. 01.01.01.11)
- Impeller with replaceable blades  
(Part No. 01.01.01.03)
- Ceramic-line scroll (Part No. 01.01.01.07)

The MicroMill is an air-swept mill and the fuel/product to be micronized is conveyed pneumatically into the transition section just below the cone inlet flange. There is only one moving part, the rotating impeller, in the primary micronizing area. This rotating impeller creates air waves in a tornado-like column of air inside the cone and MicroMill Rotational

Impact Zone. As the fuel/product particles are fed into the lower portion of the cone, centrifugal force pushes them to the outside of the cone and they are picked up in the swirling air flow. As the fuel/product particles move up in the cone, the velocity decreases as the cone area increases and eventually the particles reach a point where their mass will not allow them to move further up in the cone. They form bands of like material in the cone. Smaller, higher-velocity particles traveling up through the cone pass through those bands and impact with the larger, slower-moving particles. These impacts cause fracturing and micronizing of the particles.

As the fuel/product moves up the cone into the Rotational Impact Zone (RIZ) area, the bands of particles become more dense and finer. When the particles are small enough to be pulled out of the centrifugal bands by the air motion, they are passed through the impeller and replaceable blades and are discharged to the horizontal centrifugal classifier.

The function of the classifier is to separate oversize particles and return them to the mill feed system where they are recycled for re-micronization. The particles that are acceptable pass through the outlet orifices of the classifier and are discharged either directly to the burner process or a collection system.

The major wear areas in the MicroMill System are the upper cone, the RIZ, the replaceable-blade sections, and the mill housing scroll area. These wear areas are designed to minimize wear and utilize the materials as detailed in the Micromill Assembly Parts List No. 5.702628.

Conveying air for the MicroMill System is provided by a primary air fan. Depending on the application, it may be necessary to preheat the air to get drying of the fuel/product. The primary air fan can be designed with the preheated air before the fan or if it is a stand-alone installation, with the preheater after the fan.

The main mill drive system for the MF-3018 is provided by an electric motor driving the MicroMill impeller through a belt and sheave arrangement. The electric motor drive system is controlled during start-up by the control center (PLC).

If provided by Fuller Mineral Processing Inc., the controls and electrical equipment for the MicroMill System are incorporated in a pre-wired stand-alone control cabinet. The electric power requirements for the MF-3018 MicroMill would normally be 480 volts, 3 phase, 60 cycles. The mill can be

designed to accommodate 380 or 660 Volt, 3 Phase, 50 cycle power. The control of the MicroMill System, when provided by Fuller Mineral Processing Inc., is accomplished by the use of a programmable controller. The programmable controller monitors all critical mill operating parameters and permissive requirements and also interfaces with the customer's control system. The programmable controller is capable of being modified to accommodate various control systems or changes in control systems, should the operating mode change after the unit is placed in service.

The impeller, the only major rotating component in the MicroMill, is supported by a bearing system which consists of a bearing housing and three anti-friction bearings. Lubrication for these bearings is provided by an oil mist system which is considered to be the best bearing lubrication system for anti-friction bearings. The bearing housing is also equipped with a vibration detector which is monitored by the programmable controller control system and shuts the unit down automatically should the vibration exceed the allowable limits. Please refer to Parts List No. 5.701684 for the bearing housing assembly.

The entire MicroMill System is mounted in a modular box steel frame which contains the MicroMill and feed system components. The MicroMill System support frame transfers its load to the structure it is mounted on through a series of base plates. The foundation requirements for the MicroMill System are minimal and normally require only a 6" to 10" (150mm to 250mm) concrete slab for mounting.

Maintenance is accomplished on the MicroMill System by removing the expansion joint below the cone section and the bolts which attach the Rotational Impact Zone (RIZ) to the scroll. The RIZ/Cone section can then be lowered, and swung out of the way, by loosening the large nut on the pivot point. This will allow access to the mill's internal components.

Additional detail and specific operating and maintenance instructions are contained in the body of this manual and should be consulted with installing, operating, or maintaining the unit. The material in this manual is meant to give the operator general operating instructions and is not intended to override the purchaser's own operating and safety procedures.

Safe operation of the MicroMill System is the responsibility of the operator and the MicroMill should never be operated for any purpose other than the purpose for which it was designed; and the MicroMill should never process any material other than the material for which it was designed.

1.3 SPECIFICATIONS FORM SHEET

SYSTEM SPECIFICATIONS

July 25, 1996

Customer:	Eastman Kodak
Contract No.:	96-11028-745
Location:	Rochester, NY
Model No.:	MF-3018-1P
Material Processed:	3/4 by 0 Coal
MicroMill Data:	Size 30" - 18 blades
RPM:	2860
Drive:	Belt
Replaceable Blade:	Radial
Drive Motor:	200 HP, 480 V/3 phase/60 Hz
Bearing Data Type:	Anti-friction ball
Lubrication:	Oil mist
Shaft Seal:	Labyrinth pressurized air
Vibration Detector:	Balmac mounted on bearing housing
Bearing Temperature detectors:	Top and bottom bearings PT100 RTD's
Wear Parts, Replaceable Blades:	Radial with hardfacing
Wear Parts, Cone Liners:	High chrome white iron
Wear Parts, RIZ Liners:	High chrome white iron, 18" opening
Classifier:	Per Drawing 429-93-4-2003 Sht 1 and 2
Air Preheater:	N/A
Feed Piping:	10" Sch 40 with flanged connections
Air Piping:	N/A
Controls:	N/A

---

## 2. INSTALLATION AND COMMISSIONING

---

### 2.1 SHIPMENT INSPECTION AND VERIFICATION

Upon receipt of shipment of a MicroFuel MF-3018 MicroMill, a visual inspection of the components should be made. The carrier should be notified of any parts that were damaged. During this inspection, the equipment shipped should be verified against the assembly parts list (5.702628). Any discrepancies should be brought to the attention of Fuller Mineral Processing Inc. immediately.

NOTE: IT IS THE RESPONSIBILITY OF THE CONTRACTOR TO FOLLOW PROPER SAFETY PROCEDURES FOR ALL LIFTING AND MOVING OF EQUIPMENT DURING INSTALLATION!

### 2.2 INSTALLATION OF EQUIPMENT (PHASE 1)

#### 2.2.1 Frame Erection and Installation (See Dwg. 1.713916)

The frame should be bolted to an appropriate footing which is level to one-eighth inch in ten feet (1/8"/10' = 3.2mm/3048mm). The anchor bolts for the frame are M16 Hilti HVA adhesive anchors w/ 125 mm embedment or approved equal. After placing the base frame/mid frame (01.01.02.21 on dwg. 1.713916) on the footing, check the frame to insure it is level and square.

The mid frames, which are already installed on the base frame using hardware supplied by Fuller Mineral Processing Inc. (5/8" diameter hex bolts), must be squared on the foot pads and should be checked. Check the tightness of the bolts against the torque value listed in Table I.

#### 2.2.2 Installation of Mill Housing Frame, Vibration Isolators and Mill Discharge Transition (See Dwg. 1.713916)

Install the mill discharge transition (01.01.02.18) and gasket (01.01.02.19) with the hardware on the drawing listed above. Torque the bolts to the value indicated in Table I.

Using the lifting eyes on the mill housing frame, by suitable means lift it and the upper mill frame and

**TABLE 1: TORQUES TO PRODUCE RECOMMENDED LOADS  
CAP SCREWS**

SIZE INCH	BASIC DIAMETER	STRESS AREA	TENSILE STRENGTH (T) MIN. PROOF STRESS (P) P.S.L. SAE GRADE			CLAMP LOAD (LBS.)	S.A.E. GRADE 2 ASSEMBLY TORQUE	
			2	5	8		DRY	LUB.
			T/P	T/P	T/P		R=.200	R=.150
	.1120	.00604	69M/55M	120M/85M	150M/120M	240	5	4
	.1120	.00661	-	-	-	280	6	5
	.1250	.00776	-	-	-	330	8	6
	.1250	.00820	-	-	-	342	9	7
	.1380	.00909	-	-	-	380	10	8
	.1380	.01015	-	-	-	420	12	9
	.1640	.01400	-	-	-	580	19	14
	.1640	.01474	-	-	-	600	20	15
	.1900	.01750	-	-	-	720	27	21
	.1900	.02000	-	-	-	820	31	23
1/4 -20	.2500	.0318	-	-	-	1320	66	49
1/4 -28	.2500	.0364	-	-	-	1500	76	56
5/16 -18	.3125	.0524	-	-	-	2160	11	8
5/16 -24	.3125	.0580	-	-	-	2400	12	9
3/8 -16	.3750	.0775	-	-	-	3200	20	15
3/8 -24	.3750	.0878	-	-	-	3620	23	17
7/16 -14	.4375	.1063	-	-	-	4380	30	24
7/16 -20	.4375	.1187	-	-	-	4900	35	25
1/2 -13	.5000	.1419	-	-	-	5840	50	35
1/2 -20	.5000	.1599	-	-	-	6600	55	40
9/16 -12	.5625	.1820	64M/52M	-	-	7100	65	50
9/16 -18	.5625	.2030	-	-	-	7900	75	55
5/8 -11	.6250	.2260	-	-	-	8800	90	70
5/8 -18	.6250	.2560	-	-	-	10000	100	80
3/4 -10	.7500	.3340	-	-	-	13000	160	120
3/4 -16	.7500	.3730	-	-	-	14550	180	140
7/8 -9	.8750	.4620	55M/28M	115M/78M	-	9700	140	110
7/8 -14	.8750	.5090	-	-	-	10700	155	120
1-8	1.0000	.6060	-	-	-	12700	220	160
1-12	1.0000	.6630	-	-	-	13900	240	170
1-1/8 -7	1.1250	.7630	-	105M/74M	-	16000	300	220
1-1/8 -12	1.1250	.8560	-	-	-	18000	340	260
1-1/4 -7	1.2500	.9690	-	-	-	20350	420	320
1-1/4 -12	1.2500	1.0730	-	-	-	22550	460	360
1-3/8 -6	1.3750	1.1550	-	-	-	24300	560	420
1-3/8 -12	1.3750	1.3150	-	-	-	27500	640	460
1-1/2 -5	1.5000	1.4050	-	-	-	29800	740	560
1-1/2 -12	1.5000	1.5800	-	-	-	33200	840	620

NOTE: 1 INCH = 25.4 mm  
1 FT-LBS = 1.356 N-m  
1 in-LBS = .113 N-m

place it over the mill mid frames. Using the hardware indicated on drawing 1.713916, bolt the upper mill frame to the mid frames, making sure the holes in the frame pads line up. Torque these bolts to the value indicated in Table I. The mill housing frame is bolted to the upper frame with shipping bolts; remove these bolts and discard them. Lift the mill housing frame off the upper mill frame and position the vibration isolators (01.01.04.23 on dwg. 1.713916) onto the mill frame and bolt in place with the hardware indicated by the drawing, but do not tighten the bolts.

Lift and reposition the mill housing frame and align the holes in the frame with the holes in the vibration isolators. Using the hardware indicated in the drawing, bolt the mill housing frame to the isolators. Verify that the mill housing frame is installed correctly on the isolators and tighten all the hardware.

**BE CAREFUL NOT TO OVERTIGHTEN THIS HARDWARE.**

#### 2.2.3 Installation of Feed System (See Dwg. 1.713916 and 1.725690)

Install the feed piping according to the drawings listed above. After the pipe support (01.01.04.01) is installed, make sure the assembly is level and square.

Bolt the tramp iron valve (01.01.05.21) and 8" (200 mm) weld neck (01.01.05.20) to the feed pipe system noting the orientation of the tramp iron valve. Torque all hardware to the values listed in Table I.

#### 2.2.4 Installation of Lube Mist Assembly (See Parts List 5.701743)

Locate on the left side of the mill frame (as viewed from the front or side opposite the motor) four 3/8" diameter tapped holes. Using the bolts, flat and lock washers noted in drawing 3.704581, mount the lube mist assembly (01.01.01.09) to the frame.

#### 2.2.5 Lube Mist Piping Installation and Lube Mist Set-Up

Locate in the shipping container the various piping segments and notice that each one has a label making reference to its description. Refer to Drawing 3.704581 and note the position and orientation of each pipe segment. All piping has been manufactured so that each segment is in its appropriate location on the mill

frame according to Drawing 3.704580 and 3.704581.

When testing for leaks, in the unlikely event that a leak is found, break the connection in question and use Teflon tape to wrap the male threaded end and reconnect.

Insure that the piping is secured to the supports that are located in various areas on the mill frame. When installing the lube mist piping, the horizontal run of  $\frac{1}{2}$ " pipe MUST slope down towards the lube mist assembly to prevent oil from accumulating in the pipe (See Lubemist manual for specific instructions). Locate and install the two (2) hydraulic hoses (item 01.01.02.07 in Parts List 5.701743) from the tee to the bearing housing.

Refer to the Lube Mist manual and fill the lube mist assembly with the oil provided (01.01.02.20 on Parts List 5.701743) and replace the fill cap on the lube mist unit.

#### 2.2.6 Labyrinth Seal Installation and Labyrinth Seal Set-Up

The labyrinth seal (01.01.02.05 on dwg 1.716957) consists of two parts: the stationary member and the rotating member. The rotating member consists of a steel sleeve with six (6) Allen set screws. Using a light oil (10W) lightly coat the bearing shaft, verify the O-ring is installed properly into the bore of the sleeve and slide it onto the shaft with the set screws located to the top. Slide the sleeve up the shaft until the sleeve top is approximately  $\frac{1}{8}$ " (3 mm) below the oilseal in the bottom of the bearing housing. Lightly tighten the first Allen set screw, then tighten the Allen set screw that is directly opposite of the first one. Move sixty (60) degrees clockwise and do the same as above; then tighten the last pair. Go around the six (6) set screws and "SNUG" them down (approximately  $\frac{1}{8}$  turn from contact to shaft). **DO NOT OVER TIGHTEN!**

The stationary member comes with six  $\frac{1}{4}$ -20 Allen bolts and is installed with the flat face-down position, making sure the O-ring is seated in its groove. Slide the stationary member onto the shaft; and when the bronze ring inside the diameter comes near the sleeve, make sure the stationary member is parallel to the bored hole and the bronze ring is centered on the sleeve. Push the stationary member up until it is

seated in the counter bored hole. DO NOT FORCE THE STATIONARY MEMBER ONTO THE SLEEVE!

If it starts hard, re-position and it will slide on easily. Tighten the Allen bolts as was done for the sleeve, but do NOT overtighten.

## 2.2.7 Installation and Set-Up of Vibration Transmitter, RTD's, Pressure Switch, and Lube Mist/Labyrinth Seal Solenoids.

### 2.2.7.1 Vibration Transmitter

The vibration transmitter (01.01.02.14 on Parts List 5.701743) is installed on a 1/2" National Pipe Thread (NPT) coupling welded to the bearing housing and located near the bottom of the housing. Screw the monitor in hand tight and then 1/4 turn more (See drawing 3.704581). This transmitter should be attached to a 30 Volts Direct Current (VDC) Maximum (MAX) linear regulated or unregulated power supply and MUST be wired as shown in the diagram (drawing 3.704581).

### 2.2.7.2 PT100 RTD's

Two PT100 RTD's mount on the bearing housing to monitor the bearing temperatures. On drawing 2.708145 and 3.704580, locate the two 1/8" National Pipe Thread (NPT) female-tapped holes on the bearing housing. The RTD's are inserted into these holes. When the tip of the RTD bottoms out on the bearing, thread the male fitting into the bearing housing and tighten being careful NOT to over tighten it. Do the same for the other RTD, then tighten the nuts down onto the adapters. These nuts do not need to be excessively tight, but just tight enough to hold the RTD in place.

### 2.2.7.3 Pressure Switch

The pressure switch has been factory set and does not need to be adjusted.

#### **2.2.7.4 Limit Switches, Tramp Iron Butterfly Gate**

These switches have been set at the factory and should not need further adjustment.

#### **2.2.7.5 Labyrinth Seal/Lube Mist Solenoids**

These solenoids are installed at the factory and no further work is needed in this area. The coils for the solenoids are 120 VAC.

#### **2.2.7.6 Speed Switch**

The mill is equipped with a speed switch mounted on the mill shaft. This switch will indicate that the mill shaft is rotating. If for some reason there is a failure in the mill drive system the operator will be notified that there is a problem. Please refer to item 01.01.02.18 on Parts List 5.701743.

#### **2.2.8 Low-Level Alarm for Lube Mist**

The lube mist assembly has a low level alarm to indicate when the reservoir needs to be refilled. If the operator does not shut the system down within ten minutes after the alarm, an automatic sequenced stop will occur. At the sound of the alarm, approximately two (2) hours of lubricant remains. The wiring diagram is shown in the Lube Mist System manual and must be wired into the circuit to indicate a warning to the operator. The addition of oil to the lube mist system can be done when the MicroMill System is operating. Please use the hand pump detail in the Lube Mist manual.

#### **2.2.9 Regulator Settings and Purge**

Turn on the system air and energize the solenoid(s). Check the pressure on the plant air source supplying air to the Lube Mist and verify there is at least 80 pounds per square inch gauge (psig) (550 kPag). Check the rest of the piping for any air leaks and correct all problems as necessary. The following is a component check-out procedure:

##### **2.2.9.1 Labyrinth Seal Pressure Setting**

Refer to item 01.01.01.16 on Parts List 5.701743 and adjust the pressure regulator until the gauge reads 7 psig (50 kPag). Using

the locknut, tighten it so the setting of 7 psig (50 kPag) cannot be changed.

#### 2.2.9.2 Lube Mist Assembly

With a pressure gauge that reads 0-30 inches of water (minimum) (7.5 kPag), remove the plug and attach the gauge as shown in drawing 3.704581. Adjust the lube mist pressure regulator to achieve a pressure reading on the gauge of 20 inches of water (5 kPag).

Remove the pressure gauge and replace the plug that was removed earlier. Using the locking ring on the regulator, push in and "snap" it into the locked position. If there is a cloudy discharge, the lube mist unit is working properly. If not, refer to the "MAINTENANCE" section of this manual under "LUBE MIST SYSTEM".

#### 2.2.9.3 Bearing Housing Cooling Jacket (if supplied)

Located at the base of the bearing housing are two ½" NPT couplings, which are for a water line to remove excess heat from the bearing housing (see dwg 2.708145). One coupling is marked "IN" and the other "OUT". The cooling jacket should be piped to a suitable source of clean, cool (85 °F) water with a means to remove excess heat from the water (i.e., heat exchanger) if the water is to be re-used.

On the discharge ("OUT") of the bearing housing water jacket, the following equipment should be installed in the order specified; a) flow switch, b) manual throttling valve, c) on/off solenoid valve (refer to P&ID for additional information). The flow switch will indicate that cooling water is indeed flowing through the cooling jacket. The throttling valve will be used to regulate the flow through the housing. The on/off valve will be utilized to start water flow during the mill start-up procedure. On the inlet ("IN"), a manual shut-off valve should be installed.

The water requirements for the cooling jacket are as follows; 10 GPM @ 85 °F with a maximum allowable pressure of 20 PSIG.

Operation: The bearing housing cooling jacket is equipped with two (2) bleed air fittings. First, turn the water source on with the on/off valve and throttling valve closed. Open the bleed air fittings to allow air to escape from the cooling jacket. When water begins to exit from both bleed air fittings, close them. Next open the on/off valve. Now establish cooling water flow by opening the throttling valve. The mill bearing temperatures should be, under normal operating conditions, between 170°F-190°F. The throttling valve should be manually adjusted, during commissioning, to keep the bearing temperatures in this range under normal operating conditions. After the throttling valve location is set, normal operation of the water jacket consists of opening and closing the on/off valve during mill start-up and shutdown. Water will always be inside the cooling jacket to prevent rust.

#### 2.2.10 Installation of Motor, Driver/Driven Pulleys, Drive Belts and Belt Guard

**WARNING: MAKE SURE THE POWER HAS BEEN DISCONNECTED BEFORE PROCEEDING!**  
**THE MOTOR MUST BE WIRED TO ALL APPLICABLE CODES!**

Remove the belt guard (01.01.03.11 and 01.01.03.12 on drawing 1.713916) from the supports on top of the mill housing frame. Make sure that the motor mount plate is moved to the left-most position as viewed from the mill housing frame looking at the motor mount. If it is not, turn the adjusting bolts evenly clockwise. Lift the motor into place in the mill housing frame; and using the hardware provided on the motor mount, bolt the motor in place with the shaft up. Lightly tighten the motor hold-down bolts to insure that it is positioned snugly against the mounting plate; BUT before snugging down the bolts, make certain the motor shaft is parallel to the bearing housing shaft.

Install the lower belt guard (01.01.03.11). Then locate the driver sheave/bushing (approximately diameter 15", 381mm) and square stock key and install this on the motor, but do NOT tighten the bolts. Locate and install the driven sheave/pulley/keystock (approximate diameter 8", 203mm) on the bearing housing, but once again, do NOT tighten the bolts. Position the driven sheave so that there is approximately 3/8" (9.5mm) gap between the bottom of the sheave and the top of the bearing housing cap and tighten the bolts. Using a level, lay it across the top of the sheaves and move the driver sheave

until they are level. Make sure that the shafts protrude slightly above the bore of the sheaves and torque the bolts on both the driver/driven sheaves to the values listed in the sheave section of the manual.

Slightly loosen the motor hold-down bolts and install the drive belt(s) onto the sheaves. Turn the adjuster bolts counterclockwise to tighten the belts making sure they are evenly adjusted. Using the adjuster bolts, tighten the belts so that they deflect approximately 1/4" (6.4mm) while being pushed in hard by hand at the mid-point of the span. Measure the top and bottom distance between motor foot and mounting plate edge and make sure this distance is equal. With a level, verify that the sheave alignment with the motor is still parallel to the bearing housing. Tighten the motor hold-down bolts to the recommended value in Table I. Reinstall the top belt guard.

Wire the motor to the manufacturer's information and according to all applicable codes.

### 2.3 SYSTEM CHECK-OUT PRIOR TO INSTALLATION OF BACKPLATE ASSEMBLY

Before installation of the backplate, the bearing housing should be run to insure that the MF-3018 MicroMill is in the proper operating condition. If the motor has not been wired at this time, do so. Go through the following checklist before running the bearing housing:

- 1) Is the motor rotating clockwise looking at the drive sheave?
- 2) Is the air supply on? Does the supply air pressure gauge indicate a minimum of 80 psig (560 kPag)?
- 3) Is the lube mist assembly full of oil? Do all the pressure gauges indicate the correct pressures?
- 4) Is the vibration transmitter operating?
- 5) Are the bearing RTD's reading the ambient temperature?
- 6) Are the drive belts tight? Is the belt guard cover bolted down tightly?
- 7) Is the speed switch working?
- 8) Is the water cooling jacket fully operational?
- 9) Walk around the equipment and visually inspect the entire mill, does everything look satisfactory? If there is any question about starting the mill, get an answer first. Turn the mill on and run it for fifteen (15) minutes. During this time monitor the bearing temperature and vibration. If the temperature climbs more than 20°F (11°C) above the starting temperatures or the vibration exceeds 20% of the full scale, there is a problem that needs to be fixed before proceeding.

## 2.4 INSTALLATION OF EQUIPMENT (PHASE 2)

### 2.4.1 Backplate Assembly, Rotational Impact Zone (RIZ), Cone and Expansion Bellows

**WARNING: MAKE SURE THE POWER DISCONNECT IS LOCKED OUT FOR THE MILL MOTOR BEFORE PROCEEDING!!!**

The installation of the backplate assembly is very critical in that it can be detrimental to mill operation if this procedure is not adhered to. The necessary equipment to install the backplate is:

- 1) Torque wrench, 0-150 ft-lb (0-202 N-m)
- 2) Dial indicator with magnetic base, +/- .100" and .001 increments (+/-2.5mm @ .025mm increments).
- 3) 10 mm Allen socket.
- 4) Impeller supports with hardware, quantity 3, supplied by Fuller Power Corporation.
- 5) Vernier calipers.
- 6) Adjusting Shims (Dwg. 4.701942)
- 7) Other "usual" tools.

Remove the twelve (12) ½" bolts on the top, RIZ flange (01.01.02.01 on dwg 1.716957) and loosen the 2" hex nut on the pivot pin. As you loosen this hex nut, the RIZ will lower; and when it clears the mill casing, swing it counterclockwise (viewed from top) until it almost strikes the mill motor. On top of the mill housing locate the two square access openings. Remove the covers and put them aside. These two openings will be used to hoist the impeller assembly into and out of position with the aid of the overhead crane. Two Eye-Bolts will be screwed into the back of the mill backplate. Cables can then pass through the access openings on the mill housing and attach to the impeller assembly. The entire assembly can then be lifted into position. In addition, the spacer shims (dwg. 4.701942) supplied by Fuller Mineral Processing Inc., will be positioned through these openings.

Locate the impeller assembly (01.01.01.03 on dwg 1.716957), Ringfeder (01.01.02.09) and impeller supports. With a clean rag dipped in solvent, wipe off the shaft and make sure there is no oil or dirt on it. Make sure when the backplate assembly is being positioned for installation (with blades facing down), that blocks of wood are placed between the blades and carrying device to prevent damage to the blades. NOTE: The replaceable blade sections, RIZ liners and upper cone liners are made of high chrome, white iron, wear-resistant material. This material

is brittle and subject to mechanical failure should the sections be dropped or impacted with heavy objects. Carefully raise the impeller up into the mill housing, centering the shaft in the bored hole of the impeller. As the impeller is lifted into the mill casing, two things must be done. First, place the spacer shims (dwg 4.701942) through the access openings on top of the mill housing. Second, locate the shims between the backplate and the underside of the mill housing. The shims will ensure that a 0.25" (6.35mm) gap exists.

Continue raising the impeller until the top side of the impeller makes contact with the shims. Install the impeller supports with the included hardware and place blocks of wood between the impeller and supports in the unlikely event that the impeller would slip off the shaft. The Ringfeder should be wiped clean with a clean rag with solvent, and the surfaces indicated on Figure 1 should be lightly oiled (10W). Make sure the Ringfeder is assembled properly (Figure 1) and the Allen bolts (only) are lightly coated with anti-seize compound (moly-coat). Verify the Allen bolts are in the correct holes (non-threaded holes) for tightening the Ringfeder to shaft. The Allen bolts should have their threads just started and two (2) opposing bolts removed from the tightening holes (threaded holes) and put into loosening holes and screwed completely in. This will cause the Ringfeder to expand and ease installation of it. Slide the Ringfeder onto the shaft and into the counter-bored hole on the backplate. If the Ringfeder will not start into the counter-bored hole, remove it and re-center the impeller. The Ringfeder is in the correct position when it bottoms out against the impeller assembly. While holding the Ringfeder up and bottomed out (tap lightly to make sure), start tightening the Allen bolts in cross pattern until all the bolts are tight. Remove the two (2) bolts that were in the loosen holes and put them back in the non-threaded hole and tighten. **DO NOT OVER TIGHTEN THESE BOLTS, MAKE SURE THEY ARE TIGHT ENOUGH SO THE IMPELLER WILL STAY IN PLACE (=75 FT-LBS=100N-m).**

Remove the shims and disconnect the cables used in raising the impeller. Remove the Eye-bolts.

Using the access openings on the top of the mill set up the dial indicator. The indicator tip should be positioned as close to the outside edge of impeller as possible. Adjust the indicator so it is set at the midpoint of its range and "zero" the pointer. Slowly rotate the impeller clockwise, as viewed from the top, and watch for the maximum and minimum movement of the indicator. The backplate **MUST** be level to within .002" (.05mm) TIR (Total Indicator Readout). Rotate the backplate until the indicator reads its **MAXIMUM, HIGHEST** reading. **TIGHTEN** three or four Allen bolts closest to the position of the dial indicator.

Re-zero the indicator, and spin the impeller again. Pick the "high" again and do as stated above. If the bolt torque is approaching 120 ft-lb (90N-m), you must rotate the impeller so the indicator reads the **MAXIMUM, LOWEST** reading.

Closest to the dial indicator, loosen two Allen bolts and remove one and thread it into the hole next to the one you just removed the bolt from. Slowly tighten the bolt while watching the indicator and when the indicator has moved half the previous amount shown on the dial indicator, STOP. Remove the bolt from the "loosen" hole and put it back into its original position. Tighten these moderately so that the backplate cannot move from this position. Re-zero the indicator and spin the impeller. When the total indicator movement is not more than .055" (.13mm) TIR, re-zero and pick the high indicator reading. Begin with the Allen bolts nearest the dial indicator and torque them to 120 ft-lb (90N-m). Torque the next pair of Allen bolts to 120 ft-lb (90N-m) that are closest to the previous pair. Continue using this torquing sequence until you finish the last pair of Allen bolts that are directly opposite the dial indicator. Re-zero the indicator and check to make sure that the TIR is .002" (.05mm) MAX> When this has been verified, install the cover cap (01.01.02.11) making sure the o-ring (01.01.02.12) is seated in its groove. Put two drops of Loc-tite 242 (or comparable product) on this bolt and torque it to 30 ft-lb (22N-m). Remove the impeller supports and reinstall the access openings and gaskets.

#### 2.4.2 INSTALLATION OF RIZ (ROTATIONAL IMPACT ZONE), CONE AND EXPANSION JOINT W/LINER

Verify the installation of the O-ring (01.01.01.12) into the groove, which is on top of the RIZ flange, and wipe a light coat of grease on the mating flange to insure that the O-ring seals effectively. Rotate the RIZ on the pivot pin until the RIZ is aligned and concentric with the opening in the mill casing. Slowly tighten the 2" hex nut which will raise the RIZ, and keeping the RIZ liner centered in the mill casing until the flanges come close to meeting. Reinstall the bolt hardware for the RIZ and tighten to the torque values in Table I.

Rotate the impeller by hand and verify there are no interference problems. If there is interference, it must be corrected. Install the RIZ/cone O-ring (01.01.01.12) into the groove located at the top of the cone flange and lightly grease its mating flange. Lift the cone into place. Align the flanges to each other and align the bolt holes and install the hardware as listed in drawing 1.716957 and torque per the values listed in Table I.

Installation of the expansion joint w/liner is to be done according to Drawing 1.713916 with the hardware noted and locating the three (3) 10" (254mm) flange gaskets (Detail "H" dwg 1.716957) as shown. Tighten the bolts to the torque specified in Table I. If the flanges are not parallel, adjust the upper pipe support adjusting bolt to help align the flanges.

## 2.5 COMPLETE SYSTEM CHECK-OUT

After successful completion of the checklist on page 13, items 1 through 9, turn the MicroMill on manually and allow ambient air to flow through the system. Make sure any flow control valves are open to allow air flow. During the ramp-up to full speed, closely monitor the vibration so that if the MicroMill exceeds 40% of full scale of the vibration transmitter, the MicroMill can be shut down. If a problem is detected, it must be fixed. If no problems are encountered during start-up, run the MicroMill for one (1) hour and monitor the vibration, bearing temperature and motor amps. The vibration should not fluctuate more than 10% and the bearing temperature should rise slowly. During this time, the motor amps should be stable and energy consumption should be approximately 40 kilowatts. By the end of an hour, the bearing temperature should not exceed 170°F (75°C) and vibration should be no more than 30% of full scale of the vibration transmitter.

---

## 3. OPERATION

---

### 3.1 INSPECTION OF EQUIPMENT

#### 3.1.1 General

Initial inspection of the MicroMill should be made by the purchaser's operating and maintenance people together with a Fuller Mineral Processing Inc. representative before placing the equipment into service. This inspection and the accompanying illustrations and descriptions will be of assistance in understanding the construction, operation and maintenance of the MicroMill.

#### 3.1.2 Feed System

All access doors and panels should be removed from the feed screw and inspected for foreign material, if this has not been done already. The inspection openings and clean-out doors should be reinstalled and made secure. All flange connections to the MicroMill Feed System and the customer's bunker or hopper should be checked to insure that they are secure and gasketed. The drive unit should be checked to insure that there is proper lubrication and that the drive guard cover is in place. The screw feed should then be jogged to insure that it is wired properly and rotating in the proper direction. Once this is established, it should be operated for several minutes to insure that the screw is free and functioning properly. At this time, verify the feed screw speed switch is operating correctly and the screw calibrated for the proper feed rate.

The bunker of driven end of the main feed screw should be inspected to insure that it is connected to the customer's bunker or hopper properly and that there are no forces being introduced to the feed screw system from the customer's bunker hopper, or other material handling equipment.

#### 3.1.3 MicroMill

The MicroMill should be inspected to insure that it is assembled properly and ALL fasteners are secure and in place. The drive motor/sheave should also be inspected to insure that it is secured properly and lined up

properly with the sheave on the MicroMill bearing housing. The drive belt(s) should be checked for alignment and tightness (See Section 2.2.10). With the belt guard in place, check the operation of speed switch for the motor/bearing housing system. The system should be checked to insure that the seal air piping, the lube oil system air piping, the lube mist system piping, and cooling water jacket piping are piped and operable. The bearing housing should also be inspected to insure that the vibration detector and bearing RTD's are installed properly and operate correctly. Once this inspection is complete, the Rotational Impact Zone (RIZ) and cone section should be unbolted at the mill casing and swung out of the way to inspect the impeller and mill housing internals.

**CAUTION:** Do not work on the MicroMill until the drive motor power circuit has been disconnected and tagged out.

DO NOT WORK UNDER THE IMPELLER SECTION UNTIL IT IS SAFETY BLOCKED BY ATTACHING THE IMPELLER SUPPORTS TO THE RIZ BOLT HOLES TO CONTAIN THE IMPELLER, SHOULD IT SLIP DOWN.

DO NOT RUN THE MICROMILL WITH THE RIZ AND CONE SECTION REMOVED.

Inspect the mill housing internals to insure that all ceramics are secure and in place and that the impeller and replaceable blades rotate freely by hand. Check to insure that the impeller backplate is aligned properly. (See Section 2.4.1)

Turn on the air to the labyrinth seal system to verify that air is flowing freely and the pressure regulator indicates 7 psig (48.3 kPag). Once the alignments and internal checks are complete, verify the RIZ liners are secured, then the RIZ/cone assembly should be swung back in place, the O-ring installed, and the RIZ bolted securely to the mill housing. The cone should then be dropped by removing the bolts that attach it to the RIZ section and the flange inspected to insure that the O-ring is in place. Also inspect the cone liners and attaching bolts to insure they are not loose or missing. The cone should then be reinstalled and secured. The flexible expansion joint between the feed pipe outlet and the cone inlet should be inspected to insure that all shipping brackets are free and the joint is attached and gasketed properly.

Next, open the access doors on the classifier and inspect

the classifier and airlock to insure that they are free of debris and construction material. Once this is assured, the gaskets should be checked and in place and the doors tightened securely. The classifier discharge airlock should be inspected to insure the drive and drive system is connected properly and adequately lubricated. Once this is accomplished, the airlock should be jogged manually to see that it rotates freely and is rotating in the proper direction. Once this is established, the airlock should be operated manually for several minutes to insure that it is going to function properly. At this time, verify the airlock speed switch is operating correctly.

#### **3.1.4 Bearing Inspection**

Great care is exercised in handling and assembling the MicroMill bearings and bearing system at the Fuller Mineral Processing Inc. plant. All MicroMill bearing systems are preassembled before field shipment. They are at this time lubricated with a residual oil to prevent internal rusting and damage of the bearings during shipment and erection. There should be no need to disassemble the bearing housing and inspect the bearings unless there has been damage to the bearing system during erection such as dropping, storing in an unprotected area, flooding, and so forth. The installation of the oil lubrication mist system should be inspected to insure that it is installed properly. that sufficient air is connected to the system, and that the lube system is properly connected to the bearing housing.

**CAUTION:** The bearings should never be rotated at full speed until the oil lube mist system is checked out and has been in operation for at least 5 minutes.

Next, check the foundations and foundation bolts to insure that the MicroMill is securely bolted and grouted to the foundation.

#### **3.1.5 Auxiliaries and Ducting**

The hot primary air duct attaching to the MicroMill feed system should be inspected and has been designed to allow sufficient expansion and not put undue stresses on the MicroMill System. Make sure that the ducting is free of all debris and construction materials that could possible cause damage during initial operation of the MicroMill System.

Dampers and control valves, if applicable, should be inspected to insure that there is sufficient clearance within the ducting and system to allow smooth operation at normal operating temperatures. All automatically operated control valves and dampers should be operated to insure that they are connected properly and responding to the proper input signals.

### 3.1.6 Turbo Blower

If provided, the turbo blower should be inspected to insure that there is no debris or foreign material in it and that it is installed in accordance with its manufacturer's recommendations. The unit should then be bumped electrically to insure that it is rotating in the proper direction and that the bearing system is functioning properly. Once this has been established, the turbo blower should be operated for several minutes to insure that it is functioning properly. All discharge valves must be in the closed position.

## 3.2 START-UP AND INITIAL OPERATION

### 3.2.1 MicroMill

When the MicroMill is initially started, a person should be stationed nearby to immediately shut it down if unexplained sounds are heard or vibration exceeds 40% of full scale (.4in/sec of velocity). The MicroMill should be started the first time in manual. There may be a squealing or belt noise when the last torque on the motor occurs; this is normal and can be minimized by insuring that the belts are tensioned properly. At full speed the MicroMill should make no more noise that a turbine or such device of its size would make. If there are any unusual noises such as clicking, rubbing, squeaking, et cetera, the unit should be shut down immediately, the cause of the noise determined and eliminated. The vibration on the unit should be watched closely during start-up and if for any reason it appears it is excessive (greater than 40% of the scale provided), the unit should be shut down immediately and the cause of the vibration determined and eliminated. If the MicroMill is operating normally with all parameters such as vibration level, drive motor amperage, bearing temperatures and so forth within normal ranges, the MicroMill should be operated empty for a period of one to two hours before actual processing of coal/raw material. During this initial operation, the unit should be checked continually for such things as vibration, noises, bearing temperatures,

and other parameters impacting its operation.

### 3.2.2 Motor

During this initial operation, the motor should be checked to insure that the bearing temperatures are running within acceptable limits and that the motor cooling system inlet and outlet are free of all foreign material. While running without raw feed, the motor should not consume more than 40 kilowatts of power. If it consumes more than 40 kilowatts of power, determine the reason and correct the problem.

**NOTICE:** Inspection of the motor and bearing area should not be made with the mill in service unless the belt guard is in place and secure.

### 3.2.3 Valves and Auxiliaries

Once the MicroMill is up and running and you are satisfied that all operating conditions are within normal bounds, the balance of the system should be brought on line which would include the turbo blower, the airlock under the classifier, and the feed screw conveyor. These components should be operated for 30 minutes to one hour to insure that they will operate for extended periods without malfunctioning.

## 3.3 PREREQUISITES FOR GOOD OPERATIONS

### 3.3.1 Feed Screw Conveyor

It is required that the material provided to the feed screw conveyor be no greater than 2" x 0 to avoid undue wear, material stoppage and unnecessary jamming of the feeder. If a drive sheave is connected to the screw feed conveyor with a shear pin, a small supply of shear pins should be available. If the drive unit is not provided with shear pins and is protected by thermal overloads on the drive motor, the starter should be inspected to insure that the proper size heaters are installed.

The feed screw conveyor is equipped with clean-out and inspection doors for quick access should the screw conveyor become jammed. If the feed screw conveyor should become jammed or locked with either large lumps of coal or foreign material, the power to the feed screw conveyor drive should be disconnected prior to removing any of the access doors and freeing the foreign material. Once the foreign material is removed, the access and clean-out door should be securely attached prior to

restarting the feed screw conveyor. Keep the feed screw conveyor and its drive clean and frequently inspect it for proper operation and lubrication. Good housekeeping and preventative maintenance can save future operating troubles.

### 3.3.2 MicroMill

The MicroFuel MF-3018 MicroMill takes material that is sized 2" x 0 or less as fed to it by the feed screw conveyor, micronizes it and discharges it with the primary air to the burner or collection device. The rate of raw material feed is entirely controlled by the rotating speed of the feed screw conveyor. In order to obtain proper mill performance, the MicroMill should be operated at its designed speed. For the MF-3018 system, the impeller rotating speed is 2860 revolutions per minute.

### 3.4 OPERATION OF THE MICROMILL WHEN GRINDING COAL/RAW MATERIAL

Before the MicroMill is placed in service, calibration of the screw feed conveyor should be checked to verify that the feed rate is within tolerance. All ancillary equipment (turbo blower, airlocks, automatic valves, etc.) should be checked out and working properly. When the MicroMill has been run at least two (2) hours without any abnormalities and the rest of the "total" system has been checked out, a cursory walk-around of the equipment should be made and inspected according to the checklist in Section 2.3. If everything is acceptable, start the equipment in "auto". While the MicroMill is running, keep monitoring the vibration, bearing temperatures and motor amp load. The vibration should be steady and not fluctuate over 10% over the "nominal" running percentage and the motor amps should not fluctuate +/- 8 amps from its running load. Bearing temperature should rise and stabilize after one hour. If for any reason erratic behavior in these areas should occur, the system must be shut down and the condition corrected.

The mill operating sequence in the automatic condition should be as follows:

- 1) Fan starts with valves closed.
- 2) Mill runs up to speed.
- 3) When Fan reaches full speed, valves open to position to establish air flow(s).
- 4) Preheat for air (if installed) starts, valves reposition for flow.
- 5) Preheat reaches setpoint, material feed starts.

When the raw feed starts, the MicroMill should be monitored to insure all parameters are at their running conditions for the first hour and then on a time basis as determined by experience.

Before starting the MicroMill, the following should be checked to insure that no problems are encountered during extended operations:

- 1) Lube mist oil reservoir checked and topped off.
- 2) Lube mist filter/receiver manual drain opened to remove condensate.
- 3) Supply air pressure is at least 80 psig (560 kPag).
- 4) Verify the labyrinth seal pressure regulator is set at 7 psig (49 kPag).
- 5) The lube mist system is operating correctly.
- 6) The tramp iron gate has been opened to remove any foreign material from previous operations.
- 7) Drive belts tensioned properly and checked for cracking and fraying.
- 8) No "unusual" oil leaks or stains.
- 9) No "unusual" complaints during previous operations.
- 10) ALL sensors are operating correctly.
- 11) Cooling water jacket is operating correctly.

---

## 4. MAINTENANCE AND REPAIRS

---

### 4.1 GENERAL

The parts needing most frequent replacement in the MicroMill System are: the replaceable blade sections, the Rotational Impact Zone (RIZ) and cone liners. The design of the MicroMill is such that the replaceable blades can be retrofitted without removal of the RIZ or cone; however, to replace the RIZ liners and the upper cone liners, it is easier to remove these assemblies from the mill casing and work on them not attached to the mill.

The other wear parts needing replacement are the ceramics; however, these parts require replacement less frequently than other parts. To expedite maintenance work, it is advisable to have a forklift available for removal of the cone and RIZ sections.

Parts replacement are necessary when indicated by individual visual inspection. Initial inspection should take place at 300-500 tons throughput after commissioning. Subsequent inspections should take place at every 1000 tons of throughput, or longer, as indicated by appearance and inspections.

The replacement of the wear parts and blade sections is dependent on the throughput and the constituents in the raw feed. The blade life will vary and experience will determine the inspection and replacement cycles.

### 4.2 REPLACEABLE-BLADE SECTIONS

The replaceable-blade sections can be accessed by removing the RIZ bolts and dropping the RIZ/cone assembly from the mill casing. Once these parts are removed and swung out of the way, the maintenance crew has access to the replaceable blades and impeller.

**NOTE:** Always install the impeller supports provided to the RIZ flange tapped holes to insure that the impeller will not drop down and injure those working on it.

**NOTE:** The replaceable-blade sections, RIZ liners and upper cone liners are made of high chrome, white iron, wear-resistant material. This material is brittle and subject to mechanical failure should the sections be dropped or impacted with heavy objects.

The blade sections can then be removed and replaced by removing the center cap, and then remove the 12 Allen bolts from the retainer ring (01.01.01.07 dwg 2.707751). Remove the inspection plate to gain access to the locknuts located on the back side of the impeller backplate. With a 3/4" (approximately 19mm) combination wrench or socket, hold the hex bolt in place while using a 3/4" (approximately 19mm) socket with extension to remove the hex nut. Once this is accomplished, the blade section can be removed by loosening the 9 hex bolts.

**NOTE:** Care must be taken that the impeller blade does not fall on workers.

Replaceable blades are sold balanced. Once the blade has been removed from the backplate, the backplate should be inspected and cleaned prior to reinstalling a new blade. The blade is installed in reverse sequence (refer to drawing 2.707750). Each new installation, lightly coat the blade locking bolt with anti-seize compound and with a new blade washer (01.01.01.15 dwg 2.707750), tighten to the specific level on drawing 2.707750. Install and torque the retainer bolt locking nut while holding the hex bolt so it does not change position. See drawing 2.707750 for the torque value.

The retainer ring should be reinstalled and the Allen bolt threads coated lightly with anti-seize compound and torqued in accordance with drawing 2.707750 in an opposing fashion. The backplate should be checked for alignment per Section 2.4.1 in the Installation Section. If the backplate is within tolerances as specified, the cover cap can be installed. The cover cap O-ring should be inspected and replaced, if needed. The bolt should have two drops of Loc-tite 242 or comparable product applied to the threads, installed and torqued to 30 ft-lb (40.7 N-m).

It is recommended that on alternating blade replacements the backplate be removed and the labyrinth seal and shaft area be inspected. With the backplate removed, it is recommended that the replacement blade should be placed on the backplate of the MicroMill. The backplate and new blade section should be balanced as a component to insure that the system is within balancing tolerances if the replacement blade set was not balanced by Fuller Mineral Processing Inc. Contact Fuller Mineral Processing Inc. for information regarding balancing of blades and backplate. Once this is complete, the backplate can be installed by following the installation procedures in the installation section of this manual (Section 2.4.1).

#### 4.3 ROTATIONAL IMPACT ZONE (RIZ) AND MILL CONE LINERS

The Rotational Impact Zone (RIZ) and mill cone liners do not require replacement frequently and should be inspected each time the replacement blades are changed. When it is apparent during the current blade change that these liners will need to be replaced (RIZ 01.01.01.13, Cone 01.01.01.21 on dwg. 1.716957), they should be ordered along with compressible washers (Item 01.01.06.01) and placed in stock.

Replacement of these liners is accomplished by removing the cone and RIZ sections from the MicroMill. With the RIZ and cone sections out, remove the retaining bolts and compression washers. Remove the worn casting and clean the old sealant off the outside of the RIZ and cone. New compression washers and sealant (clear silicone or equal) are required around the retainer bolts to insure no leakage of material or air through the clearance holes for the mounting bolts. Once they are in place, reinstall the RIZ and rotate the impeller by hand to insure there are no interference problems with RIZ-to-mill housing connection. This is critical because if the sections extend above the recommended clearances, contact with the rotating replaceable blades is possible. Once this is complete, the cone, expansion joint and the rest of the MicroMill can be assembled and started up using the initial operational start-up procedures.

#### 4.4 INSTALLATION OF NEW BEARINGS

The bearings are designed to give extended life under normal operation and should not be changed unless they are suspected of excessive wear or damage. To install the bearings, it is necessary to remove the bearing housing. If the replacement of the bearings becomes necessary, it is recommended that a Fuller Mineral Processing Inc. service technician be employed to assist in this work. Too much emphasis cannot be placed on cleanliness and the handling of these bearings, the shaft and the bearing housing assembly. It is necessary to use clean rags (not waste) and have clean hands. Great care should be taken in cleaning the bearing housing and shaft. Grit and rust are the natural enemies of polished bearing surfaces and must be avoided. New bearings should never be removed from their carton or wrapper until they are ready to be mounted on the MicroMill shaft. It is recommended that the top and bottom oil seals, gaskets, bearing locknuts and washers be replaced at the same time that new bearings are installed.

**Caution:** Prior to removing the impeller assembly, the impeller supports provided should be in place and should be blocked properly so that if the impeller should drop inadvertently, it

would not cause damage or injury to anyone.

To remove the bearing housing, it is necessary to first remove the impeller section. Unbolt and remove the expansion/liner joint, as described in Section 4.2, and swing the RIZ/cone assembly out of the way. Install the impeller supports. Blocks of wood **MUST** be placed on top of the impeller supports high enough so that no more than a 1/4" (6mm) gap is between the block of wood and the lowest point of the blades. This is necessary because when the Ringfeder is released, the impeller will drop. Remove the cover cap. On the Ringfeder locate the four "loosen" holes (See Figure 1) and remove the Allen bolts adjacent to them and thread the Allen bolts into the "loosen" hole. Remove the remaining Allen bolts. In an alternating fashion tighten the four "loosen" bolts until the impeller is released from the shaft. A forklift is recommended to take the impeller down at this point; however, an overhead crane or chain hoist can be used if a forklift is not available.

After the impeller is removed, all electrical, air and lubrication connections should be removed from the bearing housing. Remove the size 1/4-20 Allen bolts that hold the stationary member of the labyrinth seal and carefully slide it down from the rotating sleeve. Open the cover to the belt guard, loosen the motor mounting bolts. Using the motor adjusting bolts, move the motor to disconnect the drive belt(s). Refer to the sheave section of this manual and remove the driven sheave from the bearing housing. Unbolt and remove the belt guard. Remove the eight 5/8" (approximately 16mm) diameter bolts. By tightening the two 1/2" (approximately 13mm) jack bolts, the bearing housing will be released. Using the 5/8-11 UNC tapped hole in the end of the shaft, the bearing housing can be lifted out. Loosen the six #10 Allen bolts that hold the rotating sleeve to the shaft and carefully slide the sleeve off.

Disassemble the bearing housing by reversing the instructions detailed on drawing 2.708145. Please note that the preheating of the lower bearing must be skipped during disassembly.

Inspect the shaft and housing for any signs of scoring, wear, pits or other indications that the shaft or housing needs replacement or refurbishment. If there are no indications of problems, clean the shaft and housing with solvent and wipe clean with uncontaminated, dirt-free rags.

#### 4.5 REASSEMBLY OF THE BEARING HOUSING

Extreme care must be taken when reassembling the bearing housing. All surfaces and the work area must be clean. The procedure detailed on drawing 2.708145 must be followed for the

appropriate results. The following are recommendations to be followed during installation:

- During assembly replace the oil seals (01.01.01.17) in the upper and lower bearing housing caps. Lightly coat the cap bored hole with oil to help ease the installation of the seal. Make sure that when installing the seals, that they are not "cocked" or crooked when being pressed in.
- Place the shaft in a vise being careful not to scratch, dent or damage the shaft surface. This will aid in placing the bearings.

#### 4.6 OIL FOR LUBRICATING BEARINGS AND THE LUBEMIST SYSTEM

The lubricating oil for the lube mist system should be a synthetic based SAE 20W, the MicroFuel part number is 01.01.02.20 on parts list 5.701743. This oil is a Mobil synthetic, their part number SHC 626 and has an ISO viscosity grade of 68. This oil is superior to all mineral oils and outperforms them in many aspects, and should be used in this application. Any oil that matches the Mobil SHC 626 specifications is adequate.

Oil consumption for the LubeMist System is approximately 0.4 fluid ounces per hour (.0296 l/HR) with air consumption at 1.2 SCFM (.472 liter/sec). The reservoir contains 1 U.S. gallon (3.79 liter) of oil, and will last about 240 hours before it needs to be refilled.

The LubeMist System is a very low maintenance unit, and the following items should be checked on a semi-annual basis.

- 1) Replace air filter element.
- 2) Inspect and clean the reservoir.
- 3) Inspect and clean the oil suction tube screen.

#### 4.7 MAINTENANCE OF FEED SYSTEM AND AUXILIARIES

Regular checks of the system components will help prevent equipment failures. Routine checks of the feed system, classifier, air supply system and other equipment should be done for routine wear and adjustment. These procedures are intended only for routine maintenance and adjustments, with more in-depth information contained in Parts Lists 5.702628, 5.702629, 5.702406, 5.701743, and Classifier drawing 429-93-4-2003 sheets 1 and 2.


#### 4.8 MICROMILL, CLASSIFIER AND AIRLOCK

The doors of the classifier should be opened, a visual inspection made and the following items should be checked:


- 1) Door gaskets.
- 2) Classifier internals. Check for worn parts or broken welds.
- 3) Check expansion joint from mill discharge to classifier inlet.
- 4) Check the exterior for leaks in weld seams.
- 5) Check airlock drive chain for tightness.
- 6) Check gear box lube level on airlock.
- 7) Check driver/driven gears on airlock for wear or broken teeth.
- 8) Check for loose hardware on the frame and mill system.
- 9) Check for leaks at all joints such as the cone/RIZ connection, RIZ/mill casings connection and all piping.
- 10) Check for oil leaks at the bearing housing and all associated piping for the lubrication system.

#### 4.9 ROUTINE MAINTENANCE FOR SCREW FEEDER, MOTOR, AND OTHER ANCILLARY EQUIPMENT

Routine maintenance for the auxiliary equipment for a MicroFuel System requires only basic checks of gearbox oil levels, and routine greasing of bearings. This should be done at a minimum of semi-annually, more often depending on how long the system is on-line.



"TIGHTEN" POSITION



"LOOSEN" OR "REMOVE" POSITION

FIGURE 1

# ENGINEERING DATA SHEET

**OLSON technologies**  
**HOMESTEAD & MOSSER VALVES**  
PO BOX 2585 • BETHLEHEM, PA 18001 • PHONE (215)770-1100  
FAX (215)770-1108

SHEET NO. S 50324 1Q02  
PAGE 1 OF 3 DATE 12/29/80

## Installation, Operation & Maintenance Instructions - Butterfly Valves Type 15-25# AW, CW, AL, CL

### GENERAL

All valves are bi-directional valves, and as such, can be installed regardless of the direction of flow. Although the valves are designed to operate in any position, a horizontal shaft orientation is recommended.


Positioning lugs, drilled holes and tapped holes are incorporated into the body design of valves to assure correct positioning in the line.

These valves are machined with a specific clearance between the valve disc and the valve body. This clearance is based on the intended service temperature.

Note: If the valve is not received as a valve/operator assembly, care must be taken in the field to insure that the proper clearances are maintained since the limiting benefit of any operator is lost.

To check the clearance of any AL/CL or AW/CW valve, establish the total clearance between the disc and body at both hubs. One-half of this dimension is the proper radial clearance between the disc and body.

Before installing an AL/AW valve in the line, be sure that the edge of the closed disc at the extreme limit of its travel is not against the valve body. To maintain the designed clearance, the disc of this type of valve is machined with a 5° bevel on the seating edge and is intended to seat at a 5° angle to the plane of the valve. Failure to observe the above may result in the valve binding up elevated temperatures.



# ENGINEERING DATA SHEET

**WILSON technologies**

**HOMESTEAD & MOSSER VALVES**

PO BOX 2585 • BETHLEHEM, PA 18001 • PHONE (215)770-1100  
FAX (215)770-1108

SHEET NO. S 50324 1Q02  
PAGE 2 OF 3 DATE 12/29/80

Disc-Body interference normally is not a problem in CL/CW valves, because these valves employ a swing-thru design.

Gasket material should be checked to assure compatibility with the flowing medium and service requirements.

## INSTALLATION

Installation is accomplished by closing the valve and positioning it with proper gasketing between the flanges of the pipeline.

Sealing surfaces of both the valve and the companion flanges should be cleaned with a suitable solvent and the valve body aligned with the corresponding bolt holes of the pipeline flanges. Insert two bolts at the bottom of the flange to aid in supporting and aligning the valve. Insert the remaining bolts around the flange connection and tighten lightly. Final tightening of all bolts should be done evenly by tightening those bolts opposite each other in alternate sequence.

## OPERATION

After the valve has been installed in the line, all foreign matter that could interfere with proper seating should be removed from the system. The valve should be manually cycled to determine whether the blade is operating freely.

Note: The normal direction of rotation to close a valve is clockwise. This is based on the rotation of the shaft at the operator end of the valve while sighting along the shaft toward the valve.

Check the source of supply of any necessary pneumatic or electrical connections for compatibility with the valve operator requirements.

Note: A groove appears on the top of all valve shafts. This groove is parallel to the disc and may be used to indicate its position.

# ENGINEERING DATA SHEET

**WILSON technologies**

HOMESTEAD & MOSSER VALVES

PO BOX 2585 • BETHLEHEM, PA 18001 • PHONE (215)770-1100  
FAX (215)770-1108

SHEET NO. S 50324 1Q02


PAGE 3 OF 3 DATE 12/29/80

After connection of the operator power supply and adjustment of any limiting devices, cycle the valve a few times to determine whether the operator connections are correct and that the valve is operating properly.


## MAINTENANCE

Routine maintenance of valves is normally confined to addition and/or replacement of the packing rings; however, it should be noted that total replacement of the packing rings may cause leakage during the operation and isolation of the line may be necessary.

Valves are furnished with adjustable packing glands or gland nuts which may be inspected periodically and adjusted as required.



GLAND NUT



PACKING GLAND

If additional packing is needed, or complete replacement is required, be sure that the additional or replacement packing material is compatible with the flowing medium and service requirements. For best results the joints of the packing rings should be staggered.

Replacement of non-consumable parts such as bearings, glands, taper pins, etc., is considered as an overhaul procedure, since the valve must be removed from the pipeline and disassembled. A special spare parts kit containing packing, bearings, gland or gland nut, and taper pin is available. When ordering spare parts, please include the following information: 1) valve size, 2) valve type, 3) figure number, and 4) order number.



11444 Deerfield Rd.  
Cincinnati, Ohio 45242  
(513) 489 - 7800  
FAX (513) 489-5243

# SuperNova S-Series


## Installation, Operating & Maintenance Instructions

All actuators are factory lubricated for life, but still should be protected from the elements and stored indoors until ready for use. The ports of the actuator are plugged as supplied from the factory. If actuators are stored for a long period of time prior to installation, the units should be stroked periodically to prevent the seals from taking a set.

Prior to assembly, check the mounting surfaces, the stem adaptor and the bracket to assure proper fit. Manually open and close the valve to insure freeness of operation. Be sure the valve and Automax actuator rotate in the same direction and are in the same position (i.e. valve open, actuator open). Secure the valve with the stem vertical. Bolt the bracket to the valve and place the stem adaptor on the valve stem. Position the actuator over the valve and lower to engage the stem adaptor to the actuator shaft. Continue to lower until the actuator seats on the bracket mounting surface. In order to align the bolt holes, it may be necessary to turn or stroke the actuator a few degrees and/or adjust the actuators travel stops. Bolt the actuator to the bracket.

After consulting the valve manufacturer's recommendations, adjust the travel stop bolts of the actuator for the proper open and closed valve positions. Pneumatically stroke the actuator several times to assure proper operation with no binding of the stem adaptor. If the actuator is equipped with an UltraSwitch or other accessories, adjust them at this time.

To prolong actuator life use only clean, dry plant air. Lubricated air is not required, however it is recommended particularly for high cycle applications. Do not use lubricated air with positioners.



Actuator	Endcap Screw Socket Size	Adjustment Bolt Socket Size	Spring Color Code
S50	4mm	1/8 inch	white
S63	5mm	5/32 inch	lt. green
S85	6mm	3/16 inch	blue
S100	6mm	7/32 inch	red
S115	6mm	7/32 inch	yellow
S135	8mm	1/4 inch	grey

### Travel Stop Adjustments (Patent #4,949,936)

#### Both Directions 5° Overtravel 12° Adjustment Each End

The *SuperNova* Series actuators have unique, patented travel stop adjustments in both the clockwise and counterclockwise directions. The 10° total overtravel provides adjustments from -5° to +7° at the 0° clockwise position and from +83° to +95° at the 90° counterclockwise position.

All actuated valves require accurate travel-stop adjustments at both ends of the stroke to obtain optimum performance and valve seat life. The accumulation of tolerances in the adaption of actuators to valves is such that there must be a range of adjustment for both ends of the stroke to achieve the expected performance.


**Ball and Plug Valves** require precise adjustment at the open (CCW) position to protect the seat from the flow media and the closed (CW) position to assure absolute shut-off.

**Butterfly Valves** require precise adjustment at the closed position to assure full shut-off, to prevent disc overtravel and damage to the seat at the closed position and to assure maximum flow in the open position.

**Tandem Valves**, where two valves are operated in tandem through a single solenoid valve (eg. a 3-Way configuration), absolutely require precise adjustment at both ends of the stroke to assure the seating of both valves.

### Stop Adjustments and Locations

View the actuator with the Air Ports facing you.




### Adjustment Bolt Location

Actuator Type	Fail Position	Clockwise (CW)	Counterclockwise (CCW)
Double Acting		Left End Cap	Right End Cap
Single Acting	CW	Left End Cap	Right End Cap


### Maintenance Instructions

#### Disassembly Procedures

1. Disconnect all air and electrical supplies from actuator.
2. Remove all accessories from actuator and dismount actuator from valve.
3. Position actuator with air supply ports facing you. Apply air pressure to Port 2 to release spring pressure from the Stop Bolt (9).
4. Remove the Stop Bolt Retaining Nut (14), Washer (15), and O-ring (16) on the Left Endcap (19) and turn the Stop Bolt (9) clockwise into the Body (1) until it is flush with the Endcap (19).
5. Exhaust air from Port 2, the Stop Bolt (9) should now turn freely. Continue turning Stop Bolt (9) clockwise until it is disengaged from the Endcap.
6. SR Actuator:  
**CAUTION: Follow step 4 to relieve force on inward travel stop before proceeding.** To remove SR Endcap, first completely remove two diagonal Endcap Screws (21) from one Endcap. The two remaining Endcap Screws should be removed evenly. As the Screws are removed, the springs will push the Endcap out. Repeat for opposite side. The springs will be totally unloaded before the screws are completely unthreaded. Remove the springs (23,24,25.)



Actuator with springs partially disarmed (right side)



Actuator with springs totally disarmed

DA Actuator: Remove the 8 Endcap Screws (21). Step 7 will push the Endcaps (18,19) from the Body (1).

7. Rotate Pinion (3) counterclockwise (DA & SR-FCW) or clockwise (DR & SR-FCCW) to drive the Pistons (2) off the end of the rack. Pull the Left Piston (2) from the body (1) by pulling on the Stop Bolt (9).
8. Remove the Right Piston (2) by pushing out

#### Reassembly Procedures

1. Inspect all parts for wear and replace any worn parts as needed. Replace all O-rings.
2. Clean all components and lightly grease cylinder bore, pinion and seals with a multi-purpose 'polymer' fortified grease such as DuBois Chemicals MPG-2. Lubricate endcap screw (21) threads with similar grease.
3. Reverse the disassembly procedures to reassemble.
4. The standard Pinion (3) orientation is with the drive pocket parallel with the Body (1) in the CW position.
5. When fitting the Pistons (2) ensure the teeth engage the Pinion (3) at the same time by measuring in from the edge of the body (1) the same distance from each end. Note: the orientation of the pistons will determine the operation of the actuator. Refer to the diagrams under 'Operation' for correct piston position.
6. Test the actuator for smooth operation and air leakage at service pressure before reinstalling.

#### Changing Number of Springs

1. Follow the Disassembly Procedures through step 6.
2. Determine nested spring combination of inner, middle and outer springs. Consult catalog torque charts, distributor or factory. Insert appropriate springs into cylinder. Springs must be properly seated against piston and endcap to assure that springs do not bind.
3. Re-assemble the actuator.

Spring chart S63-S200

Spring Group	Spring Combination Ⓞ		
	#1 Spring (Inner)	#2 Spring (middle)	#3 Spring (outer)
4		2	
5		1Ⓞ	1Ⓞ
6			2
7	1		2
8	2		2
9	1Ⓞ	1Ⓞ	2
10		2	2
11	1	2	2
12	2	2	2

Spring chart S50Ⓞ


Spring Group	Spring Combination Ⓞ		
	#1 Spring (inner)	#2 Spring (low rate outer)	#3 Spring (high rate outer)
4	1Ⓞ	1Ⓞ	
5		2	
6	2	1	
7	1	2	
8	2	2	
9	2		2

## Operation


(as viewed from top of actuator)

### Double Acting

Applying air pressure to Port 2 drives the pistons outward, which turns the pinion counterclockwise as the air volume on the outside of the pistons exhausts through Port 1.




Applying air pressure to Port 1 drives the pistons inward, which turns the pinion clockwise as the air volume on the inside of the pistons exhausts through Port 2.




### Spring Return (Fall CW)

Applying air pressure to Port 2 drives the pistons outward, which compresses the springs and turns the pinion counterclockwise as the air volume on the outside of the pistons exhausts through Port 1.




Exhausting the air pressure from Port 2 allows stored energy of the springs to drive pistons inward, turning the pinion clockwise. Air volume on outside of pistons vents through Port 1.




### Spring Return (Fall CCW)

Applying air pressure to Port 2 drives the pistons outward, which compresses the springs and turns the pinion clockwise as the air volume on the outside of the pistons exhausts through Port 1.



Exhausting the air pressure from Port 2 allows stored energy of the springs to drive pistons inward, turning the pinion counterclockwise. Air volume on outside of pistons vents through Port 1.




## Changing Pinion Orientation

*Note: Steps 4 & 8 are not required for DA actuator.*

1. Disconnect all air and electrical supplies from actuator.
2. Remove all accessories from actuator and dismount actuator from valve.
3. Position actuator with air supply ports facing you.
4. Follow step 6 under disassembly procedure to un-
5. Tap Pinion (3) lightly with plastic mallet to remove.
6. Tap Pinion (3) lightly with plastic mallet to remove. **CAUTION: Failure to follow step 4 will result in permanent damage to SR actuator.**
7. Reverse Steps 5 & 6 with new Pinion (3) orientation.
8. Assemble right endcap (18) in reverse order of dis-

### Parts & Materials



\*Consult Automax or your distributor for Parts and Materials for other series of Actuators.

Item No.	Part Description	Materials	Quantity	
			DA	SP
1	Body	Hard Anodized Aluminum	1	1
2	Pistons	Die Cast Aluminum	2	2
3	Pinion	Nickel Plated Steel	1	1
4	Pinion Washer $\emptyset$	Nylon	1	1
5	Pinion Snap Ring $\emptyset$	Steel/Plated	1	1
6	Upper Pinion O Ring $\emptyset$	Nitrile Rubber	1	1
7	Lower Pinion O Ring $\emptyset$	Nitrile Rubber	1	1
8	Piston and End Cap O Ring $\emptyset$	Nitrile Rubber	4	4
9	Inward Travel Stop Bolt	Steel/Plated	1	1
10	Inward Travel Retaining Nut	Steel/Plated	1	1
11	Inward Travel Spring	Steel/Plated	1	1
12	Piston Guide	Nylon and Molybdenum Disulfide	2	2
13	Piston Guide Band	Nylon and Molybdenum Disulfide	2	2
14	Stop Bolt Retaining Nut	Stainless Steel	2	2
15	Stop Bolt Washer	Stainless Steel	2	2
16	Stop Bolt O Ring $\emptyset$	Nitrile Rubber	2	2
17	Stop Bolt	Steel/Plated	1	1
18	Right End Cap	Die Cast Aluminum/Electrostatic Poly	1	1
19	Left End Cap	Die Cast Aluminum/Electrostatic Poly	1	1
20	End Cap Supply O Ring $\emptyset$	Nitrile Rubber	2	2
21	End Cap Screw	Stainless Steel	8	8
22	End Cap Screw Washer	Stainless Steel	8	8
23	Outer Spring	Spring Steel Coated	0	2 max. $\emptyset$
24	Middle Spring	Spring Steel Coated	0	2 max. $\emptyset$
25	Inner Spring	Spring Steel Coated	0	2 max. $\emptyset$

### Seal Kits

Buna Seal Kit Number	SN (Actuator Model No.) SKB
Viton Seal Kit Number	SN (Actuator Model No.) SKV

SN kits consist of all sealing parts, snap ring and washer.

### Pressure Rating

150 psig maximum







### Temperature Ratings

Standard	Nitrile	-20°F to +175°F
High Temp	Viton	0°F to +300°F
Low Temp	Silicon-based	-55°F to +175°F

Note:  $\emptyset$  Parts Included in a Seal Kit.  
 $\emptyset$  See Spring chart for required spring combination



500-1001-P



DIMENSIONS		DIMENSIONS																
W	Dp	A	B	C	D	E	F	H	J	K	L	M	N	P	Q	A	S	T
1/2	1/2	1.06	6.00	2.00	—	28	12.50	—	2.50	4.00	2.00	2.50	2.50	4.00	4.00	—	—	—
3/4	3/4	2.25	6.50	2.50	—	38	8.00	—	2.75	4.75	3.00	2.00	2.50	4.00	4.00	—	—	—
1	1	3.06	6.75	3.00	—	38	8.25	—	3.00	5.00	3.00	2.00	2.50	4.00	4.00	—	—	—
1 1/4	1 1/4	4.25	7.50	4.00	—	50	9.00	—	3.75	5.75	3.00	2.00	2.50	4.00	4.00	—	—	—
1 1/2	1 1/2	4.31	8.00	4.00	—	50	9.50	—	4.25	6.25	3.00	2.00	2.50	4.00	4.00	—	—	—
1 3/4	1 3/4	6.31	8.50	5.00	—	55	10.00	—	4.62	6.62	3.00	2.00	2.50	4.00	4.00	—	—	—
2	2	8.31	9.75	6.00	—	55	11.25	—	5.62	7.62	3.00	2.00	2.50	4.00	4.00	—	—	—
2 1/4	2 1/4	11.20	10.00	6.00	—	65	12.50	—	6.62	8.62	3.00	2.00	2.50	4.00	4.00	—	—	—
2 1/2	2 1/2	12.50	12.00	—	—	75	14.00	—	8.62	10.62	3.00	2.00	2.50	4.00	4.00	—	—	—
3	3	15.50	13.25	—	—	75	15.00	—	10.62	12.62	3.00	2.00	2.50	4.00	4.00	—	—	—
3 1/2	3 1/2	14.75	15.25	—	—	75	16.25	—	12.62	14.62	3.00	2.00	2.50	4.00	4.00	—	—	—
4	4	15.50	17.25	—	—	100	17.25	—	14.62	16.62	3.00	2.00	2.50	4.00	4.00	—	—	—
4 1/2	4 1/2	16.88	19.25	—	—	100	18.62	—	16.62	18.62	3.00	2.00	2.50	4.00	4.00	—	—	—
5	5	20.20	21.25	—	—	100	20.62	—	18.62	20.62	3.00	2.00	2.50	4.00	4.00	—	—	—
5 1/2	5 1/2	22.25	22.25	—	—	100	22.25	—	20.62	22.62	3.00	2.00	2.50	4.00	4.00	—	—	—
6	6	23.50	23.50	—	—	100	23.50	—	22.62	24.62	3.00	2.00	2.50	4.00	4.00	—	—	—
6 1/2	6 1/2	25.25	25.25	—	—	100	25.25	—	24.62	26.62	3.00	2.00	2.50	4.00	4.00	—	—	—
7	7	28.25	28.25	—	—	100	28.25	—	26.62	28.62	3.00	2.00	2.50	4.00	4.00	—	—	—
7 1/2	7 1/2	30.50	30.50	—	—	100	30.50	—	28.62	30.62	3.00	2.00	2.50	4.00	4.00	—	—	—
8	8	32.25	32.25	—	—	100	32.25	—	30.62	32.62	3.00	2.00	2.50	4.00	4.00	—	—	—
8 1/2	8 1/2	34.00	34.00	—	—	100	34.00	—	32.62	34.62	3.00	2.00	2.50	4.00	4.00	—	—	—
9	9	35.50	35.50	—	—	100	35.50	—	34.62	36.62	3.00	2.00	2.50	4.00	4.00	—	—	—
9 1/2	9 1/2	36.00	36.00	—	—	100	36.00	—	36.62	38.62	3.00	2.00	2.50	4.00	4.00	—	—	—
10	10	38.00	38.00	—	—	100	38.00	—	38.62	40.62	3.00	2.00	2.50	4.00	4.00	—	—	—

NOTES:  
 1 MAX OPERATING TEMP 325°F FOR STD MATERIALS  
 2 2"-24" A-536 BODY & BLADE; 25"-40" A-125 CL-B BODY A-536 DISC  
 3 FOR DIRTY SERVICE SPECIFY INBOARD PACKING  
 4 FOR HIGH TEMP SERVICE TO BOO F SUBSTITUTE THE FOLLOWING:  
 MEEHANITE H.S. BODY, DISC & CARBON BEARING & WG 1 PACKING  
 5 PRESSURE RATINGS:  
 2-12" 25 PSI  
 16-40" 15 PSI

ITEM	DESCRIPTION	MATERIAL
1	PIPE PLUG	A-126 CL-B (F RECD) 2
2	SPACER PIN	STAINLESS STEEL
3	BEARING	CARBON STL (F RECD)
4	BEARING	SAE 660 (BRONZE)
5	PACKING	TFE/ASB
6	PACKING NUT	BRASS
7	TOP SHAFT	A564 XM 25 (450 SS)
8	BOTTOM SHAFT	A564 XM 25 (450 SS)
9	BLADE	SEE NOTE 2
10	ROOY	SEE NOTE 2

BILL OF MATERIAL

DRILLING

P-1001-405

## MECHANICAL INSTALLATION DESCRIPTION

KODAK  
96-11028-745



KODK-DV-38-0-

000-000-0026--0-

DATE: June 6, 1996

00009-

96-11028-745--6/6/96

The following description details how the mill circuit will be shipped to site and provides a suggested method of how to install the system. Use this description in conjunction with the Installation, Operation & Maintenance Manual (IO&M) for the 3018 Micromill. The balance of plant contractor may adapt the procedure as deemed fit by the contractor. Fuller Mineral is not responsible for any damage and/or injury incurred during installation.

### Notes:

- A) The description below does not detail what hardware to use in a specific situation. The contractor should refer to Fuller GA 1.725690 and Micromill parts list 5.702437 for this information. Hardware will be shipped loose.
- B) The description below does not detail the field welds required. Refer to Fuller GA 1.725690 for this information.
- C) This description is for information only. During packaging it may be necessary to modify how the system will be shipped. Fuller reserves the right to make any changes that are necessary.
- D) Do **NOT** grout until after all equipment is installed and aligned properly.

- 1) Mill Lower Frame:  
The mill lower frame (shown in green) should be located according to the customer's general arrangement drawings, and anchored using the recommendation detailed on Fuller drawing 1.725689 and IO&M.
- 2) The mill inlet pipe (shown in yellow) and inlet pipe support legs (shown in pink) should be placed within the mill lower frame, but **NOT** anchored.
- 3) Mill Upper Frame:  
The mill upper frame (shown in yellow) should be set in place on top of the lower frame. Bolts should be tightened to ensure that the upper frame will not move during the remainder of construction (refer to IO&M).
- 4) The Classifier Frame:  
The classifier frame (shown in green) should be located according to the customer's general arrangement drawing, and

anchored using recommendation detailed on Fuller drawing 1.725689 and IO&M.

- 5) Classifier:  
The classifier (shown in blue) should be set into place on top of the frame. The bolts tightened (refer to IO&M).
- 6) The Classifier Rotary Feeder (16 x 16):  
The classifier rotary feeder (shown in pink under the classifier) should be bolted to the bottom flange of the classifier in the orientation shown on Fuller GA 1.725690.


**Note:** At this moment the contractor should check the alignment of the mill outlet and classifier inlet to verify they are in line. If not the contractor may need to adjust the height of the classifier frame and/or Micromill frame.

- 7) The Intake Tee:  
The intake tee below the classifier rotary feeder (shown in yellow) should be brought into position under the rotary feeder. The contractor should set the elevation of the tee by bolting it to the rotary feeder. The tee's legs are shipped loose and must be welded on in the field. Once the tee elevation is set the contractor should tack weld the legs into place, then remove the tee and complete welding. The tee should then be brought in position and bolted to the rotary feeder with two bolts. The tee should NOT be anchored yet because the flange leading into the mill pipe must still be aligned and welded.
- 8) Mill Piping:  
The mill piping elbow (shown in blue) and mill inlet pipe (shown in yellow) should be aligned with the mill cone inlet and intake tee. The first step is to align the inlet pipe with the mill cone inlet (Note that there should be 12" or less space left between the cone and the top flange of the inlet pipe for the expansion joint). Once the inlet pipe is aligned, anchor the inlet pipe support legs using the recommendations on drawing 1.725689. Next, bolt the elbow onto the intake tee and align the elbow with the mill inlet pipe (the inlet pipe should rotate because the clamp on top of the inlet pipe support should be loose). The contractor may have to break the tack welds on the flanges to align them. Once everything is aligned, the flanges should be welded on and the inlet pipe support clamp tightened. The intake tee may need to be removed again to weld its flange on. After that is complete re-install the tee and fasten the legs and flanges (refer to drawing 1.725689).
- 9) The Mill Outlet and Expansion Joint:  
The mill outlet (shown in pink) and expansion joint (shown in green) can then be installed (refer to parts list for hardware).


- 10) Mill Inlet Rotary Feeder and Transition:  
The mill inlet rotary feeder (shown in pink) and transition (shown in blue) should be aligned so the feeder flange is oriented correctly and installed (Note the flange on the inlet pipe must be welded into position).
- 11) Motor and Soleplate:  
The mill motor (shown in green) and soleplate (shown in green) must be installed. Refer to Micromill parts list for hardware. The motor must be lowered into position from above. **NOTE: BE CAREFUL NOT TO DAMAGE MOTOR DURING INSTALLATION.**
- 12) The Mill impeller and back plate should be installed according to directions detailed in IO&M manual. **CONSULT FULLER IF YOU HAVE ANY QUESTIONS. THE IMPELLER ALIGNMENT AND BALANCE IS KEY TO SOUND MILL OPERATION.**
- 13) The mill inlet expansion joint (shown in blue) should be installed.
- 14) After the motor is in place the v-belt guard (shown in yellow) must be installed (refer to parts list).
- 15) The motor sheave, mill sheave, and V-belt assembly should be installed, aligned and tightened. The cover for the guard installed.
- 16) Lubemist system piping checked and tightened.

**REFERENCE DOCUMENTS:**

- A) FULLER DRAWINGS; 1.725690, 1.725689
- B) IO&M MANUAL
- C) FULLER PARTS LIST (ASSEMBLY DRAWINGS REFERENCED OFF PARTS LIST); 5.702437
- D) FULLER GA 1.725690 WITH MARKINGS INDICATING SHIPPING QUANTITIES.







BASE PLATE FOR CLASSIFIER  
(42) REQUIRED

BASE PLATE FOR MICRO MILL  
(43) REQUIRED

INTAKE TEE SUPPORT PLATE  
(42) REQUIRED

MILL FEED PIPE SUPPORT PLATE  
(42) REQUIRED

POSITION	REQD. LOAD
A	280 LBS. / 4,132 KG.
B	1,320 LBS. / 4,313 KG.
C	2,820 LBS. / 1,281 KG.
D	1,220 LBS. / 418 KG.
E	1,220 LBS. / 418 KG.
F	2,240 LBS. / 652 KG.
G	2,240 LBS. / 652 KG.
H	2,240 LBS. / 652 KG.
I	2,240 LBS. / 652 KG.
J	2,240 LBS. / 652 KG.
K	2,240 LBS. / 652 KG.
L	2,240 LBS. / 652 KG.
M	2,240 LBS. / 652 KG.
N	2,240 LBS. / 652 KG.
O	2,240 LBS. / 652 KG.
P	2,240 LBS. / 652 KG.
Q	2,240 LBS. / 652 KG.
R	2,240 LBS. / 652 KG.
S	2,240 LBS. / 652 KG.
T	2,240 LBS. / 652 KG.
U	2,240 LBS. / 652 KG.
V	2,240 LBS. / 652 KG.
W	2,240 LBS. / 652 KG.
X	2,240 LBS. / 652 KG.
Y	2,240 LBS. / 652 KG.
Z	2,240 LBS. / 652 KG.

- 1. MICRO MILL TO BE LOCATED IN FIELD. ANCHOR WITH 1/2" IN. DIA. ANCHORS. (SHOW DIMENSIONS) IN APPROXES EQUAL.
- 2. 3/8" PLATE
- 3. CLASSIFIER LOADING ASSUMES A MAXIMUM OF 1.5 LBS. LOAD FROM PIPING AND IS BASED ON CLASSIFIER BEING PLUGGED WITH CONG.
- 4. MICRO MILL TO BE LOCATED IN FIELD. ANCHORS WITH 1/2" IN. DIA. ANCHORS. (SHOW DIMENSIONS) IN APPROXES EQUAL.
- 5. 3/8" PLATE
- 6. 1/2" PLATE
- 7. BASE PLATE TO BE SET ON 1" (25) CONCR.
- 8. ALL DIMENSIONS ARE IN INCHES.


Welded by  
Professional Engineer  
MILLER ENGINEERING CO.  
11111 1/2" DIA. ANCHORS  
2000-000-0000-1



0000-000-0000-1  
MILLER ENGINEERING CO.  
11111 1/2" DIA. ANCHORS  
2000-000-0000-1

ITEM NO.	DESCRIPTION	QTY	UNIT	REVISIONS
1	BASE PLATE FOR CLASSIFIER	42	PCS	
2	BASE PLATE FOR MICRO MILL	43	PCS	
3	INTAKE TEE SUPPORT PLATE	42	PCS	
4	MILL FEED PIPE SUPPORT PLATE	42	PCS	

MILLER ENGINEERING CO.  
11111 1/2" DIA. ANCHORS  
2000-000-0000-1



PARSONS POWER  
 X REVIEWED AND ACCEPTED  
 AS NOTED (RESUBMIT FOR REVIEW)  
 NOT ACCEPTED (RESUBMIT FOR REVIEW)  
 FOR INFORMATION ONLY (REVIEW WAGON)

THE REVIEW OF THIS SUBMITTAL IS ONLY FOR GENERAL COMPLIANCE WITH THE DESIGN CONCEPTS OF THE REGULATORY AND SAFETY REQUIREMENTS. THE REVIEWER'S RESPONSIBILITY IS TO VERIFY THAT THE DESIGN MEETS THE REGULATORY AND SAFETY REQUIREMENTS. THE REVIEWER IS NOT RESPONSIBLE FOR THE DESIGNER'S FAILURE TO MEET THE REGULATORY AND SAFETY REQUIREMENTS. THE REVIEWER'S REVIEW DOES NOT CONSTITUTE A DESIGN, ORDER, AND CONTRACT. ACTION BY THE REVIEWER DOES NOT CONSTITUTE A DESIGN, ORDER, AND CONTRACT.

- ① ALL DIMENSIONS ARE IN INCHES.
- ② ASTM A36 UNLESS NOTED.
- ③ 3/4" THICK PLATE.
- ④ 3/8" THICK PLATE.
- ⑤ ALL WELDS TO HAVE FULL PENETRATION UNLESS NOTED.
- ⑥ ALL INTERNAL WELDS TO BE GROUND SMOOTH.
- ⑦ HOLE LOCATION TOLERANCE  $\pm 1/32"$
- ⑧ FABRICATION TOLERANCE  $\pm 1/8"$




CONSTRUCTION  
 JUN 04 1996



3.706395

Original	30MAY96	JBY	BJZ	BJZ	Revision in zone / Description
Scale:	Date	Sign.	Sign.	Sign.	Mt.: ② lbs: 80
3"=1'	Drawn	Chkd	Appr	Welds: AVS	ISD-E
MICRO MILL 3018					
MILL FEED TRANSITION					
Where nothing else is stated, adhere to general instructions No. 520530.					
DETAIL					
PC: 745					Drawing Number
					3.706395
					Rev:

FULLER MINERAL PROCESSING INC.



**MATERIALS:**  
 MOUNTING FLANGES: 10"-150lb. CARBON STEEL  
 PIPE BODY: 10" SCH. 40 CARBON STEEL PIPE  
 SENSING MANIFOLDS: 316 STAINLESS STEEL  
 SIGNAL CONNECTION: 1/4" COMPRESSION FITTINGS, STAINLESS STEEL  
 APPROXIMATE WEIGHT: 165lbs.

**PROJECT:**  
 EASTMAN KODAK  
 ROCHESTER, N.Y.  
 P. O. #5-9611028-6-0120  
 AMC W.O. #28082

**AIR MONITOR CORPORATION**  
 P.O. BOX 1486 SOUTH BEND, IN 46708  
 TELEPHONE (219) 384-2700

**FLOW STATION**

DATE PLOT	07/19/96	13:40:39	FORM/1/DRWG NO.	B	W28082AA	REV	0
SCALE FACTOR	8.00		SCALE	1:8.00		DO NOT SCALE DRAWING	


SO. DIB. (LBS)/GAS	UNITS	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12
MAX. FLOW - SOLID LBS/HR		6000.0	3000.1	3000.3	2400.0	2400.1	1142.9	6.2	1.3	6001.3	3000.1	1.5	
MAX. FLOW - LIQUID LBS/HR		486.5	1153.4	1384.4	242.4	242.4	1142.9	1142.9	2000.0	1342.9	1153.4	1725.4	
FLOW - GAS LBS/HR		1153.4	1384.4	1384.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	
FLOW - LIQUID LBS/HR		4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	
FLOW - TOTAL LBS/HR		4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	4165.1	
VELOCITY	Gas/Min	70.0	102.4	102.4	102.4	102.4	102.4	102.4	102.4	102.4	102.4	102.4	
TEMPERATURE		26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	26.0	
STATIC PRESSURE	INWG	0.0054	0.0054	0.0054	0.0054	0.0054	0.0054	0.0054	0.0054	0.0054	0.0054	0.0054	
DENSITY	LB/FT <sup>3</sup>	1.227	1.227	1.227	1.227	1.227	1.227	1.227	1.227	1.227	1.227	1.227	
MUST LOAD	GR/ACT	1327.48	1327.48	1327.48	1327.48	1327.48	1327.48	1327.48	1327.48	1327.48	1327.48	1327.48	
MAX. FLOW	TON/HR	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	
COMPRESSIBILITY	TON/HR	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	
COMPRESSIBILITY	TON/HR	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	1153.4	

**FULLER**  
MINERAL PROCESSING, INC.

**CERTIFIED FOR CONSTRUCTION**

SIGNATURE: *Clark P. [Signature]*

DATE: 26 Jul 91



**PARSONS POWER**

REMOVED AND ACCEPTED  
AS NOTED PREVIOUS FOR REVIEW  
NOT ACCEPTED PREVIOUS FOR REVIEW  
FOR INFORMATION ONLY PREVIOUS WANTED

THE REVIEW OF THE SUBMITTAL IS ONLY FOR GENERAL COMPLIANCE WITH THE DESIGN CONCEPTS OF THE PROJECT AND GENERAL COMPLIANCE WITH THE DESIGN AND GENERAL COMPLIANCE WITH THE PROJECT REQUIREMENTS FOR DIMENSIONS TO BE COMPLETED AND NOT FOR THE DESIGN TO BE REVIEWED FOR TECHNICAL OR CONSTRUCTION AND FOR REVIEW DOES NOT CONSTITUTE A CHANGE ORDER AND DOES NOT ALTER ANY CONTRACT TERMS AND CONDITIONS.


DATE: \_\_\_\_\_ BY: \_\_\_\_\_

REV.	DATE	BY	CHK	DESCRIPTION
1	11/25/91	WJ	WJ	ISSUED FOR CONSTRUCTION

1 OF 2 IDENTICAL SYSTEMS


**FULLER**

1.725164




**FULLER**  
 MINERAL PROCESSING, INC.  
**CERTIFIED FOR CONSTRUCTION**  
 DATE: JUL 30 1996  
 SIGNATURE: *[Signature]*

PROJECT NO.	1724708
DATE	JUL 30 1996
DESIGNED BY	[Name]
CHECKED BY	[Name]
APPROVED BY	[Name]
SCALE	AS SHOWN
PROJECT LOCATION	1724708
CLIENT	[Name]
PROJECT NO.	1724708
DATE	JUL 30 1996
DESIGNED BY	[Name]
CHECKED BY	[Name]
APPROVED BY	[Name]
SCALE	AS SHOWN
PROJECT LOCATION	1724708
CLIENT	[Name]



  
**FULLER**  
 MINERAL PROCESSING, INC.  
 CERTIFIED FOR CONSTRUCTION  
 FT-1G-158006V  
 SIGNATURE: *Blair Swanson*  
 DATE: Jul 30 1965

REV.	DATE	BY	CHKD.	DESCRIPTION
1	7/29/65	GA	LS	ADD'D READING INDICATING WATER METER
2	7/29/65	GA	LS	REVISION TO SPEC. / REVISION
3	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
4	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
5	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
6	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
7	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
8	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
9	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
10	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
11	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
12	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
13	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
14	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
15	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
16	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
17	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
18	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
19	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
20	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
21	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
22	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
23	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
24	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
25	5/20/65	GA	LS	REVISION TO SPEC. / REVISION
26	5/20/65	GA	LS	REVISION TO SPEC. / REVISION

MICROFILMED REPAIRING MILL NO. 2  
 FULLER MINERAL PROCESSING, INC.  
 NEW YORK, U.S.A.  
 1-724708



## LOAD LIST

NYSEG/KODAK MICRONIZED COAL REBURNING PROJECT  
NEW YORK, U.S.A.

REVISION 4 - JUL Y 26, 1996  
CONTRACT No. 96-11028-745  
DOCUMENT No. 8.700863

PREPARED BY: JB  
CHECKED BY: LJS  
FULLER MINERAL PROCESSING, INC.  
3235 SCHOENERSVILLE ROAD  
BETHLEHEM, PA 18016-0810  
TEL. 610-264-6900  
FAX. 610-264-6347

	<b>FULLER</b>
	MINERAL PROCESSING, INC.
<b>CERTIFIED FOR CONSTRUCTION</b>	
SIGNATURE	<i>Lawrence J. Supren</i>
DATE:	JUL 3 0 1996

LOAD LIST  
 NYSEG/KODAK MICRONIZED COAL REBURNING PROJECT  
 NEW YORK, U.S.A.  
 REVISION 4 - JULY 26, 1996  
 CONTRACT No. 96-1102E-745  
 DOCUMENT No. 8-798663

ITEM	EQUIPMENT NUMBER	KW	H.P.	RPM	VOLTAGE	DESCRIPTION	NOTES
1	PM-CH-15B001E	150	200	1800	480 VAC	MILL MOTOR	MARATHON, 1.15 SF
2	RV-CH-15B002E	1.5	2		480 VAC	CLASSIFIER ROTARY AIRLOCK	GEARMOTOR
3	RV-CH-15B001E	1.5	2		480 VAC	MILL INLET ROTARY AIRLOCK	GEARMOTOR
4	TK-CH-15B001	0.25	1/3		120 VAC	MILL MIST COLLECTION TANK DEMISTING MOTOR	LUBRICATION SYSTEMS, INC.
5	PM-CH-15B001E	0.06			120 VAC	MILL MOTOR SPACE HEATER	MARATHON
6	SV-1A-15B040E	0.2			120 VAC	MILL LUBE MIST SYSTEM SOLENOID VALVE	ASCO
7	SV-CW-15B003E	0.2			120 VAC	MILL BEARING HOUSING WATER JACKET SOLENOID VALVE	(BY CUSTOMER)

MILL NO. 2							
ITEM	EQUIPMENT NUMBER	KW	H.P.	RPM	VOLTAGE	DESCRIPTION	NOTES
8	PM-CH-15B001W	150	200	1800	480 VAC	MILL MOTOR	MARATHON, 1.15 SF
9	RV-CH-15B002W	1.5	2		480 VAC	CLASSIFIER ROTARY AIRLOCK	GEARMOTOR
10	RV-CH-15B001W	1.5	2		480 VAC	MILL INLET ROTARY AIRLOCK	GEARMOTOR
11	PM-CH-15B001W	0.06			120 VAC	MILL MOTOR SPACE HEATER	MARATHON
12	SV-1A-015B040W	0.2			120 VAC	MILL LUBE MIST SYSTEM SOLENOID VALVE	ASCO
13	SV-CW-15B003W	0.2			120 VAC	MILL BEARING HOUSING WATER JACKET SOLENOID VALVE	(BY CUSTOMER)
	TOTAL	307.17					

REVISION NO. 1- MILL SPEED 1800 RPM, ADDED COAL FEED ROTARY AIRLOCKS, DELETED TRAMP IRON GATE SOLENOID VALVES (050699)

REVISION NO. 2- DELETED CONTROL DAMPER ACTUATORS (050996)

REVISION NO. 3- ADDED EQUIPMENT NUMBERS; ADDED MILL MOTOR SPACE HEATERS

REVISION NO. 4- CHANGED MILL HP FROM 150 TO 200; ADDED MILL BEARING HOUSING WATER JACKET SOLENOID VALVE (BY OTHERS).



**INSTRUMENT-I/O LIST**  
NYSEG/KODAK MICRONIZED COAL REBURNING PROJECT  
NEW YORK, U.S.A.

REVISION 4 - JULY 26, 1996  
CONTRACT No. 96-11028-745  
DOCUMENT No. 8.700864

PREPARED BY: JB  
CHECKED BY: LJS  
FULLER MINERAL PROCESSING, INC.  
3235 SCHOENERSVILLE ROAD  
BETHLEHEM, PA 18016-0810  
TEL. 610-264-6900  
FAX. 610-264-6347

 FULLER MINERAL PROCESSING, INC.
<b>CERTIFIED FOR CONSTRUCTION</b>
SIGNATURE <i>Lawrence J. Dupon</i>
DATE: JUL 30 1996

INSTRUMENT-I/O LIST  
 NYSEG/ KODAK MICRONIZED COAL REBURNING PROJECT  
 NEW YORK, U.S.A.  
 CONTRACT No. 96-1102B-745  
 DOCUMENT No. 8.700864  
 REVISION 4 - JULY 26, 1996

ITEM	EQUIPMENT REF. NUMBER	I/O	DESCRIPTION	INSTRUMENT	STATUS	ENG. UNIT	MIN	MAX	ALARM		TRIP		MANUFACTURER	MODEL NO.
									HIGH	LOW	HI-HI	LO-LO		
COAL MILL NO. 1														
1	TE-CH-15B04E	AI	MILL UPPER BEARING TEMPERATURE	RTD	mV	DEG. F	0	400	170				200	THERMOCOUPLE TECHNOLOGY 100 Ω PT @ 0 DEG C. ε = 0.00385 Ω/DEG C
2	TE-CH-15B04E	AI	MILL LOWER BEARING TEMPERATURE	RTD	mV	DEG. F	0	400	170				200	THERMOCOUPLE TECHNOLOGY 100 Ω PT @ 0 DEG C. ε = 0.00385 Ω/DEG C
3	SS-CH-15B04E	DI	MILL MOTOR ZERO SPEED	PROXIMITY SWITCH	0							X		PERPERL + FUCHS NCN1.5-30GM60-ZO
4	VT-CH-15B001E	AI	MILL VIBRATION	VIBRATION TRANSMITTER	4-20mA	IN/SEC	0	1	0.4 FOR 10 MIN.				0.75	BALMAC 191-1
5	PS-1A-15B003E	DI	MILL LUBE SYSTEM AIR PRESSURE LOW	PRESSURE SWITCH	0	PSIG	0	120				44		ASCO TRANSducer TF10A21
6	LS-CH-15B001E	DI	MILL LUBE SYSTEM LEVEL LOW	LEVEL SWITCH	0					X		X FOR 10 MIN.		VM40XCXC LUBRICATION SYSTEMS
7	SS-CH-15B002E	DI	CLASSIFIER ROTARY AIRLOCK ZERO SPEED	MOTION SWITCH	0							X		DIVAC DIVAC
8	SS-CH-15B001E	DI	MILL INLET ROTARY AIRLOCK ZERO SPEED	MOTION SWITCH	0							X		DIVAC DIVAC
9	FT-TG-15B02AE	AI	MILL INLET AIR FLOW	AIR MONITOR VOLTI-PROBE W/ VEI/IRON DPT TRANSMITTER	4-20mA	ACFM	0	4700				2425		AIR MONITOR
10	ZSC-CH-15B012E	DI	TRAMP IRON GATE POSITION (CLOSED)	POSITION SWITCH	1									BRAY SERIES 50

INSTRUMENT-I/O LIST  
 NYSEG/ KODAK MICRONIZED COAL REBURNING PROJECT  
 NEW YORK, U.S.A.  
 CONTRACT No. 94-1102-7/5  
 DOCUMENT No. 870884  
 REVISION 4 - JULY 26, 1996

ITEM	EQUIPMENT REF. NUMBER	I/O	DESCRIPTION	INSTRUMENT	STATUS	ENG. UNIT	MIN	MAX	ALARM		TRIP		MANUFACTURER	MODEL NO.
									HIGH	LOW	HI-HI	LO-LO		
11	SV-1A-15B040E	DO	OPEN COMPRESSED AIR SOLENOID FOR MILL LUBE	SOLENOID	1								ASCO	8210G1
12	CZ-TG-15B002E	AO	MILL INLET AIR DAMPER SP	PNEUMATIC ACTUATOR	4-20 mA	%	0	100					AUTOMAX	
13	ZSC-TG-15B002E	DI	MILL INLET AIR DAMPER (CLOSED)	POSITION SWITCH	1								MICROSWITCH	TYPE 1 & 2
14	ZSO-TG-15B002E	DI	MILL INLET AIR DAMPER (OPEN)	POSITION SWITCH	1								MICROSWITCH	TYPE 1 & 2
15	SV-CW-15B003E	DO	START BEARING HOUSING WATER JACKET COOLING SYST.	SOLENOID	1								(BY CUSTOMER)	(BY CUSTOMER)
16	FS-CW-15B001E	DI	BEARING HOUSING WATER FLOW OK	FLOW SWITCH	1	GRM	0	10			3		(BY CUSTOMER)	(BY CUSTOMER)
COAL MILL NO. 2														
17	TE-CH-15B048W	AI	MILL UPPER BEARING TEMPERATURE	RTD	mV	DEG. F	0	400	170		200		THERMOCOUPLE TECHNOLOGY	100 Q PT @ 0 DEG C e = 0.00385 D/D/DEG C
18	TE-CH-15B049W	AI	MILL LOWER BEARING TEMPERATURE	RTD	mV	DEG. F	0	400	170		200		THERMOCOUPLE TECHNOLOGY	100 Q PT @ 0 DEG C e = 0.00385 D/D/DEG C
19	SS-CH-15B004W	DI	MILL MOTOR ZERO SPEED	PROXIMITY SWITCH	0						X		PEPPERL + FUCHS	MCN15-30GM/60-ZO
20	VT-CH-15B001W	AI	MILL VIBRATION	VIBRATION TRANSMITTER	4-20mA	IN/SEC			0.4 FOR 10 MIN		0.75		BALMAC	191-1

INSTRUMENT-I/O LIST  
 NYSEG/ KODAK MICRONIZED COAL REBURNING PROJECT  
 NEW YORK, U.S.A.  
 CONTRACT No. 54-11028-745  
 DOCUMENT No. 8.700864  
 REVISION 4 - JULY 24, 1996

ITEM	EQUIPMENT REF. NUMBER	I/O	DESCRIPTION	INSTRUMENT	STATUS	ENG. UNIT	MIN	MAX	ALARM		TRIP		MANUFACTURER	MODEL NO.
									HIGH	LOW	HI-HI	LO-LO		
21	PS-1A-15B003W	DI	MILL LUBE SYSTEM AIR PRESSURE LOW	PRESSURE SWITCH	0	PSIG	0	120				44	ASCO	TRANSDUCER TF10A21
22	LS-CH-15B001W	DI	MILL LUBE SYSTEM LEVEL LOW	LEVEL SWITCH	0					X			X-FOR 10 MIN.	VM40XCXC
23	SS-CH-15B002W	DI	CLASSIFIER ROTARY AIRLOCK ZERO SPEED	MOTION SWITCH	0							X	DIVAC	
24	SS-CH-15B001W	DI	MILL INLET ROTARY AIR LOCK ZERO SPEED	MOTION SWITCH	0							X	DIVAC	
25	FT-TG-15B026W	AI	MILL INLET AIR FLOW	AIR MONITOR VOLU-PROBE W/VEL/IRON DPT TRANSMITTER	4-20mA	ACFM	0	4700		2775		2425	AIR MONITOR	
26	ZSC-CH-15B012W	DI	TRAMP IRON GATE POSITION (CLOSED)	POSITION SWITCH	1								BRAY	SERIES 50
27	SV-1A-15B040W	DO	OPEN COMPRESSED AIR SOLENOID FOR MILL LUBE	SOLENOID	1								ASCO	8210G1
28	CZ-TG-15B002W	AO	MILL INLET AIR DAMPER SP	PNEUMATIC ACTUATOR	4-20 mA	%	0	100					AUTOMAX	
29	ZSC-TG-15B002W	DI	MILL INLET AIR DAMPER (CLOSED)	POSITION SWITCH	1								MICROSWICH	TYPE 1 & 2
30	ZSC-TG-15B002W	DI	MILL INLET AIR DAMPER (OPEN)	POSITION SWITCH	1								MICROSWICH	TYPE 1 & 2
31	SV-CW-15B003W	DO	START BEARING HOUSING WATER JACKET COOLING SYST.	SOLENOID	1								(BY CUSTOMER)	(BY CUSTOMER)

**INSTRUMENT-I/O LIST**  
 NYSEG/ KODAK MICRONIZED COAL REBURNING PROJECT  
 NEW YORK, U.S.A.  
 CONTRACT No. 96-1102-7/5  
 DOCUMENT No. 8.700864  
 REVISION 4 - JULY 26, 1996

ITEM	EQUIPMENT REF. NUMBER	I/O	DESCRIPTION	INSTRUMENT	STATUS	ENG. UNIT	MIN	MAX	ALARM			TRIP	MANUFACTURER	MODEL NO.
									HIGH	LOW	H-BIT			
32	FS-CW/15B001W	DI	BEARING HOUSING WATER FLOW OK	FLOW SWITCH	1	GPM	0	10				3	(BY CUSTOMER)	(BY CUSTOMER)
Recommended Software Interlocks														
			PERMISSIVE TO START MILL CIRCUIT #1											
			PERMISSIVE TO START MILL CIRCUIT #2											
			REQUEST TO START F.D. FAN #1											
			REQUEST TO START F.D. FAN #2											
			F.D. FAN #1 RUNNING											
			F.D. FAN #2 RUNNING											
			BURNER SYSTEM OK											
			CLASSIFIER #1 EXIT TEMPERATURE		4-20 mA	DEG F	0	300						
			CLASSIFIER #2 EXIT TEMPERATURE		4-20 mA	DEG F	0	300						
			PERMISSIVE TO START COAL FEED SCREW #1											
			PERMISSIVE TO START COAL FEED SCREW #2											

**INSTRUMENT-I/O LIST**  
**NYSEG/ KODAK MICRONIZED COAL REBURNING PROJECT**  
 NEW YORK, U.S.A.  
 CONTRACT No. 96-1028-745  
 DOCUMENT No. 8.7/00864  
 REVISION 4 - JULY 26, 1996

ITEM	EQUIPMENT REF. NUMBER	I/O	DESCRIPTION	INSTRUMENT	STATUS	ENG. UNIT	MIN	MAX	ALARM		TRIP		MANUFACTURER	MODEL NO.
									HIGH	LOW	HI-HI	LO-LO		
Suggested Signals (by Customer)														
			MILL #1 AMPS		4-20 mA	% IFL	0	120						
			MILL #2 AMPS		4-20 mA	% IFL	0	120						
REVISION NO. 1- ADDED INSTRUMENT DETAIL S. DELETED CLASSIFIER OUTLET TEMPERATURE ELEMENT, ADDED SPEED SWITCH FOR COAL FEED ROTARY AIRLOCK (050696)														
REVISION NO. 2- ADDED A/AO FOR DAMPER POSITION SETPOINT AND FEEDBACK, ADDED DO FOR COMPRESSED AIR MILL LUBE SOLENOID VALVE. ADDED RECOMMENDED INTERACE SIGNALS AND SUGGESTED SIGNALS.														
REVISION NO. 3- ADDED EQUIPMENT REFERENCE NUMBERS AND INLET DAMPER POSITION SWITCH														
REVISION NO. 4- ADDED MILL BEARING HOUSING WATER JACKET SOLENOID VALVE AND FLOW SWITCH (BOTH BY CUSTOMER)														

FUJIER PC COUNT TOTALS:  
 AI 5  
 AO 1  
 DI 18  
 DO 4

NOTE: 1. NO MOTOR I/O IS INCLUDED.

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

In general all equipment may be operated in individual manual mode to permit maintenance testing of the equipment. If any equipment is operated in this manner, automatic operation of the group to which the piece of equipment belongs will not be permitted. Similarly, once an equipment group is selected for automatic group mode of operation, an individual piece of equipment cannot be operated in individual manual mode of operation.

When a piece of equipment is operated in its individual manual operating mode, only protection and personnel safety interlocks are operable.

The following sections in this document describe the operation of each of the micro mills in the following situations:

Normal Startup

Normal Operation

Normal Shutdowns

Abnormal Shutdowns

Emergency Shutdowns

For clarification of the process description, refer to the following Fuller drawings which show the process flow information for the system:

1.724705, Rev. 0

1.724706, Rev. 0

1.724707, Rev. 1

1.724708, Rev. 1

1.725164, Rev. 0

**C. Normal Startup of The Coal Milling System**

*Since both the Micromill circuits operate in the same manner, the operation described herein is for the Mill No. 1 circuit only. The operation of the second mill is identical.*

NOTE: For normal startup of the mill to proceed, it is necessary that the plant's compressed air supply (for the Mill seal air and lube mist system) and instrument air supply (for the control valve air) be fully available at the required pressure and volume. The plant cooling water supply (for the Mill Bearing Housing Water Jacket) should also be fully available at the required temperature and flow. In addition, the boiler must be in its normal operating state and ready to accept Micronized coal through the new burners. Finally, the Mill Tramp iron gate must be closed as sensed by limit switch [ZSC-CH-15B012E].

The Micromill startup proceeds in the sequence described in the following paragraphs:

When the boiler is ready to accept Micronized coal through the new burners and the Transport Gas Fan is running, an alarm bell (by others) will ring for seven (7) seconds to notify anyone near the system of the pending start of the Coal Milling System.

First the Mill Air Supply Solenoid Valve [SV-1A-15B040E] is energized, establishing the Mill Labyrinth Air Seal System, starting the Mill Mist Lubrication System, and simultaneously starting the Mill Lube Mist Demister Unit [TK-CH-15B001]. At the same time that the Mill Air Supply Solenoid Valve [SV-1A-15B040E] is energized, the Mill Bearing Housing Water Jacket solenoid [SV-CW-15B003E, by others] is energized, initiating the closed loop water cooling system for the bearing housing.

After the Labyrinth Seal and Lube System compressed air pressure is above the minimum required pressure (44 psi) as sensed by pressure switch [PS-1A-15B003E], the Tramp Iron Gate is closed as sensed by its position switch [ZSC-CH-15B012E], and the Mill Bearing Housing Water Jacket water circulation is above 3 gpm as sensed

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

by the flow switch [FS-CW-15B001E, by others] being not low, the Mill Inlet Damper [CZ-TG-15B002E] is moved to the fully open position.

After the Mill Inlet Damper [CZ-TG-15B002E] is in its fully open position as sensed by position switch [ZSO-TG-15B002E], the Mill Mist Lube System oil level [LS-CH-15B001E] is not low, the Mill Mist Lube System air pressure [PS-1A-15B003E] is not low, the Mill upper/lower bearing temperatures [TE-CH-15B048E/TE-CH-15B049E] are not HI-HI, and the Mill vibration [VT-CH-15B001E] is not HI-HI (there is a thirty (30) second bypass of vibration monitor during the mill start-up), and three (3) minutes have elapsed since the Mill air supply Solenoid Valve [SV-1A-15B040E] was energized, the Mill [PM-CH-15B001E] motor is started.

Seventy-five (75) seconds (to allow the mill to ramp up to speed) after starting the Mill [PM-CH-15B001E] motor, as sensed by motion switch [SS-CH-15B004E] not indicating zero speed, the Mill Classifier Rotary Feeder [RV-CH-15B002E] is started.

After the Mill Classifier Rotary Feeder [RV-CH-15B002E] is started, as sensed by motion switch [SS-CH-15B002E] not indicating zero speed, the automatic airflow control portion of the circuit is placed in its normal operating configuration.

Once the Classifier Outlet Temperature [TE-CH-15B050E] (by others) reaches 150°F, at least one hundred twenty five (125) seconds have elapsed since the starting of the Classifier Rotary Feeder [RV-CH-15B002E] as sensed by the motion switch [SS-CH-15B002E] not indicating zero speed, and the oxygen content of the transport gas as sensed by the customer's oxygen analyzer is below eight percent, the Mill Inlet Rotary Feeder [RV-CH-15B001E] is started.

After the Mill Inlet Rotary Feeder [RV-CH-15B001E] is started, as sensed by motion switch [SS-CH-15B003E] not indicating zero speed, the Coal Feed Screw Conveyor (by others) can be started to introduce material flow to the Coal Milling System.

*Note: the coal feed screw conveyor (by others) should start at a maximum set point of roughly 50% mill maximum capacity.*

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

**D. Normal Operation of the Coal Milling System**

Once the System has been started in the manner described in section C, normal operation consists of controlling the following:

The air flow rate into the Mill

The material feed rate into the Mill circuit (by others)

The air flow rate into the mill is controlled by the operation of the Mill Air Inlet Damper [CZ-TG-15B002E]. The control loop consists of a flow indicating controller that permits the operator to set a mill inlet air flow rate set point.

In normal operation, the flow rate at full load is set at 3460 ACFM; however, this value will be verified and adjusted during startup testing of the mill, and a table of mill inlet air flow rates will be prepared for use by the operators.

The feed rate of material into the mill circuit is manually adjusted by the operator.

*Note: during startup the maximum mill capacity will be determined, and a table of mill operating points will be established by Fuller.*

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

**E. Normal Shutdown of The Coal Milling System**

A normal shutdown of the Coal Milling System is a sequenced shutdown of the System, and is either initiated by the system operator, or automatically initiated by one of the following conditions:

Mill Mist Lube System oil level low, as sensed by level switch [LS-CH-15B001E], persisting for a period of 10 minutes or longer

High Mill vibration [VT-CH-15B001E] (in excess of 0.4 in./sec.) which persists for 10 minutes or longer

When normal shutdown is initiated, the shutdown proceeds as described below:

The Coal Feed Screw Conveyor (by others) is stopped to cut-off material flow to the Coal Milling System

Ten seconds after The Coal Feed Screw Conveyor (by others) is stopped, the mill inlet rotary feeder [RV-CH-15B001E], as sensed by motion switch [SS-CH-15B001E] indicating zero speed, is stopped

Once the mill inlet rotary feeder [RV-CH-15B001E] is stopped, as sensed by motion switch [SS-CH-15B001E] indicating zero speed, and after a 10 minute time delay to purge the system, the Classifier Rotary Feeder [RV-CH-15B002E] is stopped

Ten seconds after the Classifier Rotary Feeder [RV-CH-15B002E] is stopped, as sensed by motion switch [SS-CH-15B002E] indicating zero speed, the Mill [PM-CH-15B001E] is stopped

Ten seconds after the mill [PM-CH-15B001E] stop is initiated, the Mill Inlet Damper [CZ-TG-15B002E] is closed

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

After the Mill Inlet Damper [CZ-TG-15B002E] is closed, as sensed by its position switch [ZSC-TG-15B002E], and the mill [PM-CH-15B001E] is stopped, as sensed by motion switch [SS-CH-15B004E] indicating zero speed, the Mill Compressed Air System Valve (to the Mill Mist Lube System) is closed by de-energizing Solenoid Valve [SV-1A-15B040E], the Mill Bearing Housing Water Jacket solenoid [SV-CW-15B003E, by others] is de-energized, and the Mill Lube Mist Demister [TK-CH-15B001] is stopped. **Note: If Mill No. 2 circuit is running, the Mill Lube Mist Demister is left running.**

The de-energizing of Solenoid Valves [SV-1A-15B040E] and [SV-CW-15B003E] completes the normal shutdown of the Coal Milling System.

Note: The Transport Gas Fan, supplying air to the mill systems, may only be stopped during a shutdown of the boiler. When a coal milling system is shutdown and the boiler is operating, the transport gas will by-pass the mill system to provide cooling air to the burners.

**F. Abnormal Shutdowns Of The Coal Milling System.**

Abnormal shutdowns are those unplanned shutdowns of the system caused by either isolated process or equipment abnormalities, activation of individual equipment safety devices, or automatic activation of personnel safety systems.

Abnormal shutdowns caused by isolated process or equipment abnormalities or activation of individual safety devices will cause the immediate stopping of the affected piece of equipment and will stop all upstream equipment in a cascade fashion. Equipment downstream of the faulted piece of equipment or point at which the abnormality occurs will continue in normal operation.

- 3 In an abnormal shutdown, the mill circuit **MUST** cool down for a period of one hour prior to the opening of any equipment or ductwork ports, flanges, or (tramp iron) cleanout gates by maintenance personnel. This will prevent injury from high temperatures and reduce the danger of introducing excess oxygen into the system, which could feasibly lead to fires or explosions.

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

If, during normal operation of the Coal Milling System, any of the following systems or equipment is activated, all equipment in the System will be stopped without any intentional time delays to allow for equipment clean out and deceleration:

If at any time the boiler becomes unable to continue to receive Micronized coal through the new burners

Transport Gas Fan not running (by others)

Mill air supply system Low (< 44 psi), as sensed by pressure switch [PS-1A-15B003E]

Tramp iron gate not closed, as sensed by limit switch [ZSC-CH-15B012E].

Mill vibration [VT-CH-15B001E] high-high (0.75 in./sec)

Mill upper bearing temperature HI-HI, as sensed by temperature element [TE-CH-15B048E]

Mill lower bearing temperature HI-HI, as sensed by temperature element [TE-CH-15B049E]

During normal operation of the Coal Milling System, if the Mill [PM-CH-15B001E] Motor stalls, as sensed by motion switch [SS-CH-15B004E] indicating zero speed, the following equipment is stopped in the sequence indicated without any intentional time delays to allow for equipment clean out and deceleration:

Coal Feed Screw Conveyor (by others).

Mill Inlet Rotary Feeder [RV-CH-15B001E]

Classifier Rotary Airlock [RV-CH-15B002E]

**PROCESS DESCRIPTION - NYSEG/KODAK MICRONIZED COAL RE-BURNING PROJECT**

During normal operation of the Coal Milling System, if the Classifier Rotary Feeder [RV-CH-15B002E] stalls, as sensed by motion switch [SS-CH-15B002E] indicating zero speed, the following equipment is stopped in the sequence indicated without any intentional time delays to allow for equipment clean out and deceleration:

Coal Feed Screw Conveyor (by others)

Mill Inlet Rotary Feeder [RV-CH-15B001E]

During normal operation of the Coal Milling System, if the Mill Inlet Rotary Feeder [RV-CH-15B001E] stalls, as sensed by motion switch [SS-CH-15B001E] indicating zero speed, the following equipment is stopped in the sequence indicated without any intentional time delays to allow for equipment clean out and deceleration:

Coal Feed Screw Conveyor (by others)

During normal operation of the Coal Milling System, if the Mill Inlet Air flow falls below 2425 ACFM or the oxygen content of the transport gas exceeds eight percent (as sensed by the customer's oxygen analyzer), the following equipment is stopped in the sequence indicated without any intentional time delays to allow for equipment clean out and deceleration:

Coal Feed Screw Conveyor (by others)

Mill Inlet Rotary Feeder [RV-CH-15B001E]

*Note: After an abnormal shutdown as detailed in the above case, the mill circuit can be restarted once the airflow returns to its normal operating point and the oxygen content in the Mill falls below 7.5 percent. The coal feed screw conveyor should start at its minimum set point, and the circuit brought back to maximum capacity.*

During normal operation of the Coal Milling System, if the Mill Bearing Housing Water Jacket water circulation is less than 3 gpm as sensed by the flow switch [FS-CW-15B001E, by others]:

**"ALARM ONLY"**

During normal operation of the Coal Milling System, if the classifier outlet temperature (by others) falls below 140°F:

**"ALARM ONLY"**


Note: if the alarm persists, it is recommended that the operator use his discretion whether to "cut-back" or "cut-off" the coal feed.

**G. Emergency Shutdowns Of The Coal Milling System.**


Emergency shutdowns will cause the immediate and simultaneous shutdown of the entire Coal Milling System.

Any emergency shutdowns of the entire Coal Milling System shall be at the discretion of the customer.

- 3 In an emergency shutdown, the mill circuit MUST cool down for a period of one hour prior to the opening of any equipment or ductwork ports, flanges, or (tramp iron) cleanout gates by maintenance personnel. This will prevent injury from high temperatures and reduce the danger of introducing excess oxygen into the system, which could feasibly lead to fires or explosions.



D03115-331-015



PLAN AT EL. 234'-6"


DATE: 4/17/78  
 DRAWN BY: [Name]  
 CHECKED BY: [Name]

NO.	DESCRIPTION	DATE	BY	CHKD.
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				


EASTMAN KODAK COMPANY  
 KODAK PARK DIVISION  
 31  
 GENERAL ARRANGEMENT  
 MICROINIZER BLDG ADDITION  
 FLOOR EL. 234'-6"  
 KPE  
 D03115-331-015



10-131-331-017



SECTION A-A



SECTION D-D

DATE: 06/20/06  
 PROJECT: 331017296  
 SHEET: 03115-331-017


NO.	REVISION	DATE	BY	CHKD.
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				

GILBERT/COMMERCIAL, INC.  
 ARCHITECT  
 3/18'-11'-0"  
 ACAD/ D  
 EASTMAN KODAK COMPANY  
 KODAK PARK DIVISION  
 31  
 KPE

GENERAL ARRANGEMENT  
 MICRONIZER BLDG ADICTION  
 SECTION A-A & SECTION D-D  
 10-131-331-017




































NO.	DESCRIPTION	DATE	BY	CHECKED
1	ISSUED FOR CONSTRUCTION	1/17/51	J. W. HARRIS	D. J. HARRIS
2	REVISION			
3	REVISION			
4	REVISION			
5	REVISION			
6	REVISION			
7	REVISION			
8	REVISION			
9	REVISION			
10	REVISION			
11	REVISION			
12	REVISION			
13	REVISION			
14	REVISION			
15	REVISION			
16	REVISION			
17	REVISION			
18	REVISION			
19	REVISION			
20	REVISION			

NOTES:  
1. SEE GENERAL NOTES FOR ADDITIONAL INFORMATION.  
2. THIS DRAWING IS TO BE USED IN CONNECTION WITH THE GENERAL CONTRACTING DRAWINGS.

SECTION 16-16  
SECTION 16-16










BEAM AND CHANNEL END CONNECTIONS

NOTES  
 1. END CONNECTIONS SHALL BE MADE IN ACCORDANCE WITH THE LATEST EDITIONS OF THE AISC SPECIFICATIONS FOR STRUCTURAL STEEL BUILDINGS AND THE AISC CODE OF PRACTICE FOR CONNECTIONS OF STRUCTURAL STEEL BUILDINGS.



END CONNECTION IDENTIFICATION



END CONNECTION DETAILS AND TYPES



CHANNEL COPES

TYPE	SIZE	DEPTH	WEIGHT PER FOOT
C1	1 1/2	1 1/2	3.2
C2	2	2	5.3
C3	2 1/2	2 1/2	7.8
C4	3	3	10.9
C5	3 1/2	3 1/2	14.0
C6	4	4	18.8
C7	4 1/2	4 1/2	24.0
C8	5	5	30.9
C9	5 1/2	5 1/2	38.8
C10	6	6	48.5


BEAM BLOCKS

TYPE	SIZE	DEPTH	WEIGHT PER FOOT
B1	4	4	18.8
B2	4 1/2	4 1/2	24.0
B3	5	5	30.9
B4	5 1/2	5 1/2	38.8
B5	6	6	48.5
B6	6 1/2	6 1/2	58.8
B7	7	7	70.0
B8	7 1/2	7 1/2	82.8
B9	8	8	96.0
B10	8 1/2	8 1/2	110.4
B11	9	9	126.0
B12	9 1/2	9 1/2	142.8
B13	10	10	160.8
B14	10 1/2	10 1/2	180.0
B15	11	11	199.2
B16	11 1/2	11 1/2	219.6
B17	12	12	240.0
B18	12 1/2	12 1/2	261.6
B19	13	13	283.2
B20	13 1/2	13 1/2	306.0
B21	14	14	329.6
B22	14 1/2	14 1/2	354.0
B23	15	15	379.2
B24	15 1/2	15 1/2	405.0
B25	16	16	431.2
B26	16 1/2	16 1/2	458.0
B27	17	17	485.2
B28	17 1/2	17 1/2	513.0
B29	18	18	541.2
B30	18 1/2	18 1/2	570.0
B31	19	19	599.2
B32	19 1/2	19 1/2	629.0
B33	20	20	659.2
B34	20 1/2	20 1/2	690.0
B35	21	21	721.2
B36	21 1/2	21 1/2	753.0
B37	22	22	785.2
B38	22 1/2	22 1/2	818.0
B39	23	23	851.2
B40	23 1/2	23 1/2	886.0
B41	24	24	921.2
B42	24 1/2	24 1/2	958.0
B43	25	25	995.2
B44	25 1/2	25 1/2	1034.0
B45	26	26	1073.2
B46	26 1/2	26 1/2	1114.0
B47	27	27	1155.2
B48	27 1/2	27 1/2	1198.0
B49	28	28	1241.2
B50	28 1/2	28 1/2	1286.0
B51	29	29	1331.2
B52	29 1/2	29 1/2	1378.0
B53	30	30	1425.2
B54	30 1/2	30 1/2	1474.0
B55	31	31	1523.2
B56	31 1/2	31 1/2	1574.0
B57	32	32	1625.2
B58	32 1/2	32 1/2	1678.0
B59	33	33	1731.2
B60	33 1/2	33 1/2	1786.0
B61	34	34	1841.2
B62	34 1/2	34 1/2	1898.0
B63	35	35	1955.2
B64	35 1/2	35 1/2	2014.0
B65	36	36	2073.2
B66	36 1/2	36 1/2	2134.0
B67	37	37	2195.2
B68	37 1/2	37 1/2	2258.0
B69	38	38	2321.2
B70	38 1/2	38 1/2	2386.0
B71	39	39	2451.2
B72	39 1/2	39 1/2	2518.0
B73	40	40	2585.2
B74	40 1/2	40 1/2	2654.0
B75	41	41	2723.2
B76	41 1/2	41 1/2	2794.0
B77	42	42	2865.2
B78	42 1/2	42 1/2	2938.0
B79	43	43	3011.2
B80	43 1/2	43 1/2	3086.0
B81	44	44	3161.2
B82	44 1/2	44 1/2	3238.0
B83	45	45	3315.2
B84	45 1/2	45 1/2	3394.0
B85	46	46	3473.2
B86	46 1/2	46 1/2	3554.0
B87	47	47	3635.2
B88	47 1/2	47 1/2	3718.0
B89	48	48	3801.2
B90	48 1/2	48 1/2	3886.0
B91	49	49	3971.2
B92	49 1/2	49 1/2	4058.0
B93	50	50	4145.2
B94	50 1/2	50 1/2	4234.0
B95	51	51	4323.2
B96	51 1/2	51 1/2	4414.0
B97	52	52	4505.2
B98	52 1/2	52 1/2	4598.0
B99	53	53	4691.2
B100	53 1/2	53 1/2	4786.0

TABLE 1



TYPICAL REMOVABLE HANDRAIL DETAIL




PLAN - CORNER DETAIL




NOTES  
 1. THIS CORNER DETAIL IS FOR REMOVABLE HANDRAILS.  
 2. THIS DETAIL IS TO BE USED IN CONNECTION WITH REMOVABLE HANDRAILS.

NO.	DESCRIPTION	QTY	UNIT	REVISION
1	...	...	...	...
2	...	...	...	...
3	...	...	...	...
4	...	...	...	...
5	...	...	...	...
6	...	...	...	...
7	...	...	...	...
8	...	...	...	...
9	...	...	...	...
10	...	...	...	...
11	...	...	...	...
12	...	...	...	...
13	...	...	...	...
14	...	...	...	...
15	...	...	...	...
16	...	...	...	...
17	...	...	...	...
18	...	...	...	...
19	...	...	...	...
20	...	...	...	...
21	...	...	...	...
22	...	...	...	...
23	...	...	...	...
24	...	...	...	...
25	...	...	...	...
26	...	...	...	...
27	...	...	...	...
28	...	...	...	...
29	...	...	...	...
30	...	...	...	...
31	...	...	...	...
32	...	...	...	...
33	...	...	...	...
34	...	...	...	...
35	...	...	...	...
36	...	...	...	...
37	...	...	...	...
38	...	...	...	...
39	...	...	...	...
40	...	...	...	...
41	...	...	...	...
42	...	...	...	...
43	...	...	...	...
44	...	...	...	...
45	...	...	...	...
46	...	...	...	...
47	...	...	...	...
48	...	...	...	...
49	...	...	...	...
50	...	...	...	...
51	...	...	...	...
52	...	...	...	...
53	...	...	...	...
54	...	...	...	...
55	...	...	...	...
56	...	...	...	...
57	...	...	...	...
58	...	...	...	...
59	...	...	...	...
60	...	...	...	...
61	...	...	...	...
62	...	...	...	...
63	...	...	...	...
64	...	...	...	...
65	...	...	...	...
66	...	...	...	...
67	...	...	...	...
68	...	...	...	...
69	...	...	...	...
70	...	...	...	...
71	...	...	...	...
72	...	...	...	...
73	...	...	...	...
74	...	...	...	...
75	...	...	...	...
76	...	...	...	...
77	...	...	...	...
78	...	...	...	...
79	...	...	...	...
80	...	...	...	...
81	...	...	...	...
82	...	...	...	...
83	...	...	...	...
84	...	...	...	...
85	...	...	...	...
86	...	...	...	...
87	...	...	...	...
88	...	...	...	...
89	...	...	...	...
90	...	...	...	...
91	...	...	...	...
92	...	...	...	...
93	...	...	...	...
94	...	...	...	...
95	...	...	...	...
96	...	...	...	...
97	...	...	...	...
98	...	...	...	...
99	...	...	...	...
100	...	...	...	...



NORTH ELEVATION



NORTH/SOUTH CROSS SECTION



EAST/WEST CROSS SECTION

NOTES:  
 1. THIS DRAWING IS TO BE USED IN CONNECTION WITH DRAWING E03115-110-001A

THIS DRAWING IS THE PROPERTY OF THE ARCHITECT. IT IS TO BE USED ONLY FOR THE PROJECT AND SITE SPECIFICALLY IDENTIFIED HEREON. IT IS NOT TO BE REPRODUCED, COPIED, OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF THE ARCHITECT.

DATE: 1/27/78  
 DRAWING AND CROSS SECTION  
 ARCHITECT: [Name]  
 PROJECT: [Name]  
 SHEET: 31  
 OF: 31

NO.	REVISION	DATE	BY	CHKD.
1	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
2	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
3	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
4	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
5	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
6	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
7	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
8	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
9	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
10	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
11	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
12	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
13	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
14	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
15	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
16	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
17	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
18	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
19	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
20	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
21	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
22	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
23	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
24	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
25	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
26	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
27	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
28	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
29	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
30	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]
31	ISSUED FOR PERMIT	1/27/78	[Name]	[Name]



NOTES:  
1. SEE DRAWING TO BE COMPLETED IN CONNECTION WITH DRAWING E03115-144-001A

NO.	DESCRIPTION	DATE	BY	CHECKED
1	ISSUED FOR CONSTRUCTION			
2	REVISION			
3	REVISION			
4	REVISION			
5	REVISION			
6	REVISION			
7	REVISION			
8	REVISION			
9	REVISION			
10	REVISION			
11	REVISION			
12	REVISION			
13	REVISION			
14	REVISION			
15	REVISION			
16	REVISION			
17	REVISION			
18	REVISION			
19	REVISION			
20	REVISION			

SECTION AND STATUS

NO. 31

DATE 1/17/77

BY [Signature]

CHECKED [Signature]


APPROVED [Signature]

REVISIONS


1. SEE DRAWING TO BE COMPLETED IN CONNECTION WITH DRAWING E03115-144-001A









E03115-333-019A




PLAN AT FL. 218'-6"



SECTION 1-1



SECTION 2-2




SECTION 3-3

NO.	REVISION	DATE	BY	CHECKED
1	ISSUED FOR CONSTRUCTION	11/15/77	...	...
2	...	...	...	...
3	...	...	...	...
4	...	...	...	...
5	...	...	...	...
6	...	...	...	...
7	...	...	...	...
8	...	...	...	...
9	...	...	...	...
10	...	...	...	...
11	...	...	...	...
12	...	...	...	...
13	...	...	...	...
14	...	...	...	...
15	...	...	...	...
16	...	...	...	...
17	...	...	...	...
18	...	...	...	...
19	...	...	...	...
20	...	...	...	...
21	...	...	...	...
22	...	...	...	...
23	...	...	...	...
24	...	...	...	...
25	...	...	...	...
26	...	...	...	...
27	...	...	...	...
28	...	...	...	...
29	...	...	...	...
30	...	...	...	...
31	...	...	...	...
32	...	...	...	...
33	...	...	...	...
34	...	...	...	...
35	...	...	...	...
36	...	...	...	...
37	...	...	...	...
38	...	...	...	...
39	...	...	...	...
40	...	...	...	...
41	...	...	...	...
42	...	...	...	...
43	...	...	...	...
44	...	...	...	...
45	...	...	...	...
46	...	...	...	...
47	...	...	...	...
48	...	...	...	...
49	...	...	...	...
50	...	...	...	...



6  
 1/8" = 1'-0"  
 1/4" = 1'-0"  
 1/2" = 1'-0"  
 3/4" = 1'-0"  
 1" = 1'-0"  
 1 1/4" = 1'-0"  
 1 1/2" = 1'-0"  
 2" = 1'-0"  
 3" = 1'-0"  
 4" = 1'-0"  
 6" = 1'-0"  
 8" = 1'-0"  
 10" = 1'-0"  
 12" = 1'-0"  
 14" = 1'-0"  
 16" = 1'-0"  
 18" = 1'-0"  
 20" = 1'-0"  
 24" = 1'-0"  
 30" = 1'-0"  
 36" = 1'-0"  
 42" = 1'-0"  
 48" = 1'-0"  
 54" = 1'-0"  
 60" = 1'-0"  
 72" = 1'-0"  
 84" = 1'-0"  
 96" = 1'-0"  
 108" = 1'-0"  
 120" = 1'-0"  
 144" = 1'-0"  
 168" = 1'-0"  
 192" = 1'-0"  
 216" = 1'-0"  
 240" = 1'-0"  
 270" = 1'-0"  
 300" = 1'-0"  
 360" = 1'-0"  
 420" = 1'-0"  
 480" = 1'-0"  
 540" = 1'-0"  
 600" = 1'-0"  
 720" = 1'-0"  
 840" = 1'-0"  
 960" = 1'-0"  
 1080" = 1'-0"  
 1200" = 1'-0"  
 1440" = 1'-0"  
 1680" = 1'-0"  
 1920" = 1'-0"  
 2160" = 1'-0"  
 2400" = 1'-0"  
 2700" = 1'-0"  
 3000" = 1'-0"  
 3600" = 1'-0"  
 4200" = 1'-0"  
 4800" = 1'-0"  
 5400" = 1'-0"  
 6000" = 1'-0"  
 7200" = 1'-0"  
 8400" = 1'-0"  
 9600" = 1'-0"  
 10800" = 1'-0"  
 12000" = 1'-0"  
 14400" = 1'-0"  
 16800" = 1'-0"  
 19200" = 1'-0"  
 21600" = 1'-0"  
 24000" = 1'-0"  
 27000" = 1'-0"  
 30000" = 1'-0"  
 36000" = 1'-0"  
 42000" = 1'-0"  
 48000" = 1'-0"  
 54000" = 1'-0"  
 60000" = 1'-0"  
 72000" = 1'-0"  
 84000" = 1'-0"  
 96000" = 1'-0"  
 108000" = 1'-0"  
 120000" = 1'-0"  
 144000" = 1'-0"  
 168000" = 1'-0"  
 192000" = 1'-0"  
 216000" = 1'-0"  
 240000" = 1'-0"  
 270000" = 1'-0"  
 300000" = 1'-0"  
 360000" = 1'-0"  
 420000" = 1'-0"  
 480000" = 1'-0"  
 540000" = 1'-0"  
 600000" = 1'-0"  
 720000" = 1'-0"  
 840000" = 1'-0"  
 960000" = 1'-0"  
 1080000" = 1'-0"  
 1200000" = 1'-0"  
 1440000" = 1'-0"  
 1680000" = 1'-0"  
 1920000" = 1'-0"  
 2160000" = 1'-0"  
 2400000" = 1'-0"  
 2700000" = 1'-0"  
 3000000" = 1'-0"  
 3600000" = 1'-0"  
 4200000" = 1'-0"  
 4800000" = 1'-0"  
 5400000" = 1'-0"  
 6000000" = 1'-0"  
 7200000" = 1'-0"  
 8400000" = 1'-0"  
 9600000" = 1'-0"  
 10800000" = 1'-0"  
 12000000" = 1'-0"  
 14400000" = 1'-0"  
 16800000" = 1'-0"  
 19200000" = 1'-0"  
 21600000" = 1'-0"  
 24000000" = 1'-0"  
 27000000" = 1'-0"  
 30000000" = 1'-0"  
 36000000" = 1'-0"  
 42000000" = 1'-0"  
 48000000" = 1'-0"  
 54000000" = 1'-0"  
 60000000" = 1'-0"  
 72000000" = 1'-0"  
 84000000" = 1'-0"  
 96000000" = 1'-0"  
 108000000" = 1'-0"  
 120000000" = 1'-0"  
 144000000" = 1'-0"  
 168000000" = 1'-0"  
 192000000" = 1'-0"  
 216000000" = 1'-0"  
 240000000" = 1'-0"  
 270000000" = 1'-0"  
 300000000" = 1'-0"  
 360000000" = 1'-0"  
 420000000" = 1'-0"  
 480000000" = 1'-0"  
 540000000" = 1'-0"  
 600000000" = 1'-0"  
 720000000" = 1'-0"  
 840000000" = 1'-0"  
 960000000" = 1'-0"  
 1080000000" = 1'-0"  
 1200000000" = 1'-0"  
 1440000000" = 1'-0"  
 1680000000" = 1'-0"  
 1920000000" = 1'-0"  
 2160000000" = 1'-0"  
 2400000000" = 1'-0"  
 2700000000" = 1'-0"  
 3000000000" = 1'-0"  
 3600000000" = 1'-0"  
 4200000000" = 1'-0"  
 4800000000" = 1'-0"  
 5400000000" = 1'-0"  
 6000000000" = 1'-0"  
 7200000000" = 1'-0"  
 8400000000" = 1'-0"  
 9600000000" = 1'-0"  
 10800000000" = 1'-0"  
 12000000000" = 1'-0"  
 14400000000" = 1'-0"  
 16800000000" = 1'-0"  
 19200000000" = 1'-0"  
 21600000000" = 1'-0"  
 24000000000" = 1'-0"  
 27000000000" = 1'-0"  
 30000000000" = 1'-0"  
 36000000000" = 1'-0"  
 42000000000" = 1'-0"  
 48000000000" = 1'-0"  
 54000000000" = 1'-0"  
 60000000000" = 1'-0"  
 72000000000" = 1'-0"  
 84000000000" = 1'-0"  
 96000000000" = 1'-0"  
 108000000000" = 1'-0"  
 120000000000" = 1'-0"  
 144000000000" = 1'-0"  
 168000000000" = 1'-0"  
 192000000000" = 1'-0"  
 216000000000" = 1'-0"  
 240000000000" = 1'-0"  
 270000000000" = 1'-0"  
 300000000000" = 1'-0"  
 360000000000" = 1'-0"  
 420000000000" = 1'-0"  
 480000000000" = 1'-0"  
 540000000000" = 1'-0"  
 600000000000" = 1'-0"  
 720000000000" = 1'-0"  
 840000000000" = 1'-0"  
 960000000000" = 1'-0"  
 1080000000000" = 1'-0"  
 1200000000000" = 1'-0"  
 1440000000000" = 1'-0"  
 1680000000000" = 1'-0"  
 1920000000000" = 1'-0"  
 2160000000000" = 1'-0"  
 2400000000000" = 1'-0"  
 2700000000000" = 1'-0"  
 3000000000000" = 1'-0"  
 3600000000000" = 1'-0"  
 4200000000000" = 1'-0"  
 4800000000000" = 1'-0"  
 5400000000000" = 1'-0"  
 6000000000000" = 1'-0"  
 7200000000000" = 1'-0"  
 8400000000000" = 1'-0"  
 9600000000000" = 1'-0"  
 10800000000000" = 1'-0"  
 12000000000000" = 1'-0"  
 14400000000000" = 1'-0"  
 16800000000000" = 1'-0"  
 19200000000000" = 1'-0"  
 21600000000000" = 1'-0"  
 24000000000000" = 1'-0"  
 27000000000000" = 1'-0"  
 30000000000000" = 1'-0"  
 36000000000000" = 1'-0"  
 42000000000000" = 1'-0"  
 48000000000000" = 1'-0"  
 54000000000000" = 1'-0"  
 60000000000000" = 1'-0"  
 72000000000000" = 1'-0"  
 84000000000000" = 1'-0"  
 96000000000000" = 1'-0"  
 108000000000000" = 1'-0"  
 120000000000000" = 1'-0"  
 144000000000000" = 1'-0"  
 168000000000000" = 1'-0"  
 192000000000000" = 1'-0"  
 216000000000000" = 1'-0"  
 240000000000000" = 1'-0"  
 270000000000000" = 1'-0"  
 300000000000000" = 1'-0"  
 360000000000000" = 1'-0"  
 420000000000000" = 1'-0"  
 480000000000000" = 1'-0"  
 540000000000000" = 1'-0"  
 600000000000000" = 1'-0"  
 720000000000000" = 1'-0"  
 840000000000000" = 1'-0"  
 960000000000000" = 1'-0"  
 1080000000000000" = 1'-0"  
 1200000000000000" = 1'-0"  
 1440000000000000" = 1'-0"  
 1680000000000000" = 1'-0"  
 1920000000000000" = 1'-0"  
 2160000000000000" = 1'-0"  
 2400000000000000" = 1'-0"  
 2700000000000000" = 1'-0"  
 3000000000000000" = 1'-0"  
 3600000000000000" = 1'-0"  
 4200000000000000" = 1'-0"  
 4800000000000000" = 1'-0"  
 5400000000000000" = 1'-0"  
 6000000000000000" = 1'-0"  
 7200000000000000" = 1'-0"  
 8400000000000000" = 1'-0"  
 9600000000000000" = 1'-0"  
 10800000000000000" = 1'-0"  
 12000000000000000" = 1'-0"  
 14400000000000000" = 1'-0"  
 16800000000000000" = 1'-0"  
 19200000000000000" = 1'-0"  
 21600000000000000" = 1'-0"  
 24000000000000000" = 1'-0"  
 27000000000000000" = 1'-0"  
 30000000000000000" = 1'-0"  
 36000000000000000" = 1'-0"  
 42000000000000000" = 1'-0"  
 48000000000000000" = 1'-0"  
 54000000000000000" = 1'-0"  
 60000000000000000" = 1'-0"  
 72000000000000000" = 1'-0"  
 84000000000000000" = 1'-0"  
 96000000000000000" = 1'-0"  
 108000000000000000" = 1'-0"  
 120000000000000000" = 1'-0"  
 144000000000000000" = 1'-0"  
 168000000000000000" = 1'-0"  
 192000000000000000" = 1'-0"  
 216000000000000000" = 1'-0"  
 240000000000000000" = 1'-0"  
 270000000000000000" = 1'-0"  
 300000000000000000" = 1'-0"  
 360000000000000000" = 1'-0"  
 420000000000000000" = 1'-0"  
 480000000000000000" = 1'-0"  
 540000000000000000" = 1'-0"  
 600000000000000000" = 1'-0"  
 720000000000000000" = 1'-0"  
 840000000000000000" = 1'-0"  
 960000000000000000" = 1'-0"  
 1080000000000000000" = 1'-0"  
 1200000000000000000" = 1'-0"  
 1440000000000000000" = 1'-0"  
 1680000000000000000" = 1'-0"  
 1920000000000000000" = 1'-0"  
 2160000000000000000" = 1'-0"  
 2400000000000000000" = 1'-0"  
 2700000000000000000" = 1'-0"  
 3000000000000000000" = 1'-0"  
 3600000000000000000" = 1'-0"  
 4200000000000000000" = 1'-0"  
 4800000000000000000" = 1'-0"  
 5400000000000000000" = 1'-0"  
 6000000000000000000" = 1'-0"  
 7200000000000000000" = 1'-0"  
 8400000000000000000" = 1'-0"  
 9600000000000000000" = 1'-0"  
 10800000000000000000" = 1'-0"  
 12000000000000000000" = 1'-0"  
 14400000000000000000" = 1'-0"  
 16800000000000000000" = 1'-0"  
 19200000000000000000" = 1'-0"  
 21600000000000000000" = 1'-0"  
 24000000000000000000" = 1'-0"  
 27000000000000000000" = 1'-0"  
 30000000000000000000" = 1'-0"  
 36000000000000000000" = 1'-0"  
 42000000000000000000" = 1'-0"  
 48000000000000000000" = 1'-0"  
 54000000000000000000" = 1'-0"  
 60000000000000000000" = 1'-0"  
 72000000000000000000" = 1'-0"  
 84000000000000000000" = 1'-0"  
 96000000000000000000" = 1'-0"  
 108000000000000000000" = 1'-0"  
 120000000000000000000" = 1'-0"  
 144000000000000000000" = 1'-0"  
 168000000000000000000" = 1'-0"  
 192000000000000000000" = 1'-0"  
 216000000000000000000" = 1'-0"  
 240000000000000000000" = 1'-0"  
 270000000000000000000" = 1'-0"  
 300000000000000000000" = 1'-0"  
 360000000000000000000" = 1'-0"  
 420000000000000000000" = 1'-0"  
 480000000000000000000" = 1'-0"  
 540000000000000000000" = 1'-0"  
 600000000000000000000" = 1'-0"  
 720000000000000000000" = 1'-0"  
 840000000000000000000" = 1'-0"  
 960000000000000000000" = 1'-0"  
 1080000000000000000000" = 1'-0"  
 1200000000000000000000" = 1'-0"  
 1440000000000000000000" = 1'-0"  
 1680000000000000000000" = 1'-0"  
 1920000000000000000000" = 1'-0"  
 2160000000000000000000" = 1'-0"  
 2400000000000000000000" = 1'-0"  
 2700000000000000000000" = 1'-0"  
 3000000000000000000000" = 1'-0"  
 3600000000000000000000" = 1'-0"  
 4200000000000000000000" = 1'-0"  
 4800000000000000000000" = 1'-0"  
 5400000000000000000000" = 1'-0"  
 6000000000000000000000" = 1'-0"  
 7200000000000000000000" = 1'-0"  
 8400000000000000000000" = 1'-0"  
 9600000000000000000000" = 1'-0"  
 10800000000000000000000" = 1'-0"  
 12000000000000000000000" = 1'-0"  
 14400000000000000000000" = 1'-0"  
 16800000000000000000000" = 1'-0"  
 19200000000000000000000" = 1'-0"  
 21600000000000000000000" = 1'-0"  
 24000000000000000000000" = 1'-0"  
 27000000000000000000000" = 1'-0"  
 30000000000000000000000" = 1'-0"  
 36000000000000000000000" = 1'-0"  
 42000000000000000000000" = 1'-0"  
 48000000000000000000000" = 1'-0"  
 54000000000000000000000" = 1'-0"  
 60000000000000000000000" = 1'-0"  
 72000000000000000000000" = 1'-0"  
 84000000000000000000000" = 1'-0"  
 96000000000000000000000" = 1'-0"  
 108000000000000000000000" = 1'-0"  
 120000000000000000000000" = 1'-0"  
 144000000000000000000000" = 1'-0"  
 168000000000000000000000" = 1'-0"  
 192000000000000000000000" = 1'-0"  
 216000000000000000000000" = 1'-0"  
 240000000000000000000000" = 1'-0"  
 270000000000000000000000" = 1'-0"  
 300000000000000000000000" = 1'-0"  
 360000000000000000000000" = 1'-0"  
 42





03115-333-021A



PLAN AT EL. 244'-8 1/4" AND 249'-6"



SECTION 4-4




SECTION 5-5

SECTION 6-6



NO.	DESCRIPTION	DATE	BY	CHECKED
1	ISSUED FOR PERMIT	11/15/55	J. S. [unclear]	[unclear]
2	ISSUED FOR CONSTRUCTION	11/15/55	J. S. [unclear]	[unclear]
3	ISSUED FOR RECORD	11/15/55	J. S. [unclear]	[unclear]

PROJECT: [unclear]  
 DRAWING NO.: 03115-333-021A  
 SCALE: AS SHOWN  
 SHEET NO.: 11 OF 11




PLAN AT EL. 261'-4"


\* VERTICAL & HORIZONTAL



SECTION 7-7



SECTION 10-10










NO.	DESCRIPTION	QTY.	UNIT	PRICE	TOTAL
1	DUCT	100	LINEAL FT.	1.50	150.00
2	HANGER	50	EA.	2.00	100.00
3	SUPPORT	50	EA.	1.00	50.00
4	INSULATION	100	SQ. FT.	0.50	50.00
5	VALVE	10	EA.	10.00	100.00
6	FITTING	20	EA.	5.00	100.00
7	FLANGE	10	EA.	15.00	150.00
8	PIPE	50	LINEAL FT.	2.00	100.00
9	TEE	5	EA.	20.00	100.00
10	ELBOW	10	EA.	10.00	100.00
11	END CAP	5	EA.	10.00	50.00
12	FLANGING	10	EA.	10.00	100.00
13	WELD	100	HR.	1.00	100.00
14	PAINT	100	SQ. FT.	0.50	50.00
15	LABOR	100	HR.	10.00	1000.00
16	PERMIT	1	EA.	50.00	50.00
17	TESTING	1	EA.	100.00	100.00
18	INSPECTION	1	EA.	50.00	50.00
19	TRAVEL	100	MI.	0.50	50.00
20	OFFICE	100	HR.	5.00	500.00
21	PROFIT				100.00
22	TOTAL				3000.00

THE MCGRAW-HILL COMPANIES

PROJECT: **SECTION 8-8**
  
 DRAWING: **SECTION 8-8**
  
 DATE: **11/11/11**
  
 DRAWN BY: **ACB/D**
  
 CHECKED BY: **D**

PROJECT: **SECTION 8-8**
  
 DRAWING: **SECTION 8-8**
  
 DATE: **11/11/11**
  
 DRAWN BY: **ACB/D**
  
 CHECKED BY: **D**


PROJECT: **SECTION 8-8**
  
 DRAWING: **SECTION 8-8**
  
 DATE: **11/11/11**
  
 DRAWN BY: **ACB/D**
  
 CHECKED BY: **D**







NO.	DESCRIPTION	DATE	BY	CHECKED
1	ISSUED FOR CONSTRUCTION	11/15/50	J.P.	J.P.
2	REVISION			
3	REVISION			
4	REVISION			
5	REVISION			
6	REVISION			
7	REVISION			
8	REVISION			
9	REVISION			
10	REVISION			
11	REVISION			
12	REVISION			
13	REVISION			
14	REVISION			
15	REVISION			
16	REVISION			
17	REVISION			
18	REVISION			
19	REVISION			
20	REVISION			

BR 03115-333-024B  
 PAC 03115-333-024B  
 11/15/50  
 J.P.  
 J.P.  
 31  
 K.P.F.





V100-225-511300



BILL OF MATERIAL \*

ITEM NO.	QTY.	DESCRIPTION	MANUFACTURE/ CATALOG NO.
1	8 EA	STRAIGHT SECTION 24" V X 6" D X 1/2" THK	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-STR024-A
2	22 EA	STRAIGHT SECTION 12" V X 6" D X 1/2" THK	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-STR012-A
3	5 EA	STRAIGHT SECTION 24" V X 6" D X 1/2" THK	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-STR024-A
4	48	90° VERTICAL ELBOW INSIDE BEAD 24" V X 6" D X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-VE024-A
5	1	90° VERTICAL ELBOW OUTSIDE BEAD 24" V X 6" D X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-VE024-A
6	1	90° HORIZONTAL ELBOW 24" V X 6" D X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-HO024-A
7	3	90° HORIZONTAL ELBOW 12" V X 6" D X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-HO012-A
8	3	90° HORIZONTAL ELBOW 24" V X 6" D X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-HO024-A
9	2	30° HORIZONTAL ELBOW 24" V X 6" D X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-HO024-A
10	4	30° HORIZONTAL ELBOW 12" V X 6" D X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-HO012-A
11	1	30° VERTICAL ELBOW INSIDE BEAD 24" V X 6" D X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-VE024-A
12	1	30° VERTICAL ELBOW OUTSIDE BEAD 24" V X 6" D X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-VE024-A
13	5 EA	FLAT COVER 24" V X 1" W/ 1" PEAK	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FC024-A
14	8 EA	FLAT COVER 12" V X 1" W/ 1" PEAK	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FC012-A
15	22 EA	FLAT COVER STRAIGHT SECTION 12" V X 1" W/ 1" PEAK	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FC012-A
16	3	FLAT COVER 30° HORIZ. ELBOW	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FC030-A
17	2	FLAT COVER 45° HORIZ. ELBOW	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FC045-A
18	4	FLAT COVER 90° HORIZ. ELBOW	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FC090-A
19	1	INSIDE BEAD 12" V X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-IB012-A
20	1	OUTSIDE BEAD 12" V X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-OB012-A
21	1 PR	NOND-SYSTEMS INC. FIBER OPTIC TRAY	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FOTRAY
22	100 EA	CLAMP, GROUND WIRE, CABLE TRAY, 1/2" CA STEEL, 25/25, 5/8" X 3/8" X 1/2" W/ 44.0 AVG. VIBE	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-CLAMP
23	AS REQD.	STRAIGHT SECT. UNISTRUT SUPPORT, 1/2" CA STEEL, 25/25, 5/8" X 3/8" X 1/2" W/ 44.0 AVG. VIBE	UNISTRUT CO. CAT. NO. P100
24	AS REQD.	3/8" THREADED ROD, 30" LONG	BY FIELD
25	3	FLAT COVER 30° HORIZ. ELBOW	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FC030-A
26	1	VERTICAL STRIP 30" INSIDE	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-VSTRIP30-A
27	1	VERTICAL STRIP 30" OUTSIDE	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-VSTRIP30-A
28	2	VERTICAL STRIP 45" OUTSIDE	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-VSTRIP45-A
29	2	VERTICAL STRIP 45" INSIDE	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-VSTRIP45-A
30	1	VERTICAL ELBOW 90°	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-VE090-A
31	1	VERTICAL ELBOW 30°	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-VE030-A
32	1	FLAT COVER 30° VERTICAL ELBOW	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FC030-A
33	1	FLAT COVER 45° VERTICAL ELBOW	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FC045-A
34	2	OUTSIDE BEAD 24" V X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-OB024-A
35	2	INSIDE BEAD 24" V X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-IB024-A

\* QUANTITIES INDICATED ARE APPROXIMATE. CONTRACTOR TO PROVIDE ALL MATERIALS REQUIRED FOR A COMPLETE TRAY SYSTEM.

BILL OF MATERIAL \*

ITEM NO.	QTY.	DESCRIPTION	MANUFACTURE/ CATALOG NO.
1	2	FLAT COVER 45° VERTICAL ELBOW	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FC045-A
2	2	INSIDE BEAD 12" V X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-IB012-A
3	2	OUTSIDE BEAD 12" V X 1/2" RAD (CALO)	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-OB012-A
4	1	FLAT COVER 90° HORIZONTAL ELBOW	NOND-SYSTEMS INC. CAT. NO. P-V-6-777-FC090-A



FLOOR ELEVATION	LEGEND
B	BASEMENT
D	DECK
C	CONDENSATION FLOOR
A	APRON FEEDER
T	ATTENUEATOR
P	PRECIPITATOR
F	FAN DECK
R	ROOF

- NOTES:
- FIELD TO SUPPLY AND INSTALL ALL ITEMS SHOWN IN ACCORDANCE WITH APPLICABLE KODAK STANDARDS.
  - AND THE SCOPE OF WORK.
  - ALL DIMENSIONS ARE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (SIDE VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (TOP VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (FRONT VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (REAR VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (BOTTOM VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (LEFT VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (RIGHT VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ISOMETRIC VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (PERSPECTIVE VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (SECTIONAL VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ELEVATION VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (PLAN VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (PROFILE VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (DETAIL VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ENLARGED VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (REDUCED VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (EXPLODED VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (SECTIONAL ASSEMBLY VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (PERSPECTIVE ASSEMBLY VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ISOMETRIC ASSEMBLY VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ELEVATION ASSEMBLY VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (PLAN ASSEMBLY VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (PROFILE ASSEMBLY VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (DETAIL ASSEMBLY VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ENLARGED ASSEMBLY VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (REDUCED ASSEMBLY VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY SECTIONAL VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY PERSPECTIVE VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY ISOMETRIC VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY ELEVATION VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY PLAN VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY PROFILE VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY DETAIL VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY ENLARGED VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY REDUCED VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY SECTIONAL VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY PERSPECTIVE VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY ISOMETRIC VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY ELEVATION VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY PLAN VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY PROFILE VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY DETAIL VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY ENLARGED VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.
  - ALL DIMENSIONS TO TRAY ANGLE (ASSEMBLY REDUCED VIEW) SHALL BE TO CENTER LINE UNLESS OTHERWISE NOTED.

EASTMAN KODAK COMPANY  
 KODAK PARK DIVISION  
 31  
 NOTES, DETS. & BILL OF MAT.  
 KPE

03115-522-001A  
 11  
 12  
 13  
 14  
 15  
 16  
 17  
 18  
 19  
 20  
 21  
 22  
 23

DO315-522-002



CABLE TYPE	CONDUIT FILL CHART	NO. OF CABLES IN CONDUIT	CONDUIT SIZE
1PR-16SCHD	1	3/4"	
1PR-16SCHD	2	3/4"	
1PR-16SCHD	3	1"	
1PR-16SCHD	4	1"	
1PR-16SCHD	5	1 1/4"	
1PR-16SCHD	6	1 1/4"	
1PR-16SCHD	7	1 1/2"	
1PR-16SCHD	8	1 1/2"	
1PR-16SCHD	9	1 1/2"	
1PR-16SCHD	10	2"	

NOTE:  
1. CONDUIT FILL CHART BASED ON NATIONAL ELECTRICAL CODE CHAPTER 9, TABLE A.

REFERENCE:  
DO315-522-001 - ELECTRICAL - CABLE TRAY NOTES, DETAILS & BILL OF MATERIAL.

FLOOR B

5/C-FILE: 46400 - 828022146  
5/C-DATE: 07/24/96 - 3:41 PM


NO.	REVISIONS	DATE	BY	REVISION	DATE	BY
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						
11						
12						
13						

VERTICAL RISER UP TO JUNG DO315-522-003  
BOTTOM OF TRAY EL. 212'-0"

31  
KPE

DO315-522-002 A

300-522-1112



PLAN AT EL. 218'-6"

**CONDUIT FILL CHART**

CABLE TYPE	NO. OF CABLES	CONDUIT SIZE
JBR-15SHLD	2	3/4"
JBR-15SHLD	3	3/4"
JBR-15SHLD	4	1"
JBR-15SHLD	5	1 1/4"
JBR-15SHLD	6	1 1/2"
JBR-15SHLD	7	1 1/2"
JBR-15SHLD	8	1 1/2"
JBR-15SHLD	9	1 1/2"
JBR-15SHLD	10	1 1/2"
JBR-15SHLD	1	3/4"
JBR-15SHLD	2	1"
JBR-15SHLD	3	1"
JBR-15SHLD	4	1 1/4"
JBR-15SHLD	5	1 1/4"
JBR-15SHLD	6	1 1/2"
JBR-15SHLD	7	1 1/2"
JBR-15SHLD	8	1 1/2"
JBR-15SHLD	9	1 1/2"
JBR-15SHLD	10	2"

**NOTE:**  
 1. CONDUIT FILL CHART BASED ON NATIONAL ELECTRICAL CODE CHAPTER 9, TABLE 4.

**REFERENCE:**  
 90315-522-001 - ELECTRICAL - CABLE TRAY NOTES.  
 90315-522-002 - DETAILS & BILL OF MATERIAL.

FLOOR

6/C-FILES, 164005 - 522033.DWG  
 6/C-DATE: 07/24/96 - 3:43 PM

NO.	REVISION	DATE	BY	REVISION	DATE	BY	REVISION	DATE	BY
1									
2									
3									
4									
5									
6									
7									
8									
9									
10									
11									
12									
13									

**GLS/RY/COMP/DE/EL, INC.**  
 DESIGN AND CONSULTING ENGINEERS


**ACAP/D**

**ESTIMAN KOOK COMPANY**  
 KODAK PARK DIVISION

31  
 ELECTRICAL INSTRUMENTATION  
 CABLE TRAY & COMP. LOCATIONS  
 OPER. FLOOR PLAN EL. 218'-6"  
 KPE

003115-522-003 A

03115-522-004



PLAN AT EL. 234'-6"

FLOOR C

CONDUIT FILL CHART		
CABLE TYPE	NO. OF CABLES IN CONDUIT	CONDUIT SIZE
JPR-65SHLD	1	3/4"
JPR-65SHLD	2	3/4"
JPR-65SHLD	3	1"
JPR-65SHLD	4	1"
JPR-65SHLD	5	1 1/4"
JPR-65SHLD	6	1 1/4"
JPR-65SHLD	7	1 1/4"
JPR-65SHLD	8	1 1/2"
JPR-65SHLD	9	1 1/2"
JPR-65SHLD	10	2"
JPR-65SHLD	11	2"
JPR-65SHLD	12	2"
JPR-65SHLD	13	2"
JPR-65SHLD	14	2"
JPR-65SHLD	15	2"
JPR-65SHLD	16	2"
JPR-65SHLD	17	2"
JPR-65SHLD	18	2"
JPR-65SHLD	19	2"
JPR-65SHLD	20	2"
JPR-65SHLD	21	2"
JPR-65SHLD	22	2"
JPR-65SHLD	23	2"
JPR-65SHLD	24	2"
JPR-65SHLD	25	2"
JPR-65SHLD	26	2"
JPR-65SHLD	27	2"
JPR-65SHLD	28	2"
JPR-65SHLD	29	2"
JPR-65SHLD	30	2"
JPR-65SHLD	31	2"
JPR-65SHLD	32	2"
JPR-65SHLD	33	2"
JPR-65SHLD	34	2"
JPR-65SHLD	35	2"
JPR-65SHLD	36	2"
JPR-65SHLD	37	2"
JPR-65SHLD	38	2"
JPR-65SHLD	39	2"
JPR-65SHLD	40	2"
JPR-65SHLD	41	2"
JPR-65SHLD	42	2"
JPR-65SHLD	43	2"
JPR-65SHLD	44	2"
JPR-65SHLD	45	2"
JPR-65SHLD	46	2"
JPR-65SHLD	47	2"
JPR-65SHLD	48	2"
JPR-65SHLD	49	2"
JPR-65SHLD	50	2"

NOTE:  
1. CONDUIT FILL CHART BASED ON NATIONAL ELECTRICAL CODE CHAPTER 9, TABLE A.

REFERENCE:  
- ELECTRICAL - CABLE TRAY NOTES, DD0315-522-001  
DETAILS & BILL OF MATERIAL.

REVISION	DATE	BY	CHKD																

PROJECT NO. DD0315-522-004  
DRAWING NO. 03115-522-004A  
DATE: 07/24/96 3:45 PM  
G/C: TLE 16405, S22004.DWG  
P/C: DMG 07/24/96 3:45 PM

DESIGNED BY: [Signature]  
CHECKED BY: [Signature]  
DATE: 7/27/96

PROJECT: ELECTRICAL/INSTRUMENTATION  
CABLE TRAY & COMP. LOCATIONS  
HRR. & CRUSHER EL. 234'-6"


SCALE: 3/8" = 1'-0"

ACAD/ [Signature]

ESTIMAN KODAK COMPANY  
KODAK PARK DIVISION

31  
RPE

V500-225-51130D



PLAN AT EL. 244'-8 1/4" AND 249'-8"

FLOOR A

VERTICAL RISER UP TO Dwg. 00315-522-006  
VERTICAL RISER DN TO Dwg. 00315-522-004

REFERENCE:  
00315-522-00 - ELECTRICAL - CABLE TRAY NOTES.  
DETAILS & BILL OF MATERIAL.  
00316-341-001 - ELECTRICAL - CABLE TRAY NOTES.  
00316-341-002 - ELECTRICAL - CABLE TRAY NOTES.  
00315-522-009 - ELECTRICAL - EQUIPMENT LOCATIONS.  
APRON FEEDER FLOOR EL. 244'-8 1/4".

- NOTES:
1. ALL CABLE TRAY ELEVATIONS ON THIS DRAWING ARE BASED ON BOILER #15 FLOOR ELEVATION 244'-8 1/4" AND NOT BOILER #16 FLOOR ELEVATION OF 245'-11 3/4".
  2. CONDUIT FILL CHART BASED ON NATIONAL ELECTRICAL CODE CHAPTER 9, TABLE A.

CONDUIT FILL CHART		
CABLE TYPE	NO. OF CABLES IN CONDUIT	CONDUIT SIZE
JPR-15SK-D	2	3/4"
JPR-15SK-D	3	3/4"
JPR-15SK-D	4	1"
JPR-15SK-D	5	1 1/4"
JPR-15SK-D	6	1 1/4"
JPR-15SK-D	7	1 1/2"
JPR-15SK-D	8	1 1/2"
JPR-15SK-D	9	1 1/2"
JPR-15SK-D	10	1 1/2"
JPR-15SK-D	11	2"
JPR-15SK-D	12	2"
JPR-15SK-D	13	2"
JPR-15SK-D	14	2"
JPR-15SK-D	15	2"
JPR-15SK-D	16	2"
JPR-15SK-D	17	2"
JPR-15SK-D	18	2"
JPR-15SK-D	19	2"
JPR-15SK-D	20	2"

SECTION 1-1  
CABLE TRAY DIVISION

NO.	REVISION	DATE	BY	CHKD.	DESCRIPTION
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					


GILBERT/COMMERCIAL, INC.  
 3/16"-1'-0"  
 EASTMAN KODAK COMPANY  
 KODAK PARK DIVISION  
 ELECTRICAL/INSTRUMENTATION  
 CABLE TRAY & COMP. LOCATIONS  
 APRON FL. EL. 244'-8 1/4"  
 KPE  
 003115-522-005 A

















TAG: EAST SCREEN FEEDER FO-CH-1580016



**FILE COPY / FOR REFERENCE**  
WE ARE PROCEEDING w/  
FABRICATION FOR THIS POINT


**ISSUED**  
AUG 01 1985  
MILBUSH SPRCKET & GEAR  
READING, PA 18208

NO	QTY	DESCRIPTION
01	1	14' x 19'-3 5/16" SCREEN CONVEYOR CONSISTING OF:
02	1	14' x 19'-3 5/16" 5'-6" LE. 1/4" TH. FIBERGLASS
03	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
04	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
05	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
06	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
07	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
08	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
09	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
10	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
11	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
12	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS

NO	QTY	DESCRIPTION
13	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
14	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
15	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
16	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
17	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
18	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
19	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
20	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
21	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
22	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS

NO	QTY	DESCRIPTION
23	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
24	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
25	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
26	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
27	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
28	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
29	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
30	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
31	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS
32	1	14' x 19'-3 5/16" 16' 1/4" TH. FIBERGLASS

- GENERAL NOTES:**
1. SHOP ASSEMBLY AND TESTING.
  2. ALL DIMENSIONS ARE TO FACE UNLESS OTHERWISE NOTED.
  3. DIMENSIONS TO FACE UNLESS OTHERWISE NOTED.



DISCHARGE FLANGE  
SCALE: 1/8" = 1"

THIS DRAWING IS THE PROPERTY OF MILBUSH SPRCKET & GEAR, INC. AND MUST BE KEPT CONFIDENTIAL AND NOT MADE PUBLIC OR COPIED UNLESS SO AUTHORIZED BY THEM AND IS SUBJECT TO RETURN ON DEMAND.



**Milbush SPRCKET & GEAR, INC.**  
P.O. BOX 200  
DANIELSVILLE, PA 18028  
PHONE: (610) 837-1941  
FAX: (610) 837-2337










**BUSH-MILLER INC.**  
READING, PA

14' DIA. x 19'-3 5/16" LONG  
SCREEN CONVEYOR ASSEMBLY

REVISION	DATE	BY	DESCRIPTION
1	8/1/85	WJ	ISSUED FOR FABRICATION
2	8/1/85	WJ	ISSUED FOR FABRICATION

M12-63962-2





REVISION

DATE BY

NO. DESCRIPTION

12

11

10

9

8

7

6

5

4

3

2

1

THIS DRAWING IS THE PROPERTY OF ROBINSON AND, INC. AND IS LOANED UNDER CONDITIONS THAT IT IS NOT TO BE REPRODUCED OR COPIED IN WHOLE OR PART FOR REUSE IN ANY MANNER WITHOUT THE WRITTEN PERMISSION OF ROBINSON AND, INC. INTERESTS AND WILL BE RETURNED UPON REQUEST.

SALES ARE DESIGNED FOR A MAXIMUM ANCHOR TEMPERATURE OF 180°F.

DO NOT USE EXHAUSTIVE LUBRICANTS ON THIS UNIT. USE ONLY THE LUBRICANTS SPECIFIED IN THE DRAWING AND IN THE INSTRUCTIONS.

FAN UNIT WILL BE SHIPPED AS ASSEMBLED.

ASSEMBLED DESCRIPTION OF BEST BREAKDOWN LIMITATIONS Provided. Consult Factory. 5000 W.

FAN PERFORMANCE

YEAR	TEMPERATURE	CFM	HP	EFF.
1980	110°F	11,000	1.5	85%
1981	115°F	10,500	1.6	84%
1982	120°F	10,000	1.7	83%
1983	125°F	9,500	1.8	82%
1984	130°F	9,000	1.9	81%
1985	135°F	8,500	2.0	80%
1986	140°F	8,000	2.1	79%
1987	145°F	7,500	2.2	78%
1988	150°F	7,000	2.3	77%
1989	155°F	6,500	2.4	76%
1990	160°F	6,000	2.5	75%

ROBINSON AND, INC.

1600 W. 10th Street, Fort Worth, TX 76102

TELEPHONE: (817) 342-1111

FAX: (817) 342-1112

ESTABLISHED 1948




DA-6180219-194

- NOTES:
- FAN HOUSING & INLET PIECE SHALL BE DRILLED FROM A-30 NPT LUBES. SEE PART 1 FOR ADDITIONAL INFO.
  - OPERATING GUNDS FABRICATED FROM ALU.
  - PAINT TO RECEIVE ONE COAT OF RIB STAINING RED PAST INHIBITIVE PRIMER, 1.5" x 2" x 2" FAN ASSET MATERIAL TO BE 1.8" STAINLESS.
  - FLANGES TO BE DRILLED FOR WEBS AND SHIRT REMOVAL. WEBS NOT SHIRT VENTOR.
  - TOY AIR SPRING (FAN WEBS) (INCL. ASSET)
  - REMARKS: THESE DR AND DR THE STAINING GUN LUBRICATED. USE A PREMIUM GRADE OIL. OILS TO BE WATER COOLER. OILS TO BE WATER COOLER. WATER PRESS. 10 PSI.
  - 1.5" NPT WATER INLET. WATER PRESS. 10 PSI.
  - FROM FAN ARE REQUIRED. FAN ARE TO BE INSTALLED IN ADJACENT TO THE STRUCTURE. FAN ARE TO BE INSTALLED WITH APPROX. 18" CLEARANCE FROM THE STRUCTURE. FAN ARE TO BE INSTALLED WITH APPROX. 18" CLEARANCE FROM THE STRUCTURE.
  - 1.5" NPT WATER INLET. WATER PRESS. 10 PSI.
  - FROM FAN ARE REQUIRED. FAN ARE TO BE INSTALLED IN ADJACENT TO THE STRUCTURE. FAN ARE TO BE INSTALLED WITH APPROX. 18" CLEARANCE FROM THE STRUCTURE.
  - 1.5" NPT WATER INLET. WATER PRESS. 10 PSI.
  - FROM FAN ARE REQUIRED. FAN ARE TO BE INSTALLED IN ADJACENT TO THE STRUCTURE. FAN ARE TO BE INSTALLED WITH APPROX. 18" CLEARANCE FROM THE STRUCTURE.

MATERIAL LIST

ITEM NO.	DESCRIPTION	QTY.
1	FAN HOUSING	1
2	INLET PIECE	1
3	WEBS	18
4	OPERATING GUNDS	18
5	PAINT	1
6	PRIMER	1
7	FLANGES	2
8	SHIRT	1
9	TOY AIR SPRING	1
10	OIL	1
11	WATER COOLER	1
12	1.5" NPT WATER INLET	1
13	FROM FAN ARE REQUIRED	1
14	ADJACENT TO THE STRUCTURE	1
15	18" CLEARANCE FROM THE STRUCTURE	1






REV	DESCRIPTION	BY	DATE
1	ISSUED FOR FABRICATION		
2	REVISED DRAWING		
3	1" TUBING @ 4" ON C.		

EASTMAN KODAK  
 ROCHESTER N.Y.  
 ACCESS DOOR OPENING  
 J-960704B

















*1000' 11' 1/4\"/>*



*1000' 11' 1/4\"/>*





SEE ATKINSON DRAWING D-2038-01 FOR NOTES.

		THE SERVICES OF AN ELECTRICAL ENGINEER ARE HEREBY CERTIFIED AS HAVING BEEN RENDERED IN ACCORDANCE WITH THE REQUIREMENTS OF THE PROFESSIONAL ENGINEERING ACT OF 1908, AS AMENDED, IN THE STATE OF NEW YORK.	
PROJECT NO. _____ DRAWING NO. _____ SHEET NO. _____ OF _____ DATE _____	PROJECT NO. _____ DRAWING NO. _____ SHEET NO. _____ OF _____ DATE _____	PROJECT NO. _____ DRAWING NO. _____ SHEET NO. _____ OF _____ DATE _____	PROJECT NO. _____ DRAWING NO. _____ SHEET NO. _____ OF _____ DATE _____
ATKINSON POWER CENTER OUTLINE - ELEVATION		EASTMAN HOUSE P.A. 84-66-02/04	
1/2" = 1'-0"		0	
D-2038-02		00-00-00-00	


**FOR APPROVAL**  
 DATE SUBMITTED: JUN 11 1998  
 RETURN BY: JUN 17 1998  
 APPROVED AS SHOWN:   
 APPROVED AS NOTED:   
 NOT APPROVED REVISION:   
 BY: *[Signature]* DATE: 6/17/98  
 PROJECT NO. 84-66-02/04  
 DRAWING NO. 00-00-00-00







- NOTES:**
1. BHS LOGIC PANEL IS NEMA 12 HOFFMAN A-50MB12-2-LP CARBON STEEL. FINISH: WHITE ENAMEL INSIDE WITH RECONABLE ANS1 61 GRAY OUTSIDE.
  2. FOR WIRING AND WIRE NOTES SEE D-9681-044.
  3. FOR SUB-PANEL ARRANGEMENT SEE SHEET 2 OF THIS DRAWING.



**DETAIL A**  
SCALE: 1/2

**REVISIONS**

NO.	DATE	DESCRIPTION
1	11/18/78	ISSUED FOR FABRICATION

*SLASH DETAIL*


<b>MASTER REV.</b>		UNLESS OTHERWISE NOTED:	
1.	ALL DIMENSIONS ARE IN INCHES	DATE	11/18/78
2.	FRACTIONS ARE TO BE SHOWN AS X/16	DESIGNER	E. J. COEN
3.	ALL DIMENSIONS ARE TO BE SHOWN AS X.X	CHECKED	J. J. COEN
4.	ALL DIMENSIONS ARE TO BE SHOWN AS X.XX	DATE	11/18/78
5.	ALL DIMENSIONS ARE TO BE SHOWN AS X.XXX	PROJECT	ENCLOSURE DIAGRAM
6.	ALL DIMENSIONS ARE TO BE SHOWN AS X.XXXX	CONTRACT NO.	300-12870-1
7.	ALL DIMENSIONS ARE TO BE SHOWN AS X.XXXX	PLANT NO.	300-12870-1
8.	ALL DIMENSIONS ARE TO BE SHOWN AS X.XXXX	PLANT NO.	300-12870-1
9.	ALL DIMENSIONS ARE TO BE SHOWN AS X.XXXX	PLANT NO.	300-12870-1
10.	ALL DIMENSIONS ARE TO BE SHOWN AS X.XXXX	PLANT NO.	300-12870-1

**COEN** CONSULTING ENGINEERS  
ENCLOSURE DIAGRAM  
PLC LOGIC PANEL  
BOILER 15


SCALE: 1" = 1/8"

**D 9683-044**


SHEET 1 OF 5




EAST 8 WEST 1/0 ENCLOSURE  
FRONT VIEW  
A-6248CLP




LOGIC CABINET MOUNTING PATTERN



SIDE VIEW



CUTOUT B  
SCALE 1/2



DETAIL A  
SCALE 1/2

- NOTES:**
1. BMS LOGIC PANEL IS MEHA & HOFFMAN A-6248CLP CARBON STEEL. FINISH, WHITE EMBEL, INSIDE WITH RECOATABLE ANST 61 GRAY OUTSIDE.
  2. FOR WIRING AND WIRE NOTES SEE D-9681-044.
  3. FOR SUB-PANEL ARRANGEMENT SEE SHEET 4 & 5 OF THIS DRAWING.

REVISIONS FOR THE SCALE DRAWING  
THIS DRAWING IS THE PROPERTY OF  
COEN COMPANY  
CONSTRUCTION, AND NOT BE REPRODUCED  
OR COPIED IN ANY MANNER WITHOUT THE  
WRITTEN PERMISSION OF COEN COMPANY  
OR ITS SUCCESSORS. (REVISED 10/11/83)

SCALE: OVERSIZE WITH  
1. ALL DIMENSIONS ARE IN  
INCHES  
2. DIMENSIONS  
3. DIMENSIONS  
4. DIMENSIONS  
5. DIMENSIONS  
6. DIMENSIONS  
7. DIMENSIONS  
8. DIMENSIONS  
9. DIMENSIONS  
10. DIMENSIONS

DATE	REV	DESCRIPTION
10/11/83	1	ENCLOSURE DIAGR EAST 8 WEST 1/0 KODK PANEL
10/11/83	2	ENCLOSURE DIAGR EAST 8 WEST 1/0 KODK PANEL
10/11/83	3	ENCLOSURE DIAGR EAST 8 WEST 1/0 KODK PANEL
10/11/83	4	ENCLOSURE DIAGR EAST 8 WEST 1/0 KODK PANEL
10/11/83	5	ENCLOSURE DIAGR EAST 8 WEST 1/0 KODK PANEL


ENCLOSURE DIAGR EAST 8 WEST 1/0 KODK PANEL  
ENCLOSURE DIAGR EAST 8 WEST 1/0 KODK PANEL

SCALE: 1" = 3/16"

NO. OF COPIES	1000


NOTES:  
1. REMOVE HINGE AND TYPING TERMINAL  
2. FULLY PROVE  
3. COVER  
4. FLUSH  
5. END  
6. END  
7. END  
8. END  
9. END  
10. END

ENCLOSURE DIAGR EAST 8 WEST 1/0 KODK PANEL  
ENCLOSURE DIAGR EAST 8 WEST 1/0 KODK PANEL



TYPE 1 AND 2 ENCLOSURES FOR AUTOMATIC TRANSFER SWITCHES WITHOUT OPTIONAL ACCT. 28 OVERLAPPING NEUTRAL TRANSFER CONTACT

AMP. SIZE	DIMENSIONS		WEIGHT	
	A	B	LBS.	KG.
30, 70, 100, 150	11.50	21.00	11.42	5.19
200	14.50	24.00	16.63	7.54
400	17.50	27.00	21.84	9.89
600	20.50	30.00	27.05	12.24
800	23.50	33.00	32.26	14.59
1000	26.50	36.00	37.47	16.94
1200	29.50	39.00	42.68	19.29
1500	32.50	42.00	47.89	21.64
2000	38.50	48.00	58.30	26.41
3000	44.50	54.00	68.71	31.18
4000	50.50	60.00	79.12	35.95



TYPE 3R, 4, AND 12 ENCLOSURES FOR AUTOMATIC TRANSFER SWITCHES WITHOUT OPTIONAL ACCT. 28 OVERLAPPING NEUTRAL TRANSFER CONTACT

AMP. SIZE	DIMENSIONS		WEIGHT	
	A	B	LBS.	KG.
30, 70, 100, 150	11.50	21.00	11.42	5.19
200	14.50	24.00	16.63	7.54
400	17.50	27.00	21.84	9.89
600	20.50	30.00	27.05	12.24
800	23.50	33.00	32.26	14.59
1000	26.50	36.00	37.47	16.94
1200	29.50	39.00	42.68	19.29
1500	32.50	42.00	47.89	21.64
2000	38.50	48.00	58.30	26.41
3000	44.50	54.00	68.71	31.18
4000	50.50	60.00	79.12	35.95

- NOTES - ① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ⑩ ⑪ ⑫ ⑬ ⑭ ⑮ ⑯ ⑰ ⑱ ⑲ ⑳ ㉑ ㉒ ㉓ ㉔ ㉕ ㉖ ㉗ ㉘ ㉙ ㉚ ㉛ ㉜ ㉝ ㉞ ㉟ ㊱ ㊲ ㊳ ㊴ ㊵ ㊶ ㊷ ㊸ ㊹ ㊺ ㊻ ㊼ ㊽ ㊾ ㊿
- REMOVABLE DOORS, KEY LOCKING HANDLE, SINGLE DOOR CAPTION ON RIGHT SIDE WITH SINGLE CENTER LATCH AND TWO DOOR WITH 3-POINT AND BOTTOM FOR 30 THRU 600 AMPS.
  - FULL WIRING CUTTERS AND 0.75-0.1000 THRU 1200 AMPS.
  - TERMINAL PIVOT KNOCKOUTS PROVIDED TOP AND BOTTOM ONLY.
  - PROVIDE A DCS SEAL WITH GASGETTING TO
  - FLASH MOUNTED TYPES HAVE REMOVABLE FLASH DOOR AND TRIM.
  - ADJUST OVERLAPS 1.00" 25.4 MM. ON ALL SIDES.
  - EXTERNAL MOUNTING FOR FLASH MOUNTED ENCLOSURES, 1000-1200 AMPS ONLY. (SHOW WITH MOUNTING HOLES FOR THE 2 ENCLOSURES ARE PROVIDED WITH A TOP MOUNTED HE ENCLOSURE. A PIVOT KNOCKOUT PROVIDED IN BOTTOM ONLY.


TYPE 1 AND 2 ENCLOSURES FOR AUTOMATIC TRANSFER SWITCHES WITH OPTIONAL ACCT. 28 OVERLAPPING NEUTRAL TRANSFER CONTACT

AMP. SIZE	DIMENSIONS		WEIGHT	
	A	B	LBS.	KG.
30, 70, 100, 150	17.50	31.00	11.42	5.19
200	20.50	34.00	16.63	7.54
400	23.50	37.00	21.84	9.89
600	26.50	40.00	27.05	12.24
800	29.50	43.00	32.26	14.59
1000	32.50	46.00	37.47	16.94
1200	35.50	49.00	42.68	19.29
1500	38.50	52.00	47.89	21.64
2000	44.50	58.00	58.30	26.41
3000	50.50	64.00	68.71	31.18
4000	56.50	70.00	79.12	35.95

- NOTES
- SINGLE DOOR HINGED ON RIGHT SIDE WITH PADLOCK HASP. PLATED DOOR CLAMPS ON THREE (3) SIDES FOR TYPE 3R & 12. (50A) 10
  - TWO DOOR TYPE 4 ENCLOSURES HAVE REMOVABLE CENTER PIVOT INSTALLED BETWEEN DOORS. TWO DOOR TYPE 3R DOOR HAVE 3-POINT LATCHING WITH KEY LOCKING HANDLE. (1000) WEAVE 3-POINT LATCHING WITH KEY LOCKING FULL WIRING CUTTERS PROVIDED TOP AND BOTTOM.
  - NO KNOCKOUTS PROVIDED

TYPE 3R, 4, AND 12 ENCLOSURES FOR AUTOMATIC TRANSFER SWITCHES WITH OPTIONAL ACCT. 28 OVERLAPPING NEUTRAL TRANSFER CONTACT

AMP. SIZE	DIMENSIONS		WEIGHT	
	A	B	LBS.	KG.
30, 70, 100, 150	17.50	31.00	11.42	5.19
200	20.50	34.00	16.63	7.54
400	23.50	37.00	21.84	9.89
600	26.50	40.00	27.05	12.24
800	29.50	43.00	32.26	14.59
1000	32.50	46.00	37.47	16.94
1200	35.50	49.00	42.68	19.29
1500	38.50	52.00	47.89	21.64
2000	44.50	58.00	58.30	26.41
3000	50.50	64.00	68.71	31.18
4000	56.50	70.00	79.12	35.95




APPROXIMATE SHIPPING WEIGHT, LBS (KG). WEIGHT INCLUDES STANDARD TRANSFER SWITCH & CONTROLS

AMP. SIZE	TYPE 1 & 2	TYPE 3R, 4, & 12
30, 70, 100	11.42	11.42
200	16.63	16.63
400	21.84	21.84
600	27.05	27.05
800	32.26	32.26
1000	37.47	37.47
1200	42.68	42.68
1500	47.89	47.89
2000	58.30	58.30
3000	68.71	68.71
4000	79.12	79.12

- GENERAL NOTES (FIGURES 1, 2, & 3)
- ENCLOSURES CONSTRUCTED IN ACCORDANCE WITH UL STANDARD 508, OR UL 50.
  - STANDARD FINISH-LIGHT GREY ANSI 96.1.
  - WIDTH, HEIGHT AND DEPTH DIMENSIONS ON FIG. 1 ARE INSIDE DIMENSIONS. WIDTH, HEIGHT, AND DEPTH DIMENSIONS ON FIG. 2 & 3 ARE OUTSIDE DIMENSIONS.
  - THE TRANSFER SWITCH UNIT IS MOUNTED ON THE INSIDE BACK SURFACE AND THE ACCESSORY SURFACE PANEL MOUNTED ON THE INSIDE DOOR TO THE TRANSFER SWITCH PANEL IS CONNECTED HARNESS WITH A DOLBY DISCONNECT PLUG.
  - AN OPERATOR'S MANUAL IS FURNISHED WITH EACH AUTOMATIC TRANSFER SWITCH. INSTALL TO THIS PUBLICATION PRIOR TO INSTALLATION AND OPERATION OF THE SWITCH.

SIZES OF UL LISTED SOLDERLESS SCREW TYPE TERMINALS FOR EXTERNAL POWER CONNECTIONS SWITCH BATING WIRE SIZES

AMP. SIZE	WIRE SIZE	NAME OF AL-CU
30	10	10-10
70	10	10-10
100	10	10-10
150	10	10-10
200	10	10-10
400	10	10-10
600	10	10-10
800	10	10-10
1000	10	10-10
1200	10	10-10
1500	10	10-10
2000	10	10-10
3000	10	10-10
4000	10	10-10



APPROXIMATE SHIPPING WEIGHT, LBS (KG). WEIGHT INCLUDES STANDARD TRANSFER SWITCH & CONTROLS

AMP. SIZE	TYPE 1 & 2	TYPE 3R, 4, & 12
30, 70, 100	11.42	11.42
200	16.63	16.63
400	21.84	21.84
600	27.05	27.05
800	32.26	32.26
1000	37.47	37.47
1200	42.68	42.68
1500	47.89	47.89
2000	58.30	58.30
3000	68.71	68.71
4000	79.12	79.12

- GENERAL NOTES (FIGURES 1, 2, & 3)
- ENCLOSURES CONSTRUCTED IN ACCORDANCE WITH UL STANDARD 508, OR UL 50.
  - STANDARD FINISH-LIGHT GREY ANSI 96.1.
  - WIDTH, HEIGHT AND DEPTH DIMENSIONS ON FIG. 1 ARE INSIDE DIMENSIONS. WIDTH, HEIGHT, AND DEPTH DIMENSIONS ON FIG. 2 & 3 ARE OUTSIDE DIMENSIONS.
  - THE TRANSFER SWITCH UNIT IS MOUNTED ON THE INSIDE BACK SURFACE AND THE ACCESSORY SURFACE PANEL MOUNTED ON THE INSIDE DOOR TO THE TRANSFER SWITCH PANEL IS CONNECTED HARNESS WITH A DOLBY DISCONNECT PLUG.
  - AN OPERATOR'S MANUAL IS FURNISHED WITH EACH AUTOMATIC TRANSFER SWITCH. INSTALL TO THIS PUBLICATION PRIOR TO INSTALLATION AND OPERATION OF THE SWITCH.

SIZES OF UL LISTED SOLDERLESS SCREW TYPE TERMINALS FOR EXTERNAL POWER CONNECTIONS SWITCH BATING WIRE SIZES

AMP. SIZE	WIRE SIZE	NAME OF AL-CU
30	10	10-10
70	10	10-10
100	10	10-10
150	10	10-10
200	10	10-10
400	10	10-10
600	10	10-10
800	10	10-10
1000	10	10-10
1200	10	10-10
1500	10	10-10
2000	10	10-10
3000	10	10-10
4000	10	10-10

- NOTES
- TYPE 1 FREE STANDING, FLOOR SUPPORTED, FRAME CONSTRUCTION.
  - REMOVABLE DOORS, KEY LOCKING HANDLE, SINGLE CENTER LATCH AND TWO DOOR WITH 3-POINT AND BOTTOM FOR 30 THRU 600 AMPS.
  - TERMINAL PIVOT KNOCKOUTS PROVIDED TOP AND BOTTOM ONLY.
  - PROVIDE A DCS SEAL WITH GASGETTING TO
  - FLASH MOUNTED TYPES HAVE REMOVABLE FLASH DOOR AND TRIM.
  - ADJUST OVERLAPS 1.00" 25.4 MM. ON ALL SIDES.
  - EXTERNAL MOUNTING FOR FLASH MOUNTED ENCLOSURES, 1000-1200 AMPS ONLY. (SHOW WITH MOUNTING HOLES FOR THE 2 ENCLOSURES ARE PROVIDED WITH A TOP MOUNTED HE ENCLOSURE. A PIVOT KNOCKOUT PROVIDED IN BOTTOM ONLY.

APPROXIMATE SHIPPING WEIGHT, LBS (KG). WEIGHT INCLUDES STANDARD TRANSFER SWITCH & CONTROLS

AMP. SIZE	TYPE 1 & 2	TYPE 3R, 4, & 12
30, 70, 100	11.42	11.42
200	16.63	16.63
400	21.84	21.84
600	27.05	27.05
800	32.26	32.26
1000	37.47	37.47
1200	42.68	42.68
1500	47.89	47.89
2000	58.30	58.30
3000	68.71	68.71
4000	79.12	79.12

- GENERAL NOTES (FIGURES 1, 2, & 3)
- ENCLOSURES CONSTRUCTED IN ACCORDANCE WITH UL STANDARD 508, OR UL 50.
  - STANDARD FINISH-LIGHT GREY ANSI 96.1.
  - WIDTH, HEIGHT AND DEPTH DIMENSIONS ON FIG. 1 ARE INSIDE DIMENSIONS. WIDTH, HEIGHT, AND DEPTH DIMENSIONS ON FIG. 2 & 3 ARE OUTSIDE DIMENSIONS.
  - THE TRANSFER SWITCH UNIT IS MOUNTED ON THE INSIDE BACK SURFACE AND THE ACCESSORY SURFACE PANEL MOUNTED ON THE INSIDE DOOR TO THE TRANSFER SWITCH PANEL IS CONNECTED HARNESS WITH A DOLBY DISCONNECT PLUG.
  - AN OPERATOR'S MANUAL IS FURNISHED WITH EACH AUTOMATIC TRANSFER SWITCH. INSTALL TO THIS PUBLICATION PRIOR TO INSTALLATION AND OPERATION OF THE SWITCH.

SIZES OF UL LISTED SOLDERLESS SCREW TYPE TERMINALS FOR EXTERNAL POWER CONNECTIONS SWITCH BATING WIRE SIZES

AMP. SIZE	WIRE SIZE	NAME OF AL-CU
30	10	10-10
70	10	10-10
100	10	10-10
150	10	10-10
200	10	10-10
400	10	10-10
600	10	10-10
800	10	10-10
1000	10	10-10
1200	10	10-10
1500	10	10-10
2000	10	10-10
3000	10	10-10
4000	10	10-10

Automatic Switch Co. Composite Enclosure Outline and Mounting Diagram for 2 or 3 Pole 30 Through 4000 Amperes ASCA® 940 Automatic Transfer Switches and 386 Non-Automatic Transfer Switches. US 401853



